

THERE IS ONLY ONE GATE LATCH AND ONE MOTOR.

THIS IS LOCATED IN THE CENTER OF THE MIDDLE POLE.

THE 2 OUTER POLES ARE CONNECTED TO THE MIDDLE POLE AND WILL SPIN WHEN IT IS RELEASED.

MORE THAN LIKELY WE NEED TO HAVE A SECONDARY PULL CORD ATTACHED TO THE PULL PIN THAT RUNS TO THE BACK OF THE STAGE OUT OF VIEW. THAT WAY IF THE MOTOR FAILS, A PERSON CAN PULL ON THE CORD AND RELEASE THE CURTAIN.

