



General method for lift units. Modify as needed.
NOTE: Hinges NEVER bear the unit weight.