



Ion disassemble




1) Loosen but do not remove 3 screws on bottom edge.



2) Remove 2 screws holding side cover, and remove cover. Repeat for opposite side.



3) Remove 7 side screw indicated in blue. Leaving the 3 screws marked in red. Repeat for opposite side.



4) Remove 2 screws holding back cover. Repeat for opposite side.

5) To remove power supply, remove 4 screws around fan at back.