

24/48, 48/96, 72/144 Two scene preset Lighting control system Version 3.1

Copyright © 2001 Electronic Theatre Controls, Inc. All rights reserved. Product information and specifications subject to change. Part Number: 4110M1009 Rev B Released: June 2001

Contents

• • • •	-
	Chapter 1
	Introduction
	Using this manual
	Setting up the console
	New users
	Keyboard Help
	Text conventions
	Navigation and visual feedback
	Output level conventions
	HTP channels
	I TP Channels
	Enabling I TP
	Working with I TP channels
	Moving light concents and terms
	Fixtures
	Fixture attributes
	Parsonalities
	The Only command
	When recalling channels
	Sepoitivity
	Electronic backup maintenance
	Chanter 2
	Monitor dianlovo
	Colors in displays
	Channel numbers/Standard patch
	Channel numbers/Fixture patch
	Channel output levels
	Changing pages
	Display features
	Stage
	Blind

Colors in displays 14
Channel numbers/Standard patch
Channel numbers/Fixture patch
Channel output levels 14
Changing pages 14
Display features
Stage
Blind
Fader
Flexichannel
Updating Flexichannel 18
Patch

Chapter 3

System settings	 	 	 	 	 	 21
Setting the number of dimmers	 	 	 	 	 	 22
Setting the number of channels	 	 	 	 	 	 23
Setting default fade times	 	 	 	 	 	 24
Setting default Level key	 	 	 	 	 	 25
Setting default fader clear time	 	 	 	 	 	 25

	Setting default sneak time	5
	Enable / disable Blackout key 27	1
	Enable / disable Flexichannel	1
	Set grandmaster type 28	3
	Set channels / submasters 1-to-1	3
	Record lockout)
	Enable / disable bump buttons)
	Scene mode)
	Setting the clock	
	Clock functions display	
	Davlight Savings Time 32	,
	Set time/date 32	,
	12/24 hour clock 32	,
	l atitude longitude time zone	- 2
		, 1
	About 5110W	5
Chai	nter 4	
Data	hing abannala	
rau)
) -
	Creating a custom patch	
	Proportional patching	3
	Unpatching individual dimmers)
	Show labels)
	Dimmer profiles)
	Pre-defined profiles 40)
	Assigning a profile to a dimmer	
	Profiles display	
	Creating or editing a profile 42)
	Copying to another profile	,
	Clear All	3
	Clear to End 43	3
	Fill Between 43	3
	Resetting a profile 43	Ś
	Cantured channels in Patch 44	Ĺ
	Dimmer check	5
	About Dimmer 46	;
	About Dimmer with ETCL ink 40	,
	Sotting dimmore to Dimmor Doubling	,
	Detabling to a Strand CD20 dimmor rack	י ג
		,
Chai	nter 5	
Cott	ing channal lovale	
งยแ		1
	Channel modes	
	Selected channels	-
	Captured channels	-
	Recorded channels 52	, -
	Moving channels) -
	Tracked channels 52	2
	Channel Attributes display	3
	Editing in the Channel Attributes display	ŀ
	Independent channels 54	ŀ
	Flipped channels 54	ł
	Channel data type 55	; ;
	Channel convention	5
	Selecting channels	3

S S S C	electing channels in Flexichannel mode etting channel levels Channel sliders Trackpad Full Level key Flash neak	56 57 57 57 57 57 57 57 58 59
A	bout Channel	60
Chant		00
Vqqiu	UI O na maving lighta ta tha ahaw	~~
Addin N P P A E V	Ig moving Light Functions menu ersonality Setup Go to the Personality Setup display Loading personalities into the console Viewing a personalities Resetting defaults atching moving lights Go to the Fixture Patch display Patching one fixture or a fixture range Editing the fixture list ttribute Setup Go to the Encoder Setup display Changing assignments Vorking with moving lights Moving lights displays Go to the Fixture Box window Working with fixtures	63 65 666 677 688 690 712 737 755 757
	Setting levels in the Fixture Box	77
Chant	rer 7	/8
Clies		79
C R V T W R V	ue types Crossfade Allfade Effect Blocking Subroutine ecording functions Effect iewing cues Effect he oversized show Creating the oversized show Playing back an oversized show Vorking with cues in Stage ecording a cue in Stage Vorking with cues in Blind Recording a cue in Blind Ecording a cue in Blind	 80 80 80 80 80 80 80 80 80 81 82 82 83 84 84

Recording a cue with split fade times
Recording a cue with a wait time
Recording cues with Link and Follow
Link
Follow
Create playback loops with Link and Follow
Linking a macro to a cue
Recording a cue using Solo
Using Solo to record selected lights
Using Solo as a pre-recording filter
Labeling cues
Modifying a recorded cue live
Modifying channels in a cue
Modifying cue attributes
Updating cues
Insorting cues
Chapter 8
Track 101
Track record 102
Using record to create tracks
Recording modified cues
Inserting cues
Blackout cues and tracking
Chautau D
Multipart cues
Recording a multipart cue 112
Converting a standard cue to a multipart cue
Wait times in multipart cues 114
Editing a multipart cue
Deleting a part from a multipart cue
Adding, deleting and modifying channels
Using Update
Modifying fade and wait times
Chanter 10
Diaving back europ
ו iayiiy שמנה נעכס

laying back cues	119
Fader keys	121
Clear	121
Go	121
Hold	121
Back	121
Cue List	122
Fader Status display	123
Selecting cues	123
Playing a cue	124
Go to a different cue	124
Controlling fades manually	125
Manual override	125
Rate override	126
Quickstep	127

Chapter 11 Groups

ps	. 129
Recording a group in Stage	. 130
Recording a group from a look on stage	. 130
Recording a group using Solo	. 131
Working with groups in Blind	. 131
Group mode	. 131
Group Editing mode in Blind	. 132
Working with groups in Stage	. 133
Displaying a group	. 133
Modifying a group	. 133
Updating groups	. 134
Labeling groups	. 136
Deleting groups	. 137
Copying groups	. 137
Using cues and submasters as groups	. 138
Modifying cues or submasters	. 139

Chapter 12 Focus points

D cus points	41
Recording a focus point 14	42
Recording a focus point in Stage	42
Creating a focus point from a look on stage	42
Recording a focus point using Solo 14	43
Working with focus points in Stage 14	44
Placing a focus point on stage 14	44
Modifying a focus point 14	44
Updating focus points 14	45
Editing a focus point in Blind 14	47
Labeling focus points 14	48
Deleting focus points 14	49
Copying focus points 14	49
Setting levels with focus points 1	50

Chapter 13 Submasters

bmasters	151
Submaster types	152
Pile-on submaster	152
Inhibitive submaster	152
Effect submaster	152
Changing type	153
Submaster pages	154
Submaster bump buttons	155
Bump button status í	155
Submaster LEDs	156
Recording submasters	157
Fade and dwell times for submasters	157
Adding a rate to a submaster	160
Specifying a submaster's page	161
Using Except to record a submaster	161
Inhibitive submasters	162
Creating	162
Adding channels	163
Deleting channels	163

Modifying submasters in Blind	. 164
Modifying submasters in Stage	. 164
Re-recording submasters	. 165
Updating submasters	. 167
Live control of a submaster's rate	. 167
Controlling submaster fades manually	. 167
Labeling submasters	. 168
Copying submasters	. 169
Loading cues or groups to submasters	. 169
Copying cues or groups to submasters	. 170
Clearing submasters	. 170
Chanter 14	
Lists and spreadsheets	. 171
Cue List	. 172
Editing cues	. 172
Submaster List	. 173
Editing submasters	. 174
Deleting submasters	. 175
Group List	. 176
Labeling a group	. 176
Deleting a group	. 177
Focus Point List	. 177
Labeling a focus point	. 178
Deleting a focus point	. 178
Working in spreadsheets	. 179
Cue spreadsheet	. 179
Submaster spreadsheet	. 182
Group spreadsheet	. 184
Focus point spreadsheet	. 186
Chapter 15 Park Using the Park display Parking dimmers	. 189 . 190 . 190

Using the Park display 190
Parking dimmers 190
Unparking dimmers 191
Unparking one dimmer 191
Unparking all dimmers 191
Parking channels 192
Using the keyboard 192
Parking at a focus point 192
Unparking channels 193
Unparking one channel 193
Unparking all channels 193
Parking recorded channels 194
Unparking recorded channels 194
Parking fixtures 195
After setting attribute levels from the keypad 195
After setting attribute levels at a focus point
Unparking fixtures 196

Chapter 16	
	197
Blind Effects display	198
	198
Effects in Stage	199
Creating an effect in Blind	200
Notes on working with steps in Blind	201
Adding channels directly	201
Adding groups or focus points	202
Adding grouped channels	203
Creating an effect in Stage	204
Notes on working with steps in Stage	204
Adding channels directly	204
Adding groups or focus points	205
Adding grouped channels	206
Modifying the effect	207
Using Update	207
Editing channel levels	208
Adding channels	208
Deleting channels	209
Inserting steps	210
Deleting steps	211
Modifying effect attributes	212
Modifying step timing and levels	213
Effect fade times	214
Changing unfade, dwell and downfade	215
	215
Changing downfade only	215
	210
Posstting hold dwall time	210
Sotting a random offact rate	210
Dupping on offect que	217
	217
	217
Chanter 17	
Cubroutinoo	
Suproutines	219
Steps	220
Cue steps	220
Style steps	221
Subroutine attributes	221
Creating subroutines	222
Editing a subroutine	224
Deleting a step	224
Inserting a step	224
01 / 40	

Chapter 18 Macros

ICTOS
Creating macros
Using Learn
Using Macro Editing 228
Macro wait
Linking macros
Using submasters in macros

CL -	Playing macros Canceling a macro Powerup macro Modifying macros Clearing macros Copying macros Sample macros	232 232 233 233 233 234 234
Cha Link	apter 19 k lists Link List overview Setting up a link Inserting a link Moving a link Merging two links Deleting a link Using a link	237 238 239 240 241 241 242 242
Cha	apter 2U kette functions Diskette management Formatting diskettes Contents of the showfile Writing to diskette Reading from diskette Read show and configuration Read show components only Read system configuration components only	243 244 245 245 246 246 247 247
Cha Prin Cha	apter 21 nting Printer options Printing procedure Printouts available Moving lights	249 250 250 251 251
Clea	ar functions Clear functions Clear and reset procedure Clear and reset options	253 254 254 255
Cha Two	apter 23 o scene preset Setting the scene mode Express 24/48 Express 48/96 and 72/144 The two scene faders Two scene status display Manual crossfades Flash a scene Timed crossfades Pause a timed crossfade	257 258 258 259 260 261 261 262 262

Chapter 24 Dimmer mon

mmer monitoring	263
ETCLink functions	264
Enabling ETCLink	264
Error messages	265
How to enable / disable ETCLink error messages	266
ETCLink displays	267
Dimming system status	267
Dimmer rack status	268
Dimmer status	269
Monitoring dimmers	270
Load Management display	270
Record Loads procedure	271
Load Check procedure	272
Clear Loads procedure	273
Setting and unsetting dimmers	274
Setting a dimmer	274
Unsetting a dimmer	274
Working with Sensor backup looks	275
Recording a backup look	275
Playing a backup look	276

Chapter 25 Control inte

ontrol interfaces	277
MIDI	278
ETC MIDI	278
MIDI Show Control (MSC)	281
Real time programs	286
Go to the Real Time Programs display	286
Enabling / disabling real time programs	287
Creating real time programs	288
Editing real time programs	290
Deleting real time programs	290
Inserting real time programs	290
Copying real time programs	291
Moving real time programs	291
Sorting/recording real time programs	291
Time Code	292
Setting time code frame rate	292
Creating a time code program	293
Sorting/recording events	296
Editing time code programs	296
Re-setting the event list pointer	296
Resetting loop time	297
Deleting time code events	298
Inserting time code events	298
Copying time code events	299
Moving time code events	300
Editing events	301
Running a time code program	303
Remote macros	306
Serial interface	306
Remote trigger	307

Chapter 26

Accessories 3 Remote Focus Unit (RFU) 3 Alphanumeric keyboard 3 Console lights 3 Expression Off-Line 3	309 310 311 312 312
Appendix A	
Installation	313
Console's back panel 3	314
External device fuse	314
Installing the console and monitor	315
VGA monitor connections	315
Understanding ETCNet	316
Installing interface devices	316
Network wiring 3	316
Preparing interface devices	316
Connecting dimmers to console	318
Configuring the DMX512 ports 3	319
Port starting dimmer numbers	319
Setting the port to Dimmer Doubling	320
Setting DMX512 speed 3	320
Installing an alphanumeric keyboard	321
Installing a printer	322
Installing Remote Focus Unit	322
Installing MIDI	323
Installing console lights	323
	324
Vviring remote macros	325
	020 026
Upgrading remote interface devices	020 026
	20

Appendix B

References	329
Remote Interface devices	329
Installing jumpers	329
Remote Interface Unit (RIU)	329
Remote Video Interface (RVI)	331
Installing remote video monitors	333
Using thinnet with older consoles	334
Network wiring	334
RIU jumpers	334
RVI DIP switch settings	334

Appendix C

messages	335
Diskette error messages	335
Other error messages	335
TCLink errors	336
Fatal messages	336
Secondary Messages	337
	messages

Appendix D	
Showtile	339 339
Configuration settings Read show results Read system configuration results	340 340 340
Appendix E Softkeys	341
Appendix F Time and location United States cities Cities outside the United States	349 349 350
Appendix G Specifications	351
Appendix H Declaration of Conformity	357
Appendix I Limited Warranty	359
Index	363

Chapter 1 Introduction

This manual covers the installation and operation of lighting systems containing ETC's Express 24/48, Express 48/96 and Express 72/144 control consoles operating with version 3.1 system software. The differences between these consoles is shown under *Appendix G Specifications, page 351*. Throughout the manual, all three consoles are referred to as Express unless a distinction is necessary.

Chapter one includes information to orient you to the console and the manual. It includes the following sections:

- Using this manual
- Using Help
- Text conventions
- Navigation and visual feedback
- Output level conventions
- Moving light concepts and terms
- The Only command
- Using the trackpad
- Electronic backup maintenance
- Troubleshooting

Using this manual

This manual provides instructions for using the console's features and optional accessories.

Setting up the console

If you are setting up the system for the first time, see *Appendix A Installation, page 313*, and *Chapter 3 System settings, page 21*, for information about setting up your system. If the system is already in place, you may not need to refer to these chapters.

New users

If you are new to lighting systems or to ETC's consoles, read chapters 4 through 13 for instructions about patching conventional lights and moving light fixtures, setting levels and using cues, groups, and submasters. These are the building blocks for creating and running any show. Once you are comfortable with these functions, chapters 16 through 19 provide more advanced information on effects, subroutines, macros and link lists.

Keyboard Help

Help screens are available for all console keys, including softkeys and wheels. To display help screens, press [Help], then press any key on the console.

Text conventions

In this manual, console keys and softkeys are indicated by square brackets, such as [Enter] and [S1]. Messages appearing on a console display are printed in boldface, such as **Select channel**. References to other sections of the manual are printed in italics, such as *Chapter 1 Introduction*.

Navigation and visual feedback

Move through console menus and displays in the ways that work best for you. The console offers alternative navigational techniques and visual feedback that confirms your choices all along the way.

Note how navigation and feedback information is collected in the table below. Tables like this are used throughout this User Manual to help you use console displays. When alternative navigational techniques perform the same function, examples in the text illustrate the technique that many find the most convenient or efficient to use.

Navigation and Feedback - Console menus					
	7 8 9 4 6 6 1 2 3	[S]	^↓	4	±
Select a menu item	Х		Х		Х
Highlighted characters	Item selected				

In these Navigation and Feedback tables,

 $\frac{7 \circ 3}{4 \circ 4}$ represents the keypad,

[S] represents the softkeys,

represent the up and down keyboard arrows,

represent the right and left keyboard arrows, and

± represent the plus and minus keys.

Output level conventions

The console uses both a highest level, or pile-on, convention and a last action convention to determine levels for channels affected by more than one control. Channels may be defined to operate with either convention.

HTP channels

The behavior of a pile-on channel is defined by the Highest Takes Precedence (HTP) rule. The console reads all output levels it receives for an HTP channel and sets that channel to the highest of them. A channel controlled by a submaster always obeys the HTP rule, but the Blackout key, Grandmaster control and parked channels all have priority over levels set from the keypad.

For example, if an HTP channel is included in both a submaster and a cue that has played back and is in a fader, the console sets the channel at the higher of the two levels. Or, you may use the keypad to select that channel and set it to any level, regardless of the levels set either by the cue or the submaster.

HTP channels in the console are called "normal" channels.

LTP Channels

Channels may also be defined in the console to follow the Latest Takes Precedence (LTP) rule. An LTP channel obeys the latest command to set its level. When the command is to fade to a level, an LTP channel can fade either in a physical fader (in the foreground) or in a background fader. Each LTP channel has its own background fader.

An LTP channel fades in the foreground if its level moves to a new level in the next cue. When a channel is fading in the foreground and no change in that channel is commanded by the next cue, the fade continues in the background. A cue stops running in the background when the last of its channels stops fading in the background. Up to 600 cues may run in the background at once.

For example, consider three cues recorded for channels Chan 1, Chan 2 and Chan 3, all of which are set as LTP channels. The cues contain percentage levels for these three channels as follows:

	Chan 1	Chan 2	Chan 3
Cue 1	25	0	0
Cue 2	25	50	0
Cue 3	50	50	50

- When Cue 1 starts, channel Chan 1 starts fading to level 25 with Cue 1 timing.
- If Cue 2 starts before Cue 1 ends, channel Chan 1 continues fading in the background with Cue 1 timing and channel Chan 2 starts fading in the foreground to level 50 with Cue 2 timing.
- If Cue 3 starts before Cue 2 ends, channels Chan 1 and Chan 3 start fading in the foreground to level 50 with Cue 3 timing; channel Chan 2 continues fading in the background with Cue 2 timing.

Enabling LTP

You can set a channel's status to LTP or HTP as long as the channel is not used in Fixture Patch. If the channel is patched to a fixture, the personality controls the HTP/LTP status. All attributes (channels) are set to LTP by a personality except the intensity attribute. All channels not patched to a fixture default to HTP (considered "normal").

Set channels to HTP or LTP, either singly or in ranges, in the Channel Attributes display using the following procedures.

Keystrokes:

Action:

1.	Press [Setup] [1][1] [Enter].	Selects the channel attributes display
2.	Press [1] [Thru] [1][0] [Enter].	Specifies channels 1 through 10
3.	$Press [\rightarrow] [\rightarrow] [\rightarrow] [\rightarrow].$	Move to LTP field
4.	Press [1].	Sets channels to LTP

Working with LTP channels

Background overrides

Cues running in the background can be stopped, adjusted or otherwise controlled with background overrides.¹ There are five override options, as shown in the table below.

	Background	Override Operations							
1.	Clear Cue(s)	Clears cue levels.							
2.	Cancel Cue(s)	Stops the fade or effect.							
3.	Finish Cue(s)	Takes cue channels to their completed levels immediately.							
4.	Master Cue(s) on X-Wheel	Takes proportional control of cue levels immediately.							
5.	Alter Rate of Cue(s) on X-Wheel	Adjusts cue timing.							

Control background overrides as follows:

Keystrokes:

1.	Press [Stage] [S3], Background Overrides .	Selects the Background Overrides list
2.	Press [5] [Enter].ª	Specifies cue 5
3.	Press [#] [Enter].	Specifies the override operation you want performed

Action:

a. Press [0] in this step to apply an override operation to all cues.

^{1.} Identify which cue contains a particular channel from the About Channel display, covered under About Channel, page 60.

Effects

LTP channels may be used to preserve an effect in certain channels regardless of levels in the effect. Also, multiple effects can run simultaneously, and other looks can be provided concurrently with effects.

These features are available in the console when you use LTP channels. When an effect cue is sandwiched between two other cues, LTP channel levels in the effect cue are ignored when determining which control takes precedence. A cue that runs after an effect skips over the previous effect cue to determine what happens to levels. If there is a move in the current cue with respect to the same channel in the cue before the effect, the channel fades in the current cue and is "stolen" from the effect. If no move, the channel continues in the effect.

Blocking cue

A cue running in the background ends when its last fading channel has finished or a background override ends the cue prematurely. Sometimes, however, you would like to end a background cue prematurely.

The way to do that is to follow the background cue with a blocking cue. A blocking cue does to timing what an allfade cue does to level. As soon as an allfade cue is started, all unused channels are forced to zero. Similarly, when a blocking cue starts, all channels running in background cues are faded to completion in the blocking cue's timing. A blocking cue ends all background cues.

Aside from its initial effect on background cues, the blocking cue runs from that point on just like any other cue, including the possibility that it could be forced to the background itself by the next cue.

Moving light concepts and terms

Fixtures

Conventional lights, sometimes called fixtures, are single attribute devices whose intensity can be controlled by a console connected to a dimmer. In this User Manual, however, the term *fixture* is often used to refer to multi-attribute devices such as moving lights to distinguish them from conventional lights. The programming methods in this manual apply to any multi-attribute device controlled by DMX512 as to moving lights.

Fixture attributes

Every fixture has a set of attributes that you use to control it. For instance, a basic moving light might have only three attributes: intensity, pan and tilt. You control the fixture's brightness by adjusting the level of a DMX512 channel that controls a dimmer assigned to the fixture. Similarly, you control the fixture's horizontal and vertical movements by adjusting the levels of DMX512 channels assigned to the fixture's pan and tilt attributes. This simple fixture would require three channels to fully control it. Other, more complicated fixtures could have additional attributes such as color, focus or gobo, and each additional attribute would require an additional DMX512 channel to control it.

In contrast, a standard ellipsoidal spotlight needs only one DMX512 channel to fully control it, namely the one that controls the dimmer assigned to the spotlight. Only the spotlight's intensity can be controlled by changing the channel level. It has no other attributes.

Categories

Most attributes can be naturally categorized as affecting the beam, the image, the color or the position. All attributes are initially assigned to one of these four categories or to a fifth one called None. Beam attributes include Intensity, Zoom, Focus, Iris, and Frost. Image attributes include Gobo and F/X. Color attributes include Color, Cyan, Magenta, and Yellow. Position attributes include Pan and Tilt. You can customize the assignment of attributes to categories, including assigning an attribute to multiple categories and assigning as many attributes as you want to a single category.

Personalities

Every fixture has an electronic personality that describes how it can be controlled. The personality specifies the attributes for the fixture and the order in which these attributes are presented to DMX512 channels. Assigning a personality to a fixture makes channel patching quick and easy. All you need to do is define which console channels and DMX512 addresses are first—the personality directs the rest of the assignment.

Many personalities are included with the console software. Other personalities for leading moving light fixtures on the market are being developed by ETC. As additional personalities become available, these are made available to dealers and placed on the ETC website for downloading. Also available from dealers and at the website is a program called the **Expression Personality Editor** which enables you to create and edit fixture personalities on an IBM-compatible computer. For further information about these options, call your nearest ETC Technical Services office or visit the ETC website at www.etcconnect.com.

The Only command

Only is a particularly powerful console command. Use Only to restrict a selection while programming or creating a look on stage.

When working with fixtures

Use Only to restrict the selection of fixture attributes by category, such as when you are creating or modifying a cue, submaster, group or focus point. For example, press [S8], **Fixture**, [8] [S4], **Only**, [Position] to place the pan and tilt attributes on the trackpad.

When updating

Following is a list of things you can select when using Only after the Update command in Stage. If you make selections and change your mind, press [Channel] [0] to reselect all non-zero channels.

Channels	Example: Press [S4], Only , [Channel] [1] [Thru] [5].
Fixtures	Example: Press [S4], Only , [S8], Fixture , [1] [And] [2].
Fixture attributes	Example: Pressing [S8], Fixture, [1] [S4], Only , [S6], Attribute, [6] selects attribute 6 of fixture 1.
Fixture categories	Example: Pressing [S8], Fixture , [1] [S4], Only , [Beam] selects all attributes in the Beam cate- gory for fixture 1.
Cues	Example: Pressing [S4], Only , [Cue] [5] selects all channels in cue 5 (not for effect cues).
Submasters	Example: Pressing [S4], Only , [Sub] [6] selects all channels in submaster 6 (not for effect submasters).
Groups	Example: Pressing [S4], Only , [Group] [7] selects all channels in Group 7.
Focus Points	Example: Pressing [S4], Only , [Focus Point] [8] selects all channels in Focus Point 8.

When recalling channels

Use to restrict a selection from among the channels, fixtures and attributes on stage.

The use of Only after the Update command is illustrated with the following examples:

- Press [Group] [1] [S4], **Only**, [Channel] [5] [Thru] [1][0] to select channels in group 1 that lie in the range 5 through 10.
- Press [Group] [1] [S4], **Only**, [Cue] [6] to select channels in Group 1 that are also in cue 6.

Using the trackpad

Use the Express trackpad to set rates and levels. The trackpad operates in three modes, single mode, double mode, and XY mode, described below. You can also set the trackpad's sensitivity.

Single mode	Most of the time the trackpad is in single mode. If the console prompts you for a rate or a level, moving your finger up on the trackpad increases the rate or level. Moving it down decreases the rate or level.
Double mode	If you use the Link List function to link two or more channels and then select any linked channel, the trackpad automatically switches into double mode. In double mode the trackpad is divided into two regions, The left side controls channels in the X half of the link (colored gold on the display). The right side controls channels in the Y half of the link (colored yellow on the display). Move your finger up or down on either side to control channel levels in the corresponding link.
XY mode	If you use the Link List function to link two or more channels and set the link's position attribute for XY position, then select any linked channel with that attribute, the trackpad automatically switches into XY mode. In XY mode move your finger right or left on the trackpad to control channels in the X half of the link (colored gold on the display). Move your finger up or down to control channels in the Y half of the link (colored yellow on the display).

Trackpad notes:

- If you have channels selected from both kinds of link, the trackpad defaults to double mode.
- In double mode you may only set one side at a time.

Sensitivity

To the left of the trackpad you will find two buttons that control trackpad sensitivity. The top button has a rough texture. Press this to set the trackpad for low sensitivity. The lower button has a smooth texture. Press this to set the trackpad for high sensitivity. Use high sensitivity for precise level or rate adjustments. Use low sensitivity for faster, less precise adjustments.

Electronic backup maintenance

Information in console memory is preserved by an electronic backup system for approximately 28 days. Within the limits of this system, if power should fail or if you shut down and then re-power, all programmed elements should be the same as they were. For additional security, ETC recommends that you routinely save to diskette as you go along and before shutting down.

CAUTION: The electronic backup maintenance system must be recharged periodically to function as intended. You must have the processor on for at least seven hours every 28 days to maintain the necessary charge.

Troubleshooting

If you have problems using your console, please refer to this manual's index or to the console's Help² function for additional information.

If you do not find the answer in the manual, please call your local dealer or ETC Technical Services. Have the following information available before you call:

- Console model and serial number (located on back panel)
- Software version (displayed in the lower right corner of the Setup menu)
- Options installed
- Dimmer installation type
- Dimmer manufacturer

^{2.} See Keyboard Help, page 2.

Help from ETC Technical Services

If you are having difficulties, your most convenient resources are the references given in the index of this manual and the console Help system, which is explained under *Keyboard Help, page 2*. To search more widely, try the ETC website at www.etcconnect.com. If none of these resources are sufficient, contact ETC Techncial Services directly at one of the offices identified below. In some cases, calls outside normal business hours are answered electronically and forwarded to a service representative.

When calling for help, please have the following information handy:

- Console model and serial number
- System software version (shown in Setup menu)
- Dimmer manufacturer and installation type

Americas

ETC Americas Technical Services Department 3030 Laura Lane Middleton, WI 53562

800-775-4382 (608) 831-4116 service@etcconnect.com

Europe

ETC Europe Ltd. Technical Services Department 5 Victoria Industrial Estate Victoria Road, London W3 6UU England

+44 (0)20 8896 1000 service@etceurope.com

Asia

ETC Asia, Ltd. Technical Services Department Room 605-606 Tower III, Enterprise Square 9 Sheung Yuet Road Kowloon Bay, Kowloon, Hong Kong

(+852) 2799 1220 service@etcasia.com

Chapter 2 Monitor displays

Express operates with one color video monitor. This monitor provides information regarding your show, including a cue list, the current status of the console's two fader pairs and a variety of user selectable displays. These displays allow you to create and run shows and to configure your console and your lighting system.

If your system includes ETCNet, additional monitors may be installed at other locations, such as backstage or in the sound booth. These remote monitors show the same displays as the console's monitor. To install remote monitors, see *Installing remote video monitors, page 333*.

Chapter two includes descriptions of the following displays:

- Stage
- Blind
- Flexichannel
- Patch

Colors in displays

The colors in which channel numbers and output levels are displayed on screen provide information about the channels. The following list shows the meaning of colors in Stage and Blind displays.

Channel numbers/Standard patch

Gray	Unselected channel.
White	Channel not selected by Only function.
Yellow	Selected channel. Controlled by the level (Y) wheel.

Channel numbers/Fixture patch

Gray ba	r Surrounds all channels of one fixture.
Light gr	ay Low channels for 16-bit data types.
Gold	Channels linked through the link list or fixtures. ³
Yellow	Selected channels of selected fixtures. ³

Channel output levels

Channel level when it is being changed.
In Stage, a channel in yellow was set by a submaster.
In Stage, a channel in white was set by an effect. In
Blind, a channel in white was set by a submaster,
group, focus point or an allfade cue.
Channel was recorded into a multipart cue, but not in
the currently displayed part (Blind only).
In Stage, captured channels are in red. In Blind,
channels not recorded are in red.
Channel output level is changed from what it was in
the previous cue. In Blind only, channel output is
lower than it was in the previous cue.
Channel output level is the same as it was in the
previous cue (tracking).
In Blind only, channel output level is higher than it
was in the previous cue.

Changing pages

Channels are displayed on several pages in the Stage and Blind displays. Use [S4], **Previous Page**, and [S5], **Next Page**, to switch from page to page. Also, pressing [\leftarrow] takes you to the first page, pressing [\uparrow] takes you to the previous page (last page if currently on the first page), pressing [\downarrow] takes you to the next page, and pressing [\rightarrow] takes you to the final page.

^{3.} Only High channels for 16-bit data types.

Display features

Three of the console displays—Stage, Blind and Patch—share many features, such as a channel display area, command line and softkeys. This chapter's illustrations of these displays are all labeled with these common features, and the explanations are given directly below. If some common features differ slightly for a particular illustration, such as the profile assignment in Patch, that information and other unique information for the display is given with the illustration.

Display name

Identifies the display shown and the current time.

Keypad corner

Indicates how the console will interpret the next number entered from the keypad. For example, when the **Keypad corner** displays "Chan" the next number you press will be taken as a channel number. If you enter a range, such as with the [Thru], [And] or [Except] keys, each number is displayed in turn but only the last number in the range remains.

Channel area

Shows channels, their levels and focus point references, if any, in selected cues, submasters, groups or focus points. Below each channel number is its level, if set. Below each level is the reference to the focus point, if any, used to set the level.

Prompt area

Shows a prompt or information display related to your next or justcompleted action.

Attribute bar

Shows current settings for the selection, such as a cue, group or submaster.

Softkeys

Shows additional functions available by pressing console keys [S1] through [S8].

Stage

The Stage display shows you the current levels of all active channels. Up to 100 channels appear on the display at a time.

										l	Dis	ola	y n	an	ne					K	eyp	ad	со	rn	er
Global settings	Grand Sub P	dma: Page	ster e 1	^ 1 (00%						0:	Ste 3:59	nge 9 Pl	1						Co	aptu	Ct red	nan Cho	inne	els.
	001 16	02 75	03 05	04 25	05	006	07	08 FL	09	10	011 04	12 34	13 04	14 71	15	016	17	18 FL	19	20	021 04	22 34	23 04	24 71	25
Channel area	026	27	28 FL	29	30	031 04	32 34	33 04	34 71	35	036	37	38 FL	39	40	041	42	43	44	45	046	47	48 FL	49	50
urou	051	52	53	54	55	056	57	58	59	60	061	62	63	64	65	066	67	68 FL	69	70	071	72	73	74	75
	076	77	78	79	80	081	82	83	84	85	086	87	88	89	90	091	92	93	94	95	096	97	98	99	00
Prompt area		Select channel numbers																							
Fader Status	Fader 100%	^ A. C≀	/B (omp	Cue Let:	101 [₽] 10	1 F 00%	Fade	er (с/D с	leai	^		C) >10	ue/" 01	Type	≩ T	ime 5	Wo	ait T	L (Tin	Link Cue	Fol /	llou) Ro	ite
Attribute bar	Cue/ 101	/Tyj	pe XF	Tii 5	ne	Wait	t L	_in	k Fı	olle	ow R	ate	10	03			5				Lis	t	C		
Softkeys	1 Sne	eak		2 U	odat	te (3Bad Over	ok gr	rnd des	4	On I	y	5	To I	loω	6	Pa	rk -	7	Mo Sof'	one Ikey	8 5 F	- ixt	une	

Global settings

Current settings for Grandmaster, Blackout and submaster page.

Fader Status

Shows current status of both fader pairs, including which cues are running, their fade times, percentage of completion and follow time.

Cue / Time Code List

Normally, this displays a cue list, but it can be toggled to show a Time Code list. The Cue List shows all cues along with their attributes. The last cue that ran in the faders is highlighted in yellow, and the next cue in sequence is highlighted in white (can be changed from Stage mode, but not from Blind). The Time Code List is a comprehensive listing of all time code events in the show. See *Time Code, page 292*, for further information.

To toggle between the lists:

- 1. Press [Setup].
- 2. Choose 6 Option Settings from the Setup menu, then press [Enter].
- 3. Choose **7 Display Cue/Time Code List** from the Option Settings menu, then press [Enter].
- 4. Follow prompt to toggle the display.

Blind

The Blind display lets you work on cues, groups and submasters without affecting the look on stage. It looks exactly like the Stage display, pictured above, except some of the softkeys are different⁴ and it has Blind for the Display Name.

^{4.} See Appendix E Softkeys, page 341 for a complete tabulation of console softkeys.

Fader

Express has a special Fader display that allows you to isolate channels in the display according to whether they come from the A/B or C/D fader pairs. You may also separately display channels in background faders.

Enter the Fader display from the Stage display as follows:

- 1. Press [S7], More Softkeys, until Fader appears at softkey S4.
- 2. Press [S4], Fader.

Grand	dmas	ster	~ 1(00%						03	Fac 3:01	ler 1 PM	1									Fac	len.	3
001	02	03	04	05	006	07	08	09	10	011	12	13	14	15	016	17	18	19	20	021	22	23	24	25
026	27	28	29	30	031	32	33	34	35	036	37	38	39	40	041	42	43	44	45	046	47	48	49	50
051	52	53	54	55	056	57	58	59	60	061	62	63	64	65	066	67	68	69	70	071	72	73	74	75
076	77	78	79	80	081	82	83	84	85	086	87	88	89	90	091	92	93	94	95	096	97	98	99	00
	(1 =	= A/	′B R	Fade		2 =	C/I) Fo	Se l ider	leot N/ 3	fac = B	der Both	dis Fo	sp I o ider	iy °s, 4	4 =	Bac	skgr	our	id Cł	nanr	iels	5)	
Fader	^ A,	′B				Fade	er (C/D				Cu	ue/1	ſype	e Ti	ime	Wo	nit	L	.ink	Fol	llou	J Ro	ate
		Cle	ear					CI	lear	~														
Cuer 1	/Typ >	e KF	Tir 5	ne	Wai	† L	_inł	< Fo	ollo	ow Ro	ate	>	1						No	ot Re	ecor	-dec	ł	
1 Se Fac	leot den		2 Up	oda	te	3Bac Over	ok gr	nnd des	4	Only		5 F	011	ω	6	Par	rk -	7	Mo Soft	one Ikeys	8	Ret	turr	a l

Upon entering the Fader display, you are prompted to select a display from the four options listed below. You can re-select the display at any time by pressing [S1], **Select Fader**.

- 1. A/B Fader
- 2. C/D Fader
- 3. Both Faders
- 4. Background Channels

Flexichannel

When you enable Flexichannel,⁵ only channels used somewhere in the show will appear on the display screens, subject to the following rules:

- Flexichannel displays channels whose levels are set, whether recorded somewhere in the show or not.
- Flexichannel does not display channels whose attributes are changed unless their levels are also set.
- Flexichannel shows the channels for all fixtures patched in the show.
- Flexichannel shows all channels on link lists.
- Flexichannel shows focus point links, if applicable (see focus point links to the right of the levels in the illustration below).

By only displaying channels used in the show, you can reduce the amount of time you spend moving from page to page to find channels. All other screen elements are unchanged.

Grandmaster 100%		Stage			Chan
Sub Page 1		09:35 AM			
1:FL 01 13:FL 0 2:FL 01 14:FL 0 3:FL 01 15:FL 0 5:FL 01 15:FL 0 5:FL 01 17:FL 0 6:FL 01 18:FL 0 7:FL 01 19:FL 0 8:FL 01 21: 10:FL 01 22: 11:FL 01 23: 12:FL 01 24:	01 25; 01 26; 01 27; 01 28; 01 29; 01 30; 01 31; 01 32; 33; 33; 33; 35; 36;	37: 38: 41: 42: 44: 45: 46: 46: 46: 48:	49:::: 501::::::::::::::::::::::::::::::::	61:: 62:: 655:: 677:: 699:: 71: 72:	73: 74: 75: 77: 78: 79: 80: 81: 82: 82: 82: 82: 84:
	Sele	ect channel n	umbers		
Fader A/B <mark>Cue 103</mark> Complete 1002 1002	Fader C/D	Cue/	'Type Time	Wait	Link Follow Rate
100/1	Clear	>103	5		
Cue/Type Time Wai 103 XF 5	t Link Follo	ow Rate 103	5		
1 Sneak Update	Backgrnd 4 Dvernides	Only Fol	low Par	rk Sof	1ore 8 ?tkeys Fixture

Working with Flexichannel active differs from working without Flexichannel in only one respect, selecting channels. See *Selecting channels in Flexichannel mode, page 56* for more information.

Note: In Patch mode, channels are highlighted if they appear in the Flexichannel list; they are grayed out if they do not.

Updating Flexichannel

When channels that were used in a show are removed from the show, they remain in channel displays until Flexichannel is updated. Press [Setup] [1] [Enter] [S1], **Purge Flexi**, to update Flexichannel. This update follows the same rules for Flexichannel that are given above.

You also update Flexichannel displays when you load another show from diskette or when you cycle the console's power off and on.

^{5.} See Enable / disable Flexichannel, page 27, for information about enabling Flexichannel.

Patch

The Patch display allows you to create and modify your patch. Patch moving lights in Fixture Patch, covered under *Patching one fixture or a fixture range, page 69*.

						Disp	olay name	Keypad corner
						10	Patch):02 AM	Dim 5
Patch area	Chan 1 2 3	Dimmer 1 2 3	r/Prop 251 252 253	501 502 503	/Profi 751 752 753	le 1001 1002 1003		
	4	75 •	254	504	754	1004	——– Level assigned	ł
	6	°/4◄ 6	255	506	756	1005	Profile assigne	d
Prompt area	on	Sele press	ot dim AT to	mer nu assig	mbers, n a pr	then p oportio	press ENTER to assign to a on, or press PROFILE to as	a channel, sign a profile
Softkeys	1	2		3		4	5 6 7 Profile S	More 8 Show Softkeus Labels

Patch area

Lists channels in the first column, dimmers patched to channels in the second and subsequent columns, and the levels and/or profiles assigned to those dimmers. In Flexichannel mode, channels that are used are highlighted.

Profile assigned

Displays the profiles assigned to dimmers.

Level assigned

Shows the levels assigned to dimmers.

Chapter 3 System settings

System settings allow you to customize the console for the number of dimmers and channels in your system, set system modes and screen formats, and choose default settings for a variety of console functions. The following illustration shows default settings.

Chapter three includes the following sections:

- Setting number of dimmers
- Setting number of channels
- Setting default fade times
- Setting default Level
- Setting default fader clear times
- Setting default Sneak time
- Blackout key
- Selecting Flexichannel mode
- Master Type
- Set Channels / Submasters 1-to-1
- Record Lockout
- Bump keys
- Scene mode
- Setting the clock
- About Show

Setting the number of dimmers

Your console is set by default to provide 1,024 DMX512 outputs from its 2 DMX512 ports, where each port provides up to 512 DMX512 outputs. All DMX512 outputs are represented in the Patch display as dimmers. You may reduce the dimmer count to save clutter in the Patch display, but many prefer to leave the dimmer count at the default setting.

If you decide to reduce the dimmer count, you need to take into consideration a number of factors, including how many dimmers are actually in your system, whether you are doubling dimmers and whether you are patching moving lights. The following three rules can help you determine a comfortable dimmer count on a port-by-port basis to arrive at an optimal setting for your circumstances.

- 1. If the port is doubled, make allowance for the B-components of doubled dimmers that start at DMX512 address 257. ETC recommends that you use the full capacity when a port is doubled.
- 2. If a moving light is patched to a port, make allowance for all the channels in the fixture's personality even when no external dimmer is required. For instance, a Cyberlight contains its own dimmer and needs 20 channels to control all the fixture's attributes, so 20 DMX512 outputs are required. When one or more moving lights are patched to a port, you can either total the channels needed for all moving and conventional lights on that port, or you can play it safe and use the port's full capacity.
- 3. If the port is neither doubled nor used for moving lights, the port's dimmer count can be the actual number of dimmers connected to it.

Example: Suppose you have 96 dimmers connected to each of your 2 ports, with port 1 doubled and port 2 used for moving lights. An optimal dimmer setting would be unchanged from the default at 1,024 dimmers (512+512).

If you increase the number of dimmers, the additional dimmers are initially patched to channel zero. From there, you can assign them to the channel of your choice.

Follow these steps to set the dimmer count for your console:

- -

Key	ystrokes:	Action:
1.	Press [Setup].	Selects Setup display
2.	Select [1], System Settings, and press [Enter].	Selects System Settings menu
3.	Select [1], Number of Dimmers , and press [Enter].	Prompt reads: Select number of dimmers, then press ENTER (Note: Fixtures require one dimmer for every control channel)
4.	Press [8][0][0] to enter the desired number of dimmers.	Corner reads: Dim 800
5.	Press [Enter].	Number of dimmers is set to 800
Setting the number of channels

You may find that in some circumstances you don't need all the channels available in your console. The system default is the maximum number of channels the console can address. By reducing the channel count below this maximum, you can significantly reduce processing time and free console memory for other purposes.

If you plan to reduce the number of channels, note that when patching fixtures you need one channel for every attribute in a fixture's personality (two channels for each 16-bit attribute). For example, a fixture's personality might require the assignment of 20 channels for the mix of attributes and data types used by that fixture. If you patched five of those fixtures, your console would need to provide 100 channels.

Follow these steps to set the channel count for your console:

Keystrokes:		Action:
1.	Press [Setup].	Selects Setup display
2.	Select [1], System Settings , and press [Enter].	Selects System Settings menu
3.	Select [2], Number of Channels , and press [Enter].	Prompt reads: Select number of channels, then press ENTER Note: Fixtures require one channel for every control output)
4.	Press [1][0][0] to enter the desired number of channels.	Corner reads: Chan 100
5.	Press [Enter].	Number of channels is set to 100

Setting default fade times

The console assumes default values for upfade and downfade times, but you can change them. Change all fade times at once by changing the default values, as explained below. You can also change fade times individually as explained under *Recording a cue with a single fade time, page 85*, and also under *Recording a cue with split fade times, page 86*.⁶

Fade times may be programmed from 0.1 seconds to 99:59 minutes. The number may be entered in normal time format or in decimal format. When entered with a decimal point, the number must be less than one minute (0.1 to 59.9 seconds) to be accepted. When entered without a decimal point, a 2-digit number will be treated as seconds if less than 60 and as a calculated value of minutes and seconds if between 60 and 99. For example, if you enter 70, the time will display as 1:10. If you enter either a 3-digit or a 4-digit number, the last two digits, up to 59, are interpreted as seconds. For example, if you enter 9930, the time will display as 99:30.

Follow these steps to assign new default fade times.

Keystrokes:		Action:
1.	Press [Setup].	Selects Setup display
2.	Select [1], System Settings , and press [Enter].	Selects System Settings menu
3.	Select [3], Default Fade Time , and press [Enter].	Prompt reads: Enter default up fadetime
4.	Press [6] to enter a six second upfade time.	Corner reads: UpTime 6
5.	Press [Enter].	Prompt reads: Enter default down fadetime
6.	Press [3] to enter a three second downfade time. ^a	Corner reads: DnTime 3
7.	Press [Enter].	Fade times are reset

a. If you want the upfade and downfade times to be the same, skip steps 6 and 7. The downfade would take whatever value you assigned to the upfade time in step 4.

^{6.} The factory-set default fade time is five seconds.

Setting default Level key

The console allows you to assign a value to the [Level] key. The default value is 100 percent. You may assign [Level] any value between zero and 100.

Follow these steps to assign a value to [Level]:

Keystrokes:		Action:
1.	Press [Setup].	Selects Setup display
2.	Select [1], System Settings , and press [Enter].	Selects System Settings menu
3.	Select [4], Default Level , and press [Enter].	Prompt reads: Enter default level (Press FULL button for 100%)
4.	Use the keypad to enter the two-digit number (00-99).ª	New default for [Level] is set

a. To enter a level between one and nine percent, you must precede the number with a zero. You may also press [Level] or [Full] for the assignment.

Setting default fader clear time

The default fader clear time determines the fade time for both [Clear] keys. Pressing the [Clear] key above one of the fader pairs clears the cue from the fader, fading all channels in that fader to zero. Channels black out immediately when clear time is zero.

Fader clear times can be programmed from 0.1 second to 99:59 minutes. See *Setting default fade times, page 24*, for information about entering the time value.

Follow these steps to set a new default fade time.⁷

Ke	ystrokes:	Action:
1.	Press [Setup].	Selects Setup display
2.	Select [1], System Settings , and press [Enter].	Selects System Settings menu
3.	Select [5], Default Fader Clear Time , and press [Enter].	Prompt reads: Enter default fader clear time
4.	Press [9] to enter the time value you wish to assign.	Corner reads: Time 9
5.	Press [Enter].	New default time is set to nine seconds

^{7.} The factory-set default fader clear time is zero seconds.

Setting default sneak time

The sneak function allows you to fade or restore channel levels on stage in a specified time.

The console allows you to assign a default Sneak time.⁸ For more information about the Sneak function, see *page 58*.

Follow these steps to set a new Sneak time:

Ke	ystrokes:	Action:
1.	Press [Setup].	Selects Setup display
2.	Select [1], System Settings, and press [Enter].	Selects System Settings menu
3.	Select [6], Default Sneak Time , and press [Enter].	Prompt reads: Enter default sneak time
4.	Enter the time you wish to assign as the Sneak time and press [Enter].	Sets the new default Sneak time

^{8.} The factory-set default sneak time is five seconds.

Enable / disable Blackout key

The console's [Blackout] key may be enabled or disabled. The default condition is enabled.

Follow these steps to enable or disable [Blackout]:

Keystrokes:	Action:
1. Press [Setup].	Selects Setup display
 Select [1], System Settings, and press [Enter]. 	Selects System Settings menu
 Select [8], Blackout Key, and press [Enter]. 	Prompt reads: Enable/disable blackout key (1 = Enable, 0 = Disable)
4. Press [1] or [0].	Corner reads: Black 1 Or Black 0
5. Press [Enter].	[Blackout] is enabled or disabled

Enable / disable Flexichannel

The console's Command display can be set to operate in full display mode or in Flexichannel mode. In full display mode, channel displays show all channels and their current status. In Flexichannel mode, only channels with a recorded level or that are on the Link List appear. The console defaults to full channel display.

Follow these steps to enable or disable Flexichannel:

Keystrokes:		Action:
1.	Press [Setup].	Selects Setup display
2.	Select [1], System Settings , and press [Enter].	Selects System Settings menu
3.	Select [9], Flexichannel , and press [Enter].	Prompt reads: Enable/disable flexichannel (1 = Enable, 0 = Disable)
4.	Press [1] or [0].	Corner reads: Flexi 1 Or Flexi 0
5.	Press [Enter].	Flexichannel mode is enabled or disabled

Set grandmaster type

You may set the Master slider to one of four control options.

- **Disabled** Master slider does nothing.
- Grandmaster Master slider controls all levels on stage except parked channels and independent channels.
 Sub Grandmaster Master slider controls all levels on stage set by submasters.
 Scenemaster Master slider controls all levels on stage
 - set by the channel sliders.

To configure your Grandmaster, follow these steps:

		Action:
1.	Press [Setup].	Displays Setup menu
2.	Press [1], System Settings , [Enter].	Displays System Settings menu
3.	Press [1][0], Master Type , [Enter].	Prompt reads: Select master type and press ENTER (0 = Disabled, 1 = Grandmaster, 2 = Sub Grandmaster, 3 = Scenemaster)
4.	Press [1] [Enter].	Master is set as Grandmaster

Set channels / submasters 1-to-1

Set Channels / Submasters 1-to-1 sets your console's channels to a oneto-one match with your submasters. Thus, channel 1 is patched to submaster 1, channel 2 to submaster 2, and so on. Channel levels are set to Full and up/dwell/down times are set to 0/Manual/0.

To reset your channels and submasters, follow these steps:

Key	ystrokes:	Action:	
1.	Press [Setup].	Displays Setup menu	
2.	Press [1], System Settings , [Enter].	Displays System Settings menu	
3.	Press [1][1], Set Channels/ Submasters 1-to-1, [Enter].	Prompt reads: Select page to default, then press ENTER (0 = All pages)	
4.	Press [Enter].	Channels are assigned to submasters. The display returns to Setup menu	

Record lockout

You may set the console to disable the Record function. This protects a finished show from inadvertent changes.⁹

To disable the Record function in your system, follow these steps:

Keystrokes:

Action:

Record Lockout

- Press [Setup].
 Press [1], System Settings, [Enter].
 Selects Setup display
 Selects System Settings menu. Menu indicates current status of
- Press [1][3], Record Prompt reads:
 Lockout, [Enter].
 Prompt reads:
 Enable/Disable record lockout (1 = Enable, 0 = Disable)
- 4. Press [1] to lock out the record function. Record is locked out. If you attempt to record anything, the prompt reads:

Record is locked out (Press CLEAR to continue)

Enable / disable bump buttons

The console's submaster bump buttons (also known as bump keys) may be enabled or disabled. The default condition is enabled.

Follow these steps to enable or disable all submaster bump buttons:

Keystrokes:		Action:
1.	Press [Setup].	Selects Setup display
2.	Select [1], System Settings , and press [Enter].	Selects System Settings menu
3.	Select [1][4], Bump keys , and press [Enter].	Prompt reads: Enable/disable bump keys (1 = Enable, 0 = Disable)
4.	Press [1] or [0].	Corner reads: BpStat 1 Or BpStat 0
5.	Press [Enter].	Submaster bump buttons are enabled or disabled

^{9.} As always, the best way to safeguard your show is to make backups. See Chapter 20 Diskette functions, page 243, for instructions on backing up a show to diskette.

Scene mode

The console's operating mode may be one scene or two scene. The default condition is one scene mode. See *Chapter 23 Two scene preset*, *page 257*, for information about setting the scene mode.

Follow these steps to put the console in the desired operating mode.

Keystrokes:

Action:

1.	Press [Setup] [1] [Enter].	Selects System Settings menu
2.	Press [15] [Enter]. ^a	Prompt reads:* Select scene mode, then press ENTER (0 = One scene, 1 = Two scene)
3.	Press [1] [Enter].	Two scene mode is enabled

a. If your console is an Express 24/48, the prompt that appears at step 2 reads Select scene mode, then press ENTER (1 = Two scene, 2 = One scene without subs, 3 = One scene with subs). Selection 3 sets the bottom row of sliders to submasters rather than channel sliders when you are in the one scene mode.

Setting the clock

The console clock is called a real time clock because it is set with respect to the true time for your location, not a relative time such as would exist for a time code signal. The console's real time clock also functions as an astronomical clock, which means that you can set it for the latitude, longitude and time zone at your location and thereby control real time programs with respect to sunrise or sunset. Astronomical data for many cities in the world is given in *Appendix F Time and location, page 349*.¹⁰

Clock functions display

Before running real time programs you must set the clock. The six options available to set the clock are shown in the Clock Functions display. Go to the Clock Functions display as follows.

Keystrokes:

Action:

1. Press [Setup].

Selects Setup display Selects Clock Functions menu

2. Press [1][4] [Enter].



Set the clock functions using one or more of the procedures below.

^{10.} See Setting the clock, page 31, to set the Real Time Clock.

Daylight Savings Time

Keystrokes:

Action:

- Press [1] [Enter].
 Prompt reads: Select Daylight Savings Time (1 = daylight time, 0 = standard time)
 Press [1] [Enter].
 Enables Daylight Savings Time.^a
 - a. The clock does not automatically adjust for changes between daylight and standard times. These must be re-set manually.

Set time/date

In the following procedure, press [Enter] to scroll through the fields on the screen.

Action:

Keystrokes:

Press [2] [Enter].

Prompt reads: Enter current standard time (12 hour clock). (To start clock, press [Record] - to cancel, press [Clear]

- Enter the current time in hours and minutes. (In 24- hour format, 930 = 9:30 AM, 1625 = 4:25 PM) (In 12-hour format, use [+] to select AM or PM. Press [Enter].
- Enter the day of the month (1-31). Press [Enter].
- Enter the month (1-12). Press [Enter].
- Enter the year (00-99). Press [Enter].
- Enter the day of the week (1= Monday thru 7= Sunday). Press [Enter].
- Press [Record] to reset Real Time Clock with the new settings.

Action:

12/24 hour clock

Keystrokes:

1. Press [3] [Enter]. Prompt reads: Enter 12 or 24 hour clock (0 = 12 hour, 1 = 24 hour)

2. Press [0] [Enter]. Sets 12 hour clock.

Latitude, longitude, time zone

Choose the latitude, longitude and time reference data from **Appendix E** for the city closest to you. The example below is for Middleton, Wisconsin at 43° 04′ N latitude, 89° 23′ W longitude and 6 time zones west of Greenwich, England.

Keystrokes:

Action:

1.	Press [4] [Enter].	Prompt reads: Enter latitude in degrees, then press + for North, or press – for South
2.	Press [4][3][+] [Enter]. ^a	Enters 43 degrees North Prompt reads: Enter minutes of latitude
3.	Press [0][4][Enter].	Enters 4 minutes.
4.	Press [5] [Enter].	Prompt reads: Enter longitude in degrees, then press + for West, or press – for East
5.	Press [8][9][+] [Enter].	Enters 89 degrees West. Prompt reads: Enter minutes of longitude
6.	Press [2][3][Enter].	Enters 23 minutes.
7.	Press [6] [Enter].	Prompt reads: Enter time offset from Greenwich Mean Time in hours/minutes, then press + for West, or press – for East
8.	Press [6][0][0][+] [Enter]. ^b	Enters 6 hours West.

- a. The + used in this step and the others in this procedure may be optional. Latitude defaults to North, longitude defaults to West and time zone defaults to West.
- b. Three digits are used for time zones to allow for fractional zones.

About Show

About Show provides you with information about the currently loaded show. It tells you how many channels and dimmers your show is configured for and your utilization of recordable entities such as cues, submasters, groups, focus points, macros and time code events. This is important because not enough memory is available to store the maximum number of all recordable entities at the same time.

Use About Show to monitor your memory usage as the complexity of your show increases. If you fill the available memory, reclaim some of it by clearing recorded entities that you are no longer using, for example by reducing how many channels and dimmers are patched.

Г		—About: Sho	ω=====	
	Label: MyShow			
	Number of channe Number of dimmer	els: 240 ~s: 1024		
	Re Cues: Subs: Groups: Focus Points: Macros: Time Code: System setup:	ecorded % 4 3/3 3 2 0 0 -	Memory 1% 1% 0% 0% 0% 34%	Remaining 596 21/237 497 97 2000 3000 -
		Memory left:	64%	

Press [About] [Enter] to go to the **About Show** display.

- Label
- Number of channels
- Number of dimmers
- Recorded
- % Memory
- Remaining
- System setup

Memory left

Your show's name. The show may be named with Expression Off-Line. See *Expression Off-Line, page 312*.

- Shows the value set in the System Settings menu. See *Setting the number of channels, page 23*.
- Shows the value set in the System Settings menu. See *Setting the number* of dimmers, page 22.

Shows how many of each item in the first column that have been recorded.

Shows what percentage of console memory is consumed for each item in the Recorded column.

Shows how many more of each item in the first column may be recorded before reaching the console maximum.

Shows how much console memory is used for your setup and configuration settings.

Shows what percentage of console memory is remaining for your show.

Chapter 4 Patching channels

Before you begin creating cues for a show you should first create your patch. The patch assigns individual dimmers to control channel numbers. The console's Patch display allows you to assign any of the dimmers available to any of the control channels your console can address.

You can use the console's default one-to-one patch, or you may create a custom patch. In addition, the console's proportional patching capability allows you to set dimmer output levels and assign one of 33 output profiles to dimmers.

If you are patching dimmers in a Strand CD80 dimmer rack, see *page 49* for special instructions.

Before patching, make certain that your dimmer and channel settings are the way you want them. See *Setting the number of dimmers, page 22*, and *Setting the number of channels, page 23*, for information on setting the dimmer and channel counts. Setting these counts configures the Patch display for your specific needs and, when channel count is reduced, reduces memory utilization and speeds processing.

Chapter four includes the following sections:

- Selecting one-to-one patch
- Creating custom patch
- Proportional patching
- Labeling dimmers
- Assigning a profile to a dimmer
- Capturing channels in patch
- Dimmer check
- About Dimmer
- Setting dimmers to dimmer doubling
- Patching to a Strand CD80 dimmer rack

Selecting one-to-one patch

The one-to-one patch assigns dimmer 1 to channel 1, dimmer 2 to channel 2 and so on. If there are more dimmers than channels, the one-to-one patch assigns the first extra dimmer to channel 1, the second extra dimmer to channel 2, and so on.

NOTE: Selecting the one-to-one patch unpatches all moving light fixtures.

Follow these steps to select the console's default one-to-one patch.

Keystrokes:

Action:

- 1. Press [Setup] to display Selects Setup display the Setup menu.
- 2. Press [4], Clear Functions [Enter]. Prompt reads: Select function number, then press ENTER
- Press [9], Reset Patch
 1 to 1 [Enter].
 Prompt reads:
 To reset patch, press ENTER
 To cancel, press CLEAR
- Press [Enter] to confirm your selection of one-toone default patch, or press [Clear] to cancel the operation.
 Sets patch to default one-toone patch

Creating a custom patch

The console's custom patching capability allows you to create virtually any dimmer to channel configuration you like. (Groups of dimmers may be assigned to single channels, but only one channel may be patched to a dimmer.)

Hint: If you use the same patch for several shows, create the patch, and record it on a disk before you record any cues. Label the disk **Standard patch**. When you start your next show, read the Standard patch show into the console, then begin writing cues to avoid reentering the patch.

Follow these steps to patch dimmers to control channels.

Ke	ystrokes:	Action:
1.	Press [Patch].	Selects Patch display
2.	Press [Dim]. (If the LED in the [Dim] key is lit, you may omit this step.)	
3.	Use the keypad to enter the numbers of the dimmers you want to patch. Use [And], [Thru] or [Except] for multiple selections. ^a	Prompt reads: Select dimmer numbers, then press ENTER to assign to a channel, or press AT to assign a proportion, or press PROFILE to assign a profile
4.	Press [Enter] or [Channel].	Prompt reads: To assign dimmers, select channel number, then press ENTER To delete dimmers, press UNPATCH
5.	Enter the channel number to which you want to patch the selected dimmers and press [Enter].	Dimmer(s) are patched to the channel
6.	Repeat steps 2 through 4 to patch additional dimmers.	

a. For a dimmer set to Dimmer Double, press [S2], **A**, or [S3], **B**, after entering the dimmer number. If you select a doubled dimmer without specifying A or B, the selection defaults to A.

Proportional patching

Normally, dimmers output with a linear profile at 100 percent unless you scale them to a lower level.¹¹ The console allows you to proportionally scale the output of an individual dimmer in the Patch display.¹² For example, if you enter a dimmer proportional level of 60 in Patch and set that channel to full in a cue or submaster, the dimmer will output at 60 percent.

Follow these steps to assign a proportional dimmer output level:¹³

Keystrokes:

Action:

- 1. Press [Patch].Selects Patch display
- If the [Dim] LED is unlit, press [Dim] to indicate that the next number entered will be a dimmer.
 Prompt reads: Select dimmer numbers, then press ENTER to assign to a channel, or press AT to assign a proportion, or press PROFILE to assign a profile
- Use the keypad to enter the desired dimmer number(s). Use [And], [Thru] or [Except] for multiple selections.^a
- 4. Press [At] Prompt reads: Select dimmer proportion
- Use the keypad to enter the desired maximum output level for the dimmer(s). Full is displayed until a new level is entered. Enter a zero before singledigit levels (i.e., **08**).
 - a. If a dimmer is doubled (see Setting dimmers to Dimmer Doubling, page 48, for an explanation) Use [S2], A, and [S3], B, along with the numeric keypad, to enter dimmer numbers as you create your patch. If you select a doubled dimmer without specifying A or B, the system defaults to A.

^{11.} See Dimmer profiles, page 40, to alter a dimmer's profile. The profile takes effect after the dimmer proportion, if any, is first applied.

^{12.} Available only for 8-bit channels—applying dimmer scaling to 16-bit channels will yield unexpected results.

^{13.} Note: If the dimmer's level is highlighted (white on red), you may use [+] and [–] to adjust the level. Press [Enter] to record the edited level.

Unpatching individual dimmers

When you unpatch dimmers, they are assigned to channel zero. Channel zero functions as a holding area in which you may store dimmers not included in your patch. It is not an actual control channel.

Before you begin creating a custom patch, you may find it helpful to assign all dimmers to channel zero. Then when you begin patching, you can select dimmers from channel zero and patch them to channels as you like.

Dimmers assigned to channel zero are listed at the end of the channel list in the Patch display as "--." These dimmers are not assigned to any channel but remain on the patch screen.

Follow these steps to assign dimmers to channel zero.

Keystrokes:

Action:

assign a profile

- Press [Patch].
 Selects Patch display
 If the [Dim] LED is unlit, press [Dim] to indicate that the next number entered will be a dimmer.
 Selects Patch display
 Prompt reads: Select dimmer numbers, then press ENTER to assign to a channel, or press AT to assign a level, or press PROFILE to
- Use the keypad to enter the desired dimmer number(s) Use [And], [Thru] or [Except] for multiple selections.
- 4. Press [S6], **Unpatch.**

Selected dimmers are unpatched and assigned to channel zero (- -)

Show labels

Express allows you to show or hide labels assigned to dimmers.¹⁴ Hiding labels provides additional space in the Patch display to show additional dimmers. In the Patch display, press [S8], **Show/Hide Labels**, to toggle between these two conditions.

^{14.} Labeling for Express can be done in Expression Off-Line. See Expression Off-Line, page 312.

Dimmer profiles

A dimmer profile is a variable level sent to a dimmer during a fade that is related in some way to the percentage of fade completion. By varying the dimmer profile, you can compensate for nonlinear characteristics or other time-dependent variations in lighting instruments as well as warm filaments more slowly to increase lamp life. Dimmer profiles are not available for 16-bit channels, only for 8-bit channels.

A dimmer may have both a proportional level assigned to it as well as a dimmer profile.¹⁵ In the control sequence for a particular channel, the channel's level is first modified by the dimmer scaling, if different from 100%. Then the resulting dimmer level is modified during the channel's fade by the dimmer profile, if different from a linear profile, to yield the dimmer's final output.

The console has 33 dimmer profiles, of which 32 are editable. Profile 0, the default profile, is a linear profile¹⁶ and is not editable. Profiles 1 through 9 have preset, nonlinear profiles and are all editable. Profiles 10 through 32 default to linear profiles and are all editable.

Pre-defined profiles

- 0 Linear (not editable)
- 1 IES square
- 2 Slow bottom
- 3 Fast bottom
- 4 Slow top
- 5 Fast top
- 6 Full at 1%
- 7 Preheat at 5%
- 8 Preheat at 10%
- 9 Hot patch

^{15.} See Proportional patching, page 38, for information about how to make the dimmer output proportional to a scaling factor.

^{16.} A linear profile is one that has an intensity level directly proportional to the fade time at all points in the fade time. Thus, when the fade is 50% complete, the intensity level is 50% of the full value.

Assigning a profile to a dimmer

You may assign one of the 32 alternative profiles to a dimmer. If you assign none, the console sets the dimmer to default profile 0, the uneditable linear profile. Following is the procedure for assigning a profile to a dimmer.¹⁷

Ке	ystrokes:	Action:		
1.	Press [Patch]. ^a	Prompt reads: Select dimmer numbers, then press [Enter] to assign to a channel, or press [At] to assign a proportion, or press Profile to assign a profile		
2.	Enter the number of the dimmer to assign on the keypad.			
3.	Press [S7], More Softkeys , [S6], Profile.	Prompt reads: Select dimmer profile number		
4.	Enter the number of the desired profile.			

- 5. Press [Enter].
 - a. Press [Dim] if the dimmer LED is not lit.

Profiles display

Press [Setup] [1][0], Profiles, [Enter] to go to the Profiles display.



The Profiles display contains a bar chart, with the total time for completion of the fade broken down into 40 equally spaced bars. The height of each bar represents the percentage of the full fade level defined as intensity. Twenty of these bars are editable for intensity and are called fade points. In between the 20 editable fade points are the remaining 20 bars, and these indicate the calculated intensity levels between fade points.

^{17.} See Proportional patching, page 38, if you want to use this procedure to assign a proportional level to the dimmer.

Also, the Profiles display contains the following information:

- The profile's number and name (if labeled see **Labeling Profiles** below).
- For each fade point, the percent of the fade complete at that point. Each fade point contributes 5% to the total fade.
- For each fade point, the intensity at that point.

Navigation and Feedback - Profiles display					
	7 8 9 4 5 6 1 2 3	[S]	^↓	44	±
Select a fade point	Х	Х		Х	
Change the intensity	х		Х		Х
Yellow numbers	Fade point percentage and intensity values				
Yellow bar	Fade percent point selected				

Note: Use [At] to set the level with the keyboard or use [At] [+] or [At] [–] to bump the level by one.

Creating or editing a profile

If you need a profile that is different from any of the ten provided, you can either edit one of those that already exists (but not default profile 0) or create a new one. As you edit, the profile changes to display the results.

Edit intensities in the Profiles display as follows:

Ke	ystrokes:	Action:		
1.	Press [S1], Profile , [1][2] [Enter].	Selects profile 12 Prompt reads: Select percentage, then press [At] to select level (Or, use right/left arrows for percentage, up/down arrows for level)		
2.	Press [S2], Percent , and enter a fade point number.	Selects a fade point		
3.	Enter a new intensity on the keypad.	Selects an intensity for the face point		
Λ	Proce [Entor] if finished or			

4. Press [Enter] if finished or go back to step 2.

Copying to another profile

One convenient way to create a new profile is to copy one of the existing ones to a new profile number and edit the new one. Use softkey [S6], **Copy to Profile**, in the Profile display to copy a profile.

Clear All

For a selected profile, Clear All changes the intensity of all fade points to undefined. $^{18}\,$

Clear to End

For a selected profile, the Clear to End command sets as undefined the intensity of all those fade points above the selected one. $^{18}\,$

Fill Between

When intensities in a profile are undefined, such as when you use Clear All or Clear To End, you can use Fill Between to have them automatically filled in with a linear profile. For Fill Between to work, you must have defined intensities on both sides of an undefined range (zero intensity is a defined value). Here is how Fill Between can be used to fill in undefined intensities throughout a particular range.

Keystrokes

Action

1.	Press [S1], Profile , [1][5]	Selects profile 15.
2.	Press [S2], Percent , [5][0]	Selects the 50% fade point.
3.	Press [S4], Clear to End , [Enter]	Changes all fade points above 50% to undefined.
4.	Press [S2], Percent , [7][5]	Selects the 75% fade point.
5.	Press [At] [1][0]	Sets the 75% fade point to intensity 10
6.	Press [S5], Fill Between , [Enter]	Fills between the 50% and 75% fade points with a straight line. Fade points above 75% are unaffected.
7.	Finish profile to end.	Set inattentiveness of fade points between 75% and 100%

Resetting a profile

Press [S7], **Reset**, eliminates all editing performed on a selected profile.¹⁹ When profiles 1-9 are reset, the original relationships shown under *Pre-defined profiles, page 40*, are restored. When profiles 10 through 32 are reset, they return to linear relationships.

^{18.} Undefined intensities are marked ** on the Intensity line.

^{19.} You may reset all profiles at once by selecting Clear Profiles from the Clear Functions menu.

Captured channels in Patch

The console lets you select and capture channels without returning to Stage mode. This allows you to bring channels up on stage to view the proportional settings of dimmers assigned to a channel while you set them.

To select channels from the patch screen, follow these steps:

Keystrokes:

1. Press [Patch].

Action:

Selects Patch display

Prompt reads:

- 2. Press [Channel]. Prompt reads: Select channel numbers
- 3. Use the keypad to enter the desired channel number(s) Use [And] and [Thru] if you want to select more than one channel.
- Selected channels are set at the indicated level

Select channel numbers

- Press [Full] to set channel level at 100 percent, [Level] to set channel at the default level, or press [At] and enter a level setting.
- 5. Press [Rel] to release channel(s).

Dimmer check

The console's dimmer check allows you to raise unparked dimmers to a specified level on stage, one at a time.²⁰ Select the starting dimmer, set it at a level and then use [+] to check consecutive dimmers. You may do a dimmer check in any display except Patch and Park.

Perform a dimmer check with the following procedure.

Keystrokes:

Actions:

1.	Press [Dim].	Prompt reads: Enter dimmer number(s), then press AT to select level
2.	Press [1] to start dimmer check with dimmer 1.	Keypad corner reads: Dim 1
3.	Press [At].	Prompt reads: Select dimmer level (Press FULL button for 100%)
4.	Press [7][5] to set the dimmer's level at 75 percent. You may also press [Full] or [Level] to set the dimmer at 100 percent or at the [Level] setting.	Prompt reads: To unpatch dimmer for dimmer check, press ENTER
5.	Press [Enter].	Dimmer 1 is set at 75 percent Dimmer Check window appears Prompt reads: Press [+] or [–] to step through

 Press [+] to select dimmer
 Repeat as necessary.
 Press [Clear] to end dimmer check.^a
 Dimmer 1 returns to zero, dimmer 2 is set at 75 percent

dimmer check.

dimmers. Press [Clear] to cancel

a. If the dimmer is doubled, the dimmer check is performed on dimmer A of the doubled dimmer first. Pressing [+] moves to dimmer B of the doubled dimmer.

^{20.} If a dimmer is parked, the Dimmer Check window displays a "Parked" message and shows the level at which it is parked. The Dimmer Check does not change a parked dimmer's level on stage.

About Dimmer

The About Dimmer display tells you about the characteristics, patch and use of individual dimmers. For the contents of the About Dimmer display when using ETCLink, see *About Dimmer with ETCLink, page 47*. For similar information about channels, see *About Channel, page 60*.

Go to the About Dimmer display as follows.²¹

Keystrokes:Action:1. Press [About] [Dim].Prompt reads:
About: Select dimmer number, then
press ENTER2. Press [3].Keypad corner reads:
Dim 3

3. Press [Enter].

About Dimmer window is displayed



^{21.} Press [Clear] to remove the About window.

^{22.} You can assign labels in Expression Off-Line. See Expression Off-Line, page 312.

About Dimmer with ETCLink

If your console uses ETCLink to monitor dimmers in an ETC Sensor dimming system, the About Dimmer window displays additional dimmer monitoring information. The following expanded About Dimmer window appears if dimmer monitoring is enabled.

About:	Dimmer 3	
Label: Proportion: 100 Console dimmer level: 35 DMX512 Port: 1/3	Channel: 3 Profile: 0 Linear Parked: n	
Rack/slot number: 1/2 Rack dimmer level: 35 Dimmer level source: DMX A	Recorded lamp load: 950W Load at full: 950W Actual load: 450W Scale/Boost:	
Dimmer errors: None		

- Label:
 - Channel:

Profile:

Parked

DMX512 Port

Load at full:

The dimmer's label, if any.²²

The channel to which the dimmer is assigned.

Proportion: The dimmer's assigned proportional level.

The dimmer profile's number and name, if assigned. $^{\rm 22}$

- **Console dimmer level**: The dimmer output level the console is sending to the dimmer.
 - Whether or not the dimmer is parked.
 - Port number / address on the port.
- **Rack/Slot number**: The rack and slot in which this dimmer is located.
- **Rack dimmer level**: The actual output level at which the dimmer is set.
- **Dimmer level source**: The source of the control signal which set the dimmer's level. Possible sources

include: DMX A DMX B Rack #

The following information is available on Sensor Advanced Features dimming systems.

- **Recorded lamp load**: The load at which the selected dimmer was recorded.
 - The estimated load on the dimmer when the level is at Full.
 - Actual load: The actual load currently on the dimmer.
- Scale/Boost: The dimmer's scale or boost level. Scale is reported in volts (V) and Boost is reported in percentage (%).
- **Dimmer errors**: Describes errors, if any.

Setting dimmers to Dimmer Doubling

ETC's Dimmer Doubling technology can increase the controllable circuits of a 115 volt, 60 Hz dimming system.²³ Dimmer Doubling converts the output of a single ETC Sensor or L86 dimmer into two separate signals. Both signals then provide discrete levels for two ETC Source Four lights.²⁴

You must configure the console by setting the mode of the dimmer and the dimmer's port before the dimmer will function in Dimmer Doubling mode. Each dimmer and port is set individually. Before patching, set the port mode with the procedure given under *Setting the port to Dimmer Doubling, page 320*.

When a dimmer is doubled, it is functionally split into two dimmers that are distinguished by A and B. For example, dimmer 1 becomes dimmer 1A and dimmer 1B. For each doubled port, the A components of each dimmer are controlled by DMX512 outputs 1-256 and the B components of each dimmer are controlled by DMX512 outputs 257-512. The console represents doubled dimmers in the Patch display as dimmers in the range 1-256, parts A and B.

If a channel was patched to the dimmer before it was doubled, the channel is assigned to both the A and B parts, thus keeping the number of controlled circuits the same rather than doubled. To assign the doubled parts of a dimmer independently, see *Creating a custom patch, page 37*.

Set dimmers to doubled with the procedure below.

Keystrokes:		Action:	
1.	Press [Patch].	Selects Patch display	
2.	Press [Dim] [1][8] [Thru] [3][5]. ^a	Selects dimmers 18 through 35 Prompt reads: Select dimmer numbers, then press ENTER to assign to a channel, or press AT to assign a proportion, or press PROFILE to assign a profile	
3.	Press [S1], Dimmer Double.	Sets selected dimmers to doubled mode	

a. Often there is no need to press [Dim] in this step because the Patch display defaults on entry to dimmer input.

^{23.} Dimmer Doubling is available only for ETC dimming systems operating nominally at 115 volts, 60 Hz. It is not available for systems operating at other voltages or frequencies.

^{24.} The Source Four lights should be running 77V HPL lamps when operated by a doubled dimmer.

Patching to a Strand CD80 dimmer rack

Strand CD80 dimmer racks have 48 dimmer slots. Each dimmer slot holds either two 2.4kW dimmers or one 6kW or 12kW dimmer. The console requires that you include all 96 possible dimmer numbers per rack in the patch.

Refer to the charts below to determine dimmer numbers for each slot on each rack. When patching 6kW or 12kW dimmers, enter the slot's odd dimmer number under the desired channel number. Enter the slot's even dimmer number under channel zero.

For example, to patch a 6kW dimmer into the last dimmer slot on the first rack, enter dimmer 95 in the desired channel number and dimmer 96 in channel zero.

1	3	5	7	9	11	
2	4	6	8	10	12	
13	15	17	19	21	23	
14	16	18	20	22	24	
25	27	29	31	33	35	
26	28	30	32	34	36	
37	39	41	43	45	47	
38	40	42	44	46	48	
49	51	53	55	57	59	
50	52	54	56	58	60	
61	63	65	67	69	71	
62	64	66	68	70	72	
73	75	77	79	81	83	
74	76	78	80	82	84	
85	87	89	91	93	95	
86	88	90	92	94	96	

97	99	101	103	105	107
98	100	102	104	106	108
109	111	113	115	117	119
110	112	114	116	118	120
121	123	125	127	129	131
122	124	126	128	130	132
133	135	137	139	141	143
134	136	138	140	142	144
145	147	149	151	153	155
146	148	150	152	154	156
157	159	161	163	165	167
158	160	162	164	166	168
169	171	173	175	177	179
170	172	174	176	178	180
181	183	185	187	189	191
182	184	186	188	190	192

Chapter 5 Setting channel levels

Setting channel levels is the first step in recording cues, submasters and groups. Setting channel levels in Stage mode brings light levels up on stage. Setting channel levels in Blind mode does not affect stage lights.

This chapter includes the following sections:

- Channel modes
- Channel attributes
- Selecting channels
- Setting channel levels
- Channel check
- About Channel

Channel modes

The color and behavior of channels depends upon their modes.

Selected channels

Selected channels are channels over which you have immediate control with the keypad or level wheel. Their channel numbers are displayed in yellow and their levels displayed in red. You can select channels in all display modes. Press [Rel] once to release selected channels.

Captured channels

Captured channels have levels set in the Stage or Fader displays by any source except faded cues or submasters and take precedence over levels set by faded cues or submasters. For example, if you capture a channel at 50 that was faded to 100 percent, you set it to 50 percent. When one or more channels are captured, the message "Captured Channels" appears in red near the top right corner of the display.

Captured channels may be released in a particular order. If no channels are selected and you press [Rel], all dependent channels are released. If you press [Rel] a second time, all independent channels are released. If you had selected one or more channels before pressing [Rel], the first time, only those selected channels would have been released, and further presses of [Rel] would be in the same order as explained above.²⁵

Captured channels in fixtures are released essentially the same way. If no fixtures are selected and you press [Rel], all dependent channels are released, including the dependent channels in all fixtures. If you press [Rel] again, all independent channels are released, including the independent channels in all fixtures. If you select a fixture first before you press [Rel], only the dependent channels of that selected fixture are released. Pressing [Rel] a second time releases all independent channels of that selected fixture. Pressing [Rel] on or two times again releases remaining dependent and independent channels as explained above.

Recorded channels

Recorded channels have been recorded in a cue, group, focus point or submaster. Recorded channels may be either moving or tracked in Blind mode (see below). Channel levels controlled by effects are in white in Stage or Fader displays. Channel levels controlled by submasters other than effect submasters are in yellow in Stage displays.

Moving channels

Moving channels are channel levels that change from one cue to the next. In Stage mode, all moving channels are displayed in green. In Blind, moving channels are displayed in green if they are moving down or blue if they are moving up.

Tracked channels

A tracked channel is a channel whose level is unchanged from the preceding cue. Tracked channels are displayed in purple.

^{25.} See Channel Attributes display, page 53, for a discussion of independent and dependent channels.

Channel Attributes display

The Channel Attribute display shows the following settings for every console channel.

Independent

Designates whether a channel is dependent upon or independent of Grandmaster, Flash, Release, Solo, and Blackout control. Independent channels have a "y" in the **Ind** field, while all others have no entry in the **Ind** field. You must press [Rel] twice, or in some cases, three times to release independent channels.

Flip

Means that the channel's output is reversed. A flipped channel's DMX output is at full when the channel is set to zero and at zero when the channel is set to full. In this display, a flipped channel is identified with a "y" in the **Flip** field, while unflipped channels have no entry in the **Flip** field.

• 16-bit

Designates whether a channel is used for 8-bit or 16-bit data. For 8-bit data, there is no entry in the **16b** field. For 16-bit data, the **16b** field can have a "Hi" or a "Lo" label signifying whether the channel sends the higher or lower bits of a 16-bit control signal.

LTP

Designates whether a channel obeys the Highest Takes Precedence (HTP) or the Latest Takes Precedence (LTP) convention. HTP channels have no entry in the **LTP** field of the display, while LTP channels are identified by a "y" in the **LTP** field.

• Label

You cannot assign labels to channels with an Express console. However, you may make labeling assignments for Express in Expression Off-Line and those assignments will remain when the show is read into an Express console. See *Expression Off-Line, page 312*.



Editing in the Channel Attributes display

Channels not patched to fixtures may be fully edited in the Channel Attributes display.²⁶ Use [Thru], [And] and [Except] if you wish to select multiple channels.

Independent channels

A channel is normally controlled by the Grandmaster, Flash, Release, Solo, and Blackout functions but can be made independent of them.²⁷ Use the procedure below to make one channel or a range of channels independent.

Keystrokes:

Action:

1.	Press [Setup].	Selects Setup menu
2.	Press [1][1] [Enter].	Selects Channel Attributes display
3.	Enter channel number(s).	Selects channel(s)
4.	Press [S1], Independent .	Prompt reads: Enable/disable independent channel(s) (1 = Enable, 0 = Disable) (Channels in ML fixture patch cannot be edited except label)
5.	Press [1] [Enter].	Each selected channel is set as independent

Flipped channels

Two lights can be made to work in opposite directions if the output of one of them is flipped. For example, if a flipped conventional light and a normal conventional light both are recorded to a submaster, one will brighten and the other darken as the submaster slider is moved. Use the procedure below to flip one channel or a range of channels.

Ke	ystrokes:	Action:
1.	Press [Setup]	Selects Setup menu.
2.	Press [1][1] [Enter]	Selects Channel Attributes display.
3.	Enter channel number(s).	Selects channel(s)
4.	Press [S2], Flip .	Prompt reads: Enable/disable flipped channel(s) (1 = Enable, 0 = Disable) (Channels in ML fixture patch cannot be edited except label)
5.	Press [1] [Enter]	Each selected channel is set as flipped.

^{26.} Use the Expression Personality Editor to edit fixture attributes.

^{27.} See Captured channels, page 52, for information about releasing channels on stage when they're independent.

Channel data type

Channels normally contain 8-bit data but may be enabled to contain 16-bit data. Enabling for 16-bit data always involves the next channel in order as well. The enabled channel is called the "HI" channel because it holds the high-order bits of the 16-bit data. The subsequent channel is called the "LO" channel because it holds the low-order bits. Either may be reassigned to 8-bit data, but when you do that, both channels of a 16-bit pair are reassigned at once. Use the procedure below to enable one channel or a range of channels for 16-bit data.

Keystrokes:

Action:

1.	Press [Setup].	Selects Setup menu.
2.	Press [1][1] [Enter].	Selects Channel Attributes display.
3.	Enter channel number(s).	Selects channel(s)
4.	Press [S3], 16b .	Prompt reads: Enable/Disable 16 bit channel(s) (1=Enable, 0=Disable) (Channels in ML fixture patch cannot be edited except label)
5.	Press [1] [Enter].	Each selected channel is set for 16-bit use

Channel convention

Channels normally operated in HTP mode but may be enabled to operate in LTP mode.²⁸ Use the procedure below to enable one channel or a range of channels for LTP mode.

Keystrokes:		Action:
1.	Press [Setup].	Selects Setup menu.
2.	Press [1][1] [Enter].	Selects Channel Attributes display.
3.	Enter channel number(s).	Selects channel(s)
4.	Press [S6], LTP .	Prompt reads: Enable/Disable "last takes precedence" channel(s) (1=LTP, 0= Normal) (Channels in ML fixture patch cannot be edited except label)
5.	Press [1] [Enter].	Each selected channel is set as LTP

^{28.} See Output level conventions, page 4, for a comparative discussion of HTP and LTP channels.

Selecting channels

Using the keypad to set channel levels involves two steps: selecting the channels whose levels you want to modify, then entering output levels.

- To select a single channel, enter the channel number preceded by [Channel] if the [Channel] LED is not lit. For example, [Channel] [1] selects channel 1 or just entering 1 will do it if the [Channel] LED is lit.
- To select two channels that are not consecutively numbered, enter the number of the first channel, then press [And] and enter the number of the second channel. For example, [Channel] [1] [And] [7] selects channels 1 and 7.
- To select a group of consecutively numbered channels, enter the number of the first channel, then press [Thru] and enter the last number. For example, [Channel] [1] [Thru] [9] selects channels 1, 2, 3, 4, 5, 6, 7, 8, and 9.
- To exclude consecutive channels from a selected group of channels, press [Except] before entering the channels to exclude. For example, [Channel] [1] [Thru] [1][5] [Except] [5] [Thru] [1][3] selects channels 1, 2, 3, 4, 14, and 15.
- Use [And] to select each non-consecutive channel to include in a selection. For example, [Channel] [1] [Thru] [5] [And] [8] [And] [1][1] selects channels 1, 2, 3, 4, 5, 8 and 11.
- Use [Except] to exclude each non-consecutive channel from a selection. For example, [Channel] [1] [Thru] [5] [Except] [1] [Except [5] selects channels 2, 3 and 4.
- If no channels are selected, press [Enter] to select all channels currently at a level above zero.

Once you have entered your channel selections, you are ready to set channel levels.

Selecting channels in Flexichannel mode

In Flexichannel mode, only channels that are used in the show appear on the Stage, Blind and Fader displays. See *Flexichannel, page 18*, for information on enabling and updating Flexichannel.

When Flexichannel mode is enabled, the [Thru] key functions slightly differently. For example, in normal mode, pressing [1] [Thru] [5] selects all channels from 1 to 5. In Flexichannel mode, pressing [1] [Thru] [5] selects all **visible** channels from 1 to 5.

To select <u>all</u> channels from 1 to 5, including channels that haven't been used in the show so far, press [1] [Thru] [Thru] [5]. Pressing [Thru] a second time alerts the system to ignore Flexichannel for that channel selection.

Setting channel levels

You assign output levels to channels using the basic format [Channel] [#] [At] [#] where the first number is the channel and the second is the level. For example, [Channel] [4] [At] [7][5] sets channel 4 at 75 percent. If you enter a single digit for the level, the console multiplies it by ten and you must follow it with [Enter]. In other words, [Channel] [4] [At] [1] [Enter] sets channel 4 to 10 percent. To set channel 4 to 1 percent, enter [Channel] [4] [At] [0][1].²⁹

Channel sliders

Your console has two rows of numbered channel sliders. Each channel slider controls the level of a channel. The sliders on the top row have a single number, indicating the channel they control. The sliders on the bottom row have two numbers. The larger number indicates which channel they control when the console is in one scene mode. The smaller number indicates which channel they control when the console is in two scene mode.

On the Express 24/48, in one scene mode, you may also set the bottom row of sliders to be submasters instead of channel sliders. See *Scene mode, page 30* for more information.

Trackpad

To set channel levels with the trackpad, select the channels whose levels you want to modify, then move your finger up or down on the trackpad to set the desired output level.

There are two ways to select channels for trackpad adjustment. You can specify them on the keyboard or you can select all those channels at once whose levels are above zero. As an example of the first of these, press [Channel] [1] [Thru] [5]. To select all non-zero channels, press [Enter].

Full

Press [Full] to set selected channel levels to 100 percent. For example, press [Channel] [1] [Thru] [3] [Full] to set channels 1, 2 and 3 to 100 percent.

Level key

[Level] sets selected channel levels to the output level assigned to the [Level] key. The default value for [Level] is 100 percent. (See *Setting default Level key, page 25*, for instructions on changing the Level key's setting.) For example, if Level is set at 75 percent, press [1] [Thru] [5] [Level] to set channels 1, 2, 3, 4, and 5 to 75 percent.

Flash

Flash sets the selected channel's level to 100 percent if the channel is currently at a level at or below 50 percent. If the channel's level is above 50 percent, **Flash** sets it to zero. Levels set by Flash are only maintained while the key is pressed. For example, press [Channel] [5], then press and hold [S8], **Flash**, to set channel 5 to either 100 or zero.

^{29.} To clear channels, press [At] [Clear].

Sneak

Sneak is a softkey that you can use to fade channels on stage to a level you choose in a specific time or to restore channels to the last level at which they were set with a fader or submaster. For example, if you bring up a cue, then change the look, you can use sneak to go back to the look created by the original cue. You can use Sneak with groups, submasters and focus points as well as with cues.

If you do not indicate a time, the sneak occurs in the default sneak time, set in System Settings.

Follow these steps to use Sneak to set a channel level.

Keystrokes: Action: Selects Stage display mode 1. Press [Stage]. 2. Press [S1], Sneak. Selects Sneak mode Prompt reads: Sneak mode - Select channels, then press ENTER to sneak, or AT to select sneak level, or TIME to select sneak time Selects channel 5. Sets level at 50 3. Select the channel(s) you want to sneak and the level percent Prompt reads: to which you want it to fade. For example, press Sneak mode - Select level [5] [At] [5]. 4. Press [Time] and enter the Selects Sneak time of ten seconds time for the sneak. For Prompt reads: Sneak mode - Select time example, press [Time] [1][0]. Fades channel 5 to 50 percent over 5. Press [Enter]. ten seconds

Follow these steps to restore a channel to its last fader or submaster level. $^{\rm 30}$

Keystrokes:Action:1. Press [Sneak] and select
the channel(s) you want to
restore. For example,
press [5].Selects channel 5 to sneak
Prompt reads: Sneak mode - Select
channels, then press ENTER to
sneak, or AT to select sneak level,
or TIME to select sneak time

2. Press [Enter]. Fades channel 5 back to its most recent cue or sub level

^{30.} Press [Sneak] [Enter] to restore all channels to their current fader or submaster levels.
Channel check

Flash.

Use a Channel Check to check which channel controls which light. The console allows you to check channels by selecting a single channel and flashing it to a level.³¹ Once you have selected a channel you can then advance sequentially through the channels, checking one at a time. You may start a channel check with any channel.

Follow these steps to run a channel check:

Keystrokes:		Actions:
1.	Press [Stage].	Selects Stage display Prompt reads: Select channel numbers
2.	Press [Channel] [1].	Corner reads: Chan 1
3.	Press [S7], More Softkeys.	
4.	Press and hold [S8], Flash .	Sets channel 1's level to 100 percent if its current level is at or below 50 percent or Sets channel 1's level to zero if its current level is above 50 percent
5.	While holding [S8], press [+] or [–] to select the next or previous channel.	Flashes each channel in turn
6.	Once you have checked all the channels, release [S8],	

^{31.} If a channel is independent, it will not flash in response to a channel check.

About Channel

The About Channel display gives you information about the characteristics, patch and use of individual channels. It can be displayed while in any other display. For similar information about dimmers, see *About Dimmer, page 46*.

Go to the About Channel display as follows.

Key	ystrokes:	Action:
1.	Press [About] [Channel].	Prompt reads: About: Select channel number, then press ENTER
2.	Press [6].	Keypad corner reads: Chan 6
3.	Press [Enter].	About Channel window is displayed. ^a

a. Press [Clear] to remove the window.

Features of the display

Following is an About Channel display for a channel patched to a fixture attribute. When a channel is either unpatched or patched to a conventional light, the Fixture and Type fields shown below are replaced by a Link field. When a name or label is indicated below, see *Expression Off-Line, page 312*, for information about assigning labels,

	=About:	Channel 1]
Label :			
Fixture: 1 Type: I-Beam Device: Pan	16	Attributes: Ind	165 Hi LTP
First used: 1 Number of cues:	4	Last used: 103 Number of moves: 4	
Level: O Source: None		Parked: n Inhibited: n	
Dimmers: 1			

- Label
- Fixture

Туре

Name, if any, assigned to the channel.

(Only for channels patched to a fixture) Number and name, if any, assigned to the channel in Fixture Patch.

(Only for channels patched to a fixture) Name of the personality used for this fixture.

- Link
- **Device** If channel is patched to a fixture, Device shows the assigned fixture attribute. If channel is on a Link List, Device shows which trackpad axis is assigned.

Link number, if any.

- Attributes
 - ▼ Ind
 - ▼ 16b Hi

Flip

LTP

First used

Last used

Level

Inhibited

Dimmers

Number of cues

Number of moves

Source

- portion of 16-bit data.³² **16b Lo** The channel controls the low
 - The channel controls the low bits portion of 16-bit data.³²

Channel characteristics, such as:

The channel controls the high bits

The channel is independent.³²

- The channel's output has been reversed.³³
- The channel's convention is LTP. ³²
 - Identifies how the channel is being controlled, e.g. cue number, background cue number, captured, fader pair, submaster number.
 - The first cue in which this channel appears.
 - The highest numbered cue in which this channel appears.
 - The total number of cues in which this channel appears.
 - The total number of cues in which this channel moves.
 - The channel's current level and focus point reference, if any.
 - The inhibitive submaster, if any, which is controlling the level of the channel.
- The dimmers assigned to the channel, as space permits.

^{32.} Editable in the Channel Attributes display except for channels patched to ML fixtures. This feature is editable for ML fixtures in the Expression Personality Editor.

^{33.} Editable in the Channel Attributes display except for channels patched to ML fixtures. Editable in Fixture Patch for channels patched to ML fixtures.

Chapter 6 Adding moving lights to the show

The first step in working with moving lights is to add them to your show. Then, when your console has information about what types of fixtures, personalities and fixture attributes you are using, you are ready to customize your console to work most efficiently with them. Both steps are initiated from the Moving Light Functions menu.

This chapter contains the following sections:

- The Moving Lights Function menu
- Personality setup and editing
- Patching moving light fixtures and fixture editing
- Attribute setup and category editing
- Encoder setup
- Using the moving lights Fixture Box
- Fixture focus with Solo

Moving Light Functions menu

Go to the Moving Lights Functions menu by pressing [Setup] [1][5] [Enter].



- 1. **Personality Setup** The console comes with default personalities already included in its system software code. These may not be sufficient for your purposes, however, and you may need to add additional ones. Work directly with personalities here.
- Fixture Patch Once you have the personalities in the console that you need, begin the task of patching fixtures with those personalities. In addition to patching, you can customize here by labeling and modifying the standard patching.³⁴
- 3. Attribute Setup Go to this display to customize the assignment of fixture attributes to categories. Later during the creation of your show, this categorization will help you grab the moving light attributes you want by color, position or other traits to set levels, create cues, etc. The attributes used in your show are highlighted in the Attribute Setup display.
- 4. **Encoder Setup** This display allows you to customize the assignment of the trackpad to fixture attributes for greater level-setting convenience. The console helps you here too by highlighting those fixture attributes you are using so you can easily put them where you want them.

^{34.} You can assign labels to dimmers in Expression Off-Line. See Expression Off-Line, page 312.

Personality Setup

You may find that the default personalities embedded in console software are sufficient for your needs. If not, you may be able to get the personality you need from ETC or create it yourself. See *Personalities, page 7*, to learn about these options.

All personalities can be included in your show or deleted from it to save console memory. You may also inspect a personality in your show.

Go to the Personality Setup display

- 1. Press [Setup] [1][5] [Enter] to display the Moving Lights Functions menu.
- 2. Press [1] [Enter] to go to the Personality Setup display

			Personali	ty Se	tup		Person
			02:46	РM			
Num	Personality	Num Pe	rsonality	Num	Personality	Num	Personality
+~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	Cyberlight I-Beam 16 MAC500-16 Mac600-16 Mscan hpe Stage Scan StudioCo UL6 16 UL6 16 EXT UL6 16 EXT UL5 16 EXT TechnoBm_16						
			elect person	ality	number		
S1	S2	S3	S4	S5	S6	S7	S8
En Dir	om sk	View Personlt			Delete Personitu	Res Defa	et ults Return

Navigation and Feedback - Personality Setup display							
	7 8 9 4 6 6 1 2 3	[S]	⋪↓	4	±		
Select a personality	Х		Х		Х		
Yellow highlighting	Perso	Personality selected in the display					
Purple highlighting	Perso	onalities	s in use	in the s	show		

Loading personalities into the console

You may load additional personalities to your show if you find that the default personalities are not sufficient for your needs. Any personalities loaded to your show are saved with your show.

Load personalities to your show from a diskette. If you obtained the extra personalities from ETC's internet website, store them first on your hard drive, preferably in the Shows directory set up by Expression Off-Line. See the Expression Off-Line QuickGuide for information about using Off-Line to create and edit shows for your console.

When you are ready to load personalities to your show, transfer what you need from your computer to a diskette. The console loads all files from the diskette to your show at once. Follow the procedure below to load personality files.

- 1. Insert the 3.5-inch diskette in the console disk drive.
- 2. From the Personality Setup display, Press [S1], From Disk, [Enter].
- 3. Remove and store the diskette when the transfer is complete.

WARNING - If possible, always load personalities before patching. If you try loading a personality with the same name as one you already have in your show, you will get the warning shown below. If you are replacing a personality with one that assigns more channels, the automatic repatching will cause erroneous overlapping. Such overlapping can cause unexpected or inconsistent behavior from recorded elements such as groups and cues used in the show. You may need to repatch fixtures.

				Democratic	A			
				Personali 02:16	ity Setup 5 PM			
Num	Personal	lity N	um Perso	onality Noor	NUM Pe	rsonality	Num Pers	onality
1	Cuberl			WHR	11NG			
ź	I-Beam	Stu	dioCo alm	ready exis	sts in sh	οω		
3	MACSOO	- A name	can be us	sed for or	ily one p	ersonality i	na 👘	
4	Мновор	show.	lt L⊦rom. L:to o:l	DiskJ is Lbe over	continue witten w	d, the previ	ous Enom	
Ğ	Stage	disk wh	ich has '	the same r	iame. As	signed fixtu	res	
7	Studio	will be	unpatche	ed and hep	atched.			
8	VL6 16	To over	white all	l duplicat	tes (pres	s [Enter]		
10	ULS 16	To over	write th	is duplica	ite, pres	s [Plus]		
11	VL5_16	To skip	this dup	licate, p	oness EMi	nusl		
12	Techno		_		_			
13	ngresi							
C 4		22	63	94	95	96	97	co
En	rom		View			Delete	Reset	
Di	sk	Per	rson I tu			PersonItu	Defoults	Return

Viewing a personality

- 1. From the Personality Setup display, type the number of the personality you want to view.
- 2. Press [S3], **View Personality** and the view display appears. To view another personality, scroll with the [+] or [-] keys.
- 3. Press [S8], **Return**, to return to the Personality Setup display.

Deleting personalities

You may delete personalities from the show either one at a time or in groups using the [+], [–], [And] or [Thru] keys.

- 1. From the Personality Setup display, press [S6], Delete Personality.
- 2. Type the number of the personality you want to delete, followed by [Enter] to confirm your choice. If you change your mind after selecting a personality, press [Clear] to begin again.

Resetting defaults

You may restore any of the default personalities that were deleted. When restoring the default personalities, any uploaded personalities are deleted. To reset defaults, go to the Personality Setup display, Press [S7], **Reset Defaults**, and complete the action by pressing [Enter].

WARNING - Resetting restores default personalities. If you loaded a personality with the same name as a default and used it in your show, the fixtures patched with that personality will be repatched using the default.

Patching moving lights

Fixtures are installed in the Fixture Patch display in numerical order, either singly or in ranges.

Go to the Fixture Patch display

There are two ways to get to the Fixture Patch display. Either select option 2 from the Moving Light Functions menu or press [S8], **Fixture Patch**, in the Patch display. 35

			Fix O	ture Po 2:37 Pi	atch M			F	Tixtur
Fixture Number	Label	Personali	ty	Start Chan	DMX512 Start	Remote Dimmer	Swap Focu	Flip 5	Intens Chan
1 2 3 4 5 6 7 8 9 0 10		2 I-Beam 2 I-Beam 2 I-Beam 2 I-Beam 2 I-Beam 1 Cyberl 1 Cyberl 1 Cyberl 1 Cyberl	16 16 16 16 16 16 16 16 16 16 16 16 16 1	1 21 31 41 51 71 91 131	1/1 1/21 1/21 1/51 1/51 1/71 1/211 1/111				8 18 28 48 68 88 108 128 148
		Se	lect f	ixture	number	(s)			
S1	S2	SS	S4		S5	S6		S7	S8
Fixture	Label	ality	Previo	e	Page	Fixtu	re :	More Boftkeys	Return

Navigation and Feedback - Fixture Patch display							
	7 8 9 4 6 6 1 2 3	[S]	^↓	*	±		
Select a fixture	Х	Х	Х		Х		
Select a feature		Х		Х			
Make a change	Х				Х		
White line	Indicates fixture selected						
Yellow coloration	In	dicates	feature	selecte	ed		

^{35.} Pressing [S8], **Return**, in Fixture Patch returns you either to the Moving Lights Functions menu or to the Patch display, depending upon which of the two you were in just prior.

Patching one fixture or a fixture range

The following procedure makes use of the automatic cursor movement from field to field for efficient data entry. When patching a range, all range members receive the same assignments except as noted below. Alternatively, you can use softkeys at any time to make entries in specific fields, such as to individualize labels when fixtures are patched as a range.

- 1. **Fixture Number**: Enter the fixture number or range. Fixtures are entered in order, starting with "1". Press [Enter].
- 2. **Label**: Can be assigned with Expression Off-Line. See *Expression Off-Line, page 312*.
- 3. **Personality**: Enter the number of the personality from the list of personalities you have available. Alternatively, scroll through the personality choices with the [+] or [–] keys. Press [Enter] to select.
- 4. **Start Channel**^{36, 37}: Enter a number for the first channel to be assigned to the fixture(s). If entering a range, picking the Start Channel assigns a sequential start channel to every fixture in the range. Press [Enter].
- 5. **DMX512 Start**³⁶, ³⁸: Enter the number of the desired DMX port. Press [Enter]. The cursor remains in the DMX512 start field but moves to the right of a slash inserted in the field. Enter an address for the fixture within the DMX port (1-512). If entering a range, picking the DMX address assigns a sequential address at that port to every fixture in the range. Press [Enter].
- 6. **Remote Dimmer**: If the personality signals that the fixture has its own dimmer, an "n" automatically appears in this field. If the fixture needs a remote dimmer, enter the dimmer's number. If entering a range, picking the dimmer number automatically assigns a unique dimmer to every fixture in the range. Press [Enter].
- 7. **Swap Focus**: If you use a pointing device, pan level adjustment is normally on the X-axis and tilt level adjustment is normally on the Y-axis. Regardless of where pan and tilt level adjustments are assigned, you may reverse these assignments with Swap Focus. Follow the onscreen prompt or toggle with the [+] or [-] keys to switch between swap and normal. Press [Enter].
- 8. Flip: Normally, when the control to which pan or tilt is assigned is increased, the level increases too. You may invert this relationship for pan or tilt with Flip, which can be used to "mirror" two moving lights. In Fixture Patch, Pan is prompted first, tilt second. For each, follow the onscreen prompt or toggle with the [+] or [-] keys to switch between flip and normal. Press [Enter] to complete each assignment.
- 9. **Intensity Channel**: Identifies the channel number of the fixture's intensity channel.

^{36.} An Advisory appears if you choose a Start Channel or DMX512 Start address that overlaps patchings for other fixtures. A Warning appears if the start address is too high. Press [Clear] to remove the Advisory or the Warning and make other selections.

^{37.} After a fixture's start channel is selected, levels can be set for the fixture's attributes and recorded into cues. The console will not control the moving light, however, until DMX512 addresses have been set.

^{38.} The port and starting address must be set so that there are enough DMX512 outputs for all the attributes of all the fixtures.

Editing the fixture list

You may edit or delete fixtures individually or in groups in the Fixture Patch display. $^{\rm 39}$

Editing a fixture

- 1. From the Fixture Patch display, enter the fixture number(s).
- 2. Use the left/right arrow keys to move to the field where you want to make a change. Enter a numeric value or scroll with the [+] or [–] keys to make the change. Press [Enter].

Deleting a fixture or a range of fixtures:

- 1. From the Fixture Patch display, press [S6], **Delete Fixture**. If Delete Fixture is not displayed as a softkey, press [S7], **More Softkeys**, first, then press [S6], **Delete Fixture**.
- 2. Enter the fixture number(s).
- 3. Press [Enter] to delete, or press [Clear] to re-select.

^{39.} When an edit field and fixture are selected, you can move quickly to other edit fields or fixtures with the arrow keys. Use the left/right arrows to move to other edit fields and the up/down arrows to move to other fixtures.

Attribute Setup

Personalities may have as many as 64 attributes. Most of the 64 attributes have names that describe the function to which they are assigned, such as pan, tilt, gobo or strobe. The rest have either User or Reserved designations and are unassigned.

The system software assigns each attribute to one of five categories by default, but you can change these assignments. The category assignments affect all fixtures in the show alike. See the list of categories and examples of attributes assigned to them in the table below.

Categorization provides a way for you to refer to attributes during programming in relation to their function (such as position or color) rather than to attributes by their individual names. Use the Only command when referencing attribute categories.

	Default attribute category assignments							
Position	Position attributes, such as pan and tilt, control the direction of the fixture.							
Beam Beam attributes, such as intensity and zoom, cor the quality of the fixture's field.								
Image	Image attributes, such as gobo and F/X, control the shape of the fixture's field.							
Color	Color attributes, such as cyan and magenta, control the color of the fixture's beam.							
None	None are those attributes, such as speed and control, not included in the other four categories.							

Go to the Attribute Setup display

The Attribute Setup display lists all attributes and identifies their category assignments. You can change the categories to which an attribute is assigned by adding or removing them in this display. Every attribute must be assigned to at least one category. Multiple category assignments are allowed except when an attribute is assigned to the None category.

- 1. Press [Setup] [1][5] [Enter] to display the Moving Light Functions menu.
- 2. Press [3] [Enter] to go to the Attribute Setup display.

	Attribut 09:36	te Setup 5 AM		Attrib
Attribute	Category	Attribute	Category	
1 Intens 2 Pan 3 Tilt 4 Color 5 Color2 6 Cyan 7 Magent 8 Yellow 9 Gobo 10 GoboRo 10 GoboRo 11 Gobo2R 13 F/X 14 F/X Ro 15 Prism 16 Strobe	Beam Posit Color Color Color Color Image Image Image Image Image Beam Beam	17 Zoom 18 Focus 19 Iris 20 Frost 21 Pan Ro 22 TiltRo 23 Beam1a 24 Beam1a 25 Beam2a 26 Beam2a 27 Beam3a 28 Beam4a 29 Beam4a 30 Beam4b 31 BeamRo 32 Speed	Beam Beam Beam Posit Beam Beam Beam Beam Beam Beam Beam Beam	
	Select attri	bute number		
S1 S2	S3 S4	S5 S6	S7	S8
Select Attribute Cate	gory Previous	Page	Defaults	Return

Navigation and Feedback - Attribute Setup display							
	7 8 9 4 6 6 1 2 3	[S]	⋪↓	++	±		
Select an attribute	Х	Х	Х		Х		
Select a category		Х		Х			
Make a change	Х						
Purple coloration	Att	ributes	used in	the sh	ow		
Gray coloration	Attributes not used in the show						
Yellow coloration		lter	n selec	ted			

Changing an attribute's category assignment:

- 1. Enter the number of the attribute. Press [Enter].
- For each category to be added or removed, enter its assignment number (0=None; 1=Position; 2=Image; 3=Color; 4=Beam). Entering the number either adds or removes the category depending upon whether the attribute is already assigned to it or not.
- 3. Press [Enter] after you have made all changes. You may start over at any time by pressing [Clear] or typing 0 to choose None.

Resetting defaults:

Each of the 64 attributes has a unique default category assignment. To reset all attributes to their category defaults, go to the Attribute Setup Display. Then, Press [S7], **Reset Defaults**, followed by [Enter].

Encoder Setup

Encoders are rotating level setting devices that are either installed in some consoles or available as an attachment. Express consoles do not use encoders but can make use of encoder pages to provide easier access to a number of fixture attributes.

The encoder Setup display allows you to change the assignment of fixture attributes among your level-setting devices and pages. For Express, that means you can choose which attributes are assigned to the two axes of the trackpad, TX and TY, for the six pages available.

The default assignment is to have the pan and tilt attributes on the trackpad for every page. That means you can retain the convenience of having the position attributes on the trackpad for one of those pages and make alternate attribute assignments on the remaining 5 pages.

Go to the Encoder Setup display

- 1. Press [Setup] [1][5] [Enter] to display the Moving Light Functions menu.
- 2. Press [4] [Enter] to go to the Encoder Setup display.

			Encoder Set	up		Encodr				
			11:41 AM							
Encoder	Page 1	Page 2	Page 3	Page 4	Page 5	Page 6				
1 2 3 4 5	Intens Color Color2 Cyan Magent	GoboRo Gobo2 Gobo2R F/X F/X Ro	Zoom Focus Iris Frost Pan Ro	Beam1b Beam2a Beam2b Beam3a Beam3b	BeamRo Speed Speed2 Contrl Contr2	ChkSum User 6 User 5 User 4 User 3				
6 X 7 Y	Yellow Gobo	Prism Strobe	TiltRo Beam1a	Beam4a Beam4b	CirFnc LensWi	User 2 User 1				
8 TX 9 TY	Pan Tilt		Pan Tilt		Pan Tilt					
	Select encoder number									
S1	62	00	e4 e	E 96	67	c0				
Select Encoder	Page	Attribute			Reset Default	s Return				

Navigation and Feedback - Encoder Setup					
	7 8 9 4 5 6 1 2 3	[S]	↑ ↓	+	±
Select an encoder	Х	Х	Х		Х
Select a page	х	Х		Х	Х
Assign attribute	х				Х
Purple coloration	Attributes used in the show			ow	
Gray coloration	Attributes not used in the show				
Yellow coloration	Encoder/page selections				
White coloration	/	Attribut	e field s	selected	ł

Changing assignments

Encoders and other level setting devices are assigned to 44 of the 64 available attributes by default. You may change the default settings to suit your individual needs, such as to reassign attributes that you most commonly select to suit your individual setup or preferences. You may not, however, assign an attribute to more than one location on a page.

There are three ways to change assignments in the Encoder Setup display: individually, automatically and back to defaults.

Change individually

- 1. Select a trackpad axis with the up/down arrows.
- 2. Select Page 1 with the left/right arrows. Press [Enter].
- 3. Select an attribute with the [+] or [-] keys.
- 4. Continue making changes until done.

Change automatically

The console can make automatic level setting assignments for all fixture attributes you are using in your show. One reason you may want to use this automatic assignment feature is to ensure that all your attributes are included in the encoder setup (20 do not appear in a default setup). Another reason is to quickly concentrate your attributes on the lower-numbered pages, thus reducing the need to change pages when setting levels. Only attributes in the current show are assigned. pan and tilt are assigned to the trackpad on every page.

This feature is available as a softkey called Autoload Encoders in Fixture Patch or in the Encoder Setup display (in Fixture Patch, you may need to press [S7], **More Softkeys**, first). In the Encoder Setup display, press [S6], **Autoload Encoders** (you must press [Enter] twice to confirm). After executing an Autoload assignment, the Encoder Setup display resembles the one shown in the illustration below.

			Encoder	 Setu 	γp				Enco	odn
			08:14	1 AM						
Encoder	Page 1	Page 2	Page	з	Pag	e 4	P	age 5	Page	≥ 6
1 2 3 4 5	Intens Color Color2 Cyan Magent		Focus Iris Frost Speed Contrl							
	Yellow Gobo									
8 TX 9 TY	Pan Tilt		Pan Tilt							
		Sel	ect enco	oder n	umber					
S1	S2	S3	S4	SS	5	S6		S7	S	3
Select Encoder	Page	Attribute				- Autol - Encod	oad ens	Reset Default:	s Ref	turn

Resetting defaults

You may return to the default level setting assignments anytime you wish. In the Encoder Setup display, press [S7], **Reset Defaults**, and press [Enter] twice to confirm.

Working with moving lights

Moving lights displays

Moving lights and conventional lights use the same Blind and Stage displays. Each moving light, however, is distinguished in these displays by a gray bar surrounding the numbers of all channels in the fixture. Also, channels that carry the low order bits of 16-bit attributes have dimmed channel numbers.

Levels are set for the channels of moving light fixtures in a Fixture Box window that pops up in Blind and Stage displays when a fixture is selected.⁴⁰ The list under the screen shot below identifies the contents of the Fixture Box window.

Go to the Fixture Box window

- 1. Press the [Stage] or [Blind] key.
- 2. Press [S8], Fixture.
- 3. Enter a fixture number(s). The fixture box appears.



Following are features of the Fixture Box.

- The fixture is identified by number, label (if assigned) and personality.
- Page numbers are shown in white if any of the fixture's attributes are on that page. The current encoder page is identified in yellow.
- The fixture's attributes on the current page are identified in gold.
- The level assigned to each identified attribute is identified in the "Value" line. For 8-bit data types, the level is given as a percentage. For 16-bit data types, the level is given as a value in the range 0-65535.
- The level setting device assigned to each identified attribute is identified, where TX and TY are the axes of the trackpad.⁴¹

^{40.} When a range of fixtures is selected, the Fixture Box contains information pertaining only to the last fixture in the range.

^{41.} E1-E5 are for encoders; X and Y are for wheels. These settings are inapplicable to Express consoles which have neither encoders nor wheels.

Working with fixtures

Following are some principles to keep in mind when setting fixture attribute levels.

- If a fixture has a strobe attribute, that attribute must be set above zero so that the light can be seen.
- The intensity attribute is selected by default unless you select an attribute. Use this as a shortcut method to set fixture intensities. For example, set the intensity of three moving lights on stage by pressing [Stage] [S8], **Fixture**, [1] [thru] [3] [Full].
- If you wish, you can assign attribute levels without using the Fixture Box. For instance, if a fixture is patched to channels 1 through 20, you can set the levels of channels 7 and 8 as follows: press [Stage] [Channel] [7] [And] [8] [At] [5] [Enter].
- If you are working with fixtures directly but don't want the Fixture Box on the screen, press [Clear] to remove it. The encoders remain active when the Fixture Box is cleared. You can clear away the Fixture Box even in the midst of a lengthy command sequence without altering the results. For instance, set the intensity of fixtures 1 through 3 to full and clear away the Fixture Box in one command sequence as follows: press [Blind] [S8], **Fixture**, [1] [thru] [3] [Clear] [Full].

Setting levels in the Fixture Box

Use the procedure below this Navigation and Feedback table to set attribute levels in the fixture box.

Navigation and Feedback - Fixture Box display				
	7 8 9 4 6 6 1 2 3	^ ↓	44	±
Select fixture	Х			Х
Select page		Х		
Select attribute			Х	
Page highlighted white	Fixture attributes exist on page			S
Page highlighted yellow		Selecte	ed page	
Attribute gold	Attribute of selected fixture			
Attribute highlighted yellow	S	elected	attribut	e

- 1. With a fixture in the Fixture Box, press the up/down arrows to select a page.
- 2. Select an attribute with the left/right arrows.
- 3. Adjust the level of the selected attribute with the trackpad.⁴²
- 4. If there are other fixture attributes on the same page that you wish to set, repeat steps 2 and 3 above. Continue until finished with all attributes on that page.
- 5. If attributes of this fixture are on a different page, repeat steps 1 through 4 above. Continue for all pages on which the fixture's attributes are located.
- 6. To set the channel levels of another fixture, select the fixture with the [+] or [-] keys.
- 7. Repeat steps 1 through 6 until finished with all fixtures.

^{42.} Pan and tilt are always selected together when either is selected. Whichever of these two attributes is selected is placed on one axis of the trackpad and the other of the two is placed on the second axis.

Fixture focus with Solo

Solo provides a convenient way to point or otherwise adjust a selected moving light without the interference of others. Even better, you can increment through fixtures one at a time, adjusting as you go, with a single execution of the solo function.

There is no reason to use solo in Blind because the Fixture Box has a similar incrementing feature. If you do use it in Blind, however, be aware that solo leaves the levels for the selected fixture set and all the rest at zero.

Example:

- 1. Patch fixtures 1-10.
- 2. Press [Stage].
- 3. Select fixtures 1-10 and set levels.
- Press [S8], Fixture, [1] [S7], More Softkeys, [S5], Solo.
- 5. Adjust the fixture.
- 6. Press the + or keys to solo the next fixture.
- 7. Repeat steps 4 and 5 until finished.
- 8. Press [S5], Solo.

Brightens fixture 1 and darkens all other lights.

Solo the next fixture.

Increment through all fixtures.

Return to the complete look on stage.

Chapter 7 Cues

The console allows you to save up to 600 cues per show.⁴³ Cues consist of channel levels and cue attributes. Multiple attributes can be applied to one cue.

This chapter shows you how to create and modify cues as well as copy and delete them. Play back a recorded cue using the procedures given in *Chapter 10 Playing back cues, page 119*.

The examples in this chapter assume there are no cues stored in the console. To clear all cues in memory, press [Setup] [4] [Enter] [2] [Enter] [Enter]. Before you do that, however, consider saving the contents of memory as a show using the procedures given in *Chapter 20 Diskette functions, page 243*.

Chapter seven contains the following sections:

- Cue types
- Record functions
- Creating cues
- Viewing cues
- Working with cues in Stage mode
- Recording a cue in Stage
- Working with cues in Blind mode
- Recording a cue in Blind
- Recording a cue with a single fade time
- Recording a cue with split fade times
- Recording a cue with a wait time
- Recording cues with Link and Follow
- Recording a cue using Solo
- Labeling cues
- Modifying a recorded cue live
- Modifying cue attributes
- Using Update to modify a cue
- Deleting cues
- Copying cues
- Inserting cues

^{43.} If you need more than 600 cues in your show, see The oversized show, page 82.

Cue types

[Type] displays all but one of the fade type options described below. The subroutine option is discussed under *Chapter 17 Subroutines, page 219*.

To select a cue fade type in Stage, Blind or Fader modes, press [Type], and enter the type number given in the prompt. If you change a cue's fade type, you must re-record the cue. For example, [Cue] [2] [Type] [2] [Record] [Enter] records cue 2 with an allfade. Cues default to crossfade when you do not enter a fade type.

Crossfade

In a crossfade cue, channel levels that increase fade to their new level in the assigned upfade time. Channel levels that decrease fade to their new level in the assigned downfade time. The cue starts when you press [Go]. You may use a wait time to delay the start of the upfade or downfade.

Allfade

An allfade cue forces all unused channels to zero intensity when you press [Go] and clears the other fader. Allfade is useful for forcing an end cue when tracking channels. For more information on using allfade cues for tracking, see *Chapter 8 Track*.

Effect

An effect cue contains an effect. Effects allow you to assign channels to a series of steps. When you play back the effect, the steps run in assigned chase patterns, or in random order. For more information on using effects, see *Chapter 16 Effects*.

Blocking

A blocking cue forces all LTP channels to fade to completion in background cue timing and then runs in a physical fader like any other cue. One use for a blocking cue is to end background effect cues under program control. For more information on blocking cues in relation to LTP channels, see *Working with LTP channels, page 5*.

Subroutine

A subroutine is a cue that controls the playback of a series of recorded cues. Subroutines are similar to linked cues, except that you have more playback options. For more information on using subroutines, see *Chapter 17 Subroutines*.

Recording functions

The console has two record functions: Record and Track. Record saves all channels as they appear on the screen (what you see is what you get) in the cue, group or submaster you specify. When you use Record to record a cue, levels are recorded in only one cue.

Track is a record function that works only with cues. It allows you to build a new cue from the previous cue's channel settings. Tracked channels are channels whose levels do not change from one cue to the next. A *track* often runs through several cues for the length of a scene or an act.

Track also allows you to add tracked channels through existing cues. For example, if you have created all cues for a scene, and then decide to add a few new channels to all cues, or adjust the level of a channel throughout the cues, Track lets you do so with one short record command. To do the same thing with Record would require you to add the new channels to each cue individually.

Note: When a channel level that tracks through a series of cues reaches an Allfade cue, the track ends.

We use the standard Record function for all cues in this chapter. Instructions for using the Track function are included in *Chapter 8 Track*.

Viewing cues

You can view stored cues in two ways, live in Stage or Fader displays or on the monitor in Blind mode.

To view cues live, you must select the cue and play it back in a fader. See *Chapter 10 Playing back cues, page 119*, for instructions.

To view a cue only on the screen, select Blind mode and enter the desired cue number. To view a different cue, press [Cue] and the new cue number that you want to see.

In Blind mode you can also use [+] and [–] to move through recorded cues and cue parts, one at a time. Press [Cue], then press [+] to display the next cue or part. Press [–] to display the previous cue or part.

The oversized show

If your show requires more than 600 cues, you can still run it by creating the show in segments, with each segment having less than 600 cues. Follow the procedures below to create and play back an oversized show as a series of separate show segments.

Creating the oversized show

Let's assume that you want to create a show containing 800 cues. Create the intended show as two, separate shows using the following procedure:

- 1. Create a show containing the first 400 cues and store it on a diskette called *Beginning*. You will have the show called *Beginning* stored on diskette as well as in console memory.
- 2. Next, erase all cues from the show in the console memory (not the one on diskette).
- 3. Re-program that show in memory for the remaining 400 cues you need.
- 4. Store that second show on a new diskette called *End*.

Playing back an oversized show

- 1. When it's time to play back the show, load and play back the show called *Beginning*.
- 2. When all cues in *Beginning* have been played, load and play back the show called *End*. Arrange the break between shows *Beginning* and *End* so that it occurs during a natural break in the show or between cues.

Note: If you load in show *End* while playing a cue from show *Beginning* in the faders, you will not be able to view that *Beginning* cue in the Blind display. Instead, the Blind display will show the first cue in show *End*.

Working with cues in Stage

When recording in Stage, such as to record a cue, group or submaster, you will commonly want to start without any live channels. For instance, you may want to create a new cue without using any of the lights placed on stage from a previous fade or channel selection. To clear lighting from the stage, use one or all of the following procedures:

- If the lights are from a cue in a fader, press the fader's [Clear] key one or more times.
- If the lights are captured, press [Rel] two or more times.
- If from a submaster, lower the slider to zero.
- If from channels running in the background, press [S3], **Background Overrides**, [Enter] [Enter].

Recording a cue in Stage

There are several ways you can create a cue from a look on stage. If you have several cues already stored, you may want to base a new cue on the look already recorded for another cue. You would do that by playing the cue in the faders and then modifying the resulting look on stage.

In other circumstances, you may want to enter all channel levels manually. That is the procedure used below. When creating this cue, you will only set channel levels. Default settings will determine all other attributes of the cue. You can change most default settings from the System Settings menu. See *Chapter 3 System settings*, for information about setting and changing defaults.

Follow these steps to record cue 1:44

Key	ystrokes:	Action:		
1.	Press [Stage].	Selects Stage display mode Prompt reads: Select channel numbers		
2.	Press [1] [Thru] [1][0].	Selects channels 1 through 10		
3.	Press [At].	Prompt reads: Enter intensity		
4.	Press [5][0].	Sets a level of 50 percent for channels 1 through 10		
5.	Press [Record].	Prompt reads: To record cue, select number and press ENTER To cancel, press CLEAR		
6.	Press [1].	Selects cue 1		
7.	Press [Enter].	Records cue 1 containing channels 1 through 10 at 50 percent		
8.	Press [Rel].	Releases captured channels		

^{44.} Note that the keypad defaults to cue mode when you press [Record].

Working with cues in Blind

Blind mode allows you to create, preview or modify cues without affecting the current look on stage. If you prefer to work with live looks, you should work in Stage mode.

Recording a cue in Blind

Key	ystrokes:	Action:
1.	Press [Blind].	Selects Blind display mode Prompt reads: Select cue number To select cue type, press TYPE
2.	Press [2].	Selects cue 2
3.	Press [Channel] [1][3] [And] [1][5].	Selects channels 13 and 15 Prompt reads: Select channel numbers
4.	Press [Full]. ^a	Sets channels at full intensity level
5.	Press [Record].	Prompt reads: To record cue, select number and press ENTER To cancel, press CLEAR
6.	Press [Enter].	Records cue 2 with channels 13 and 15 at Full

a. Note that when using [Full], you do not have to press [At] first.

When you record the cue, channel levels set by a fader change from red (indicating a channel level set on the keypad) to colors based on the channels' level movements from cue to cue. $^{45}\,$

^{45.} See Navigation and visual feedback, page 3, for more information on what channel level colors mean.

Recording a cue with a single fade time

Unless you tell it otherwise, the console assigns default fade times to any cue you record. If you prefer, you may record cues with custom fade times instead.

Fade times can be zero seconds to 99:59 minutes long. They may be expressed in minutes and seconds, or as fractions of seconds (in decimal format). Acceptable time values include: 0.2 (.2 seconds), 00:12 (12 seconds), 5.5 (5.5 seconds), or 5:30 (five minutes, 30 seconds).

Follow these steps to record a cue with a custom fade time:

Кеу	strokes:	Action:
1.	Press [Stage] or [Blind].	Selects display mode
2.	Press [Cue].	Prompt reads: Select cue number To select cue type, press TYPE
3.	Press [3].	Selects cue 3
4.	Press [Time].	Prompt reads: Enter upfade time
5.	Press [8].	Enters a fade time of 8 seconds. Corner reads: UpTime 8
6.	Press [Enter] [Enter].	Enters matching downfade time
7.	Press [Record]. ^a	Prompt reads: To record cue, select number and press ENTER To cancel, press CLEAR
8.	Press [Enter].	Records cue 3 with fade time of eight seconds

a. If the cue already exists, you may omit steps 7 and 8.

Recording a cue with split fade times

The console allows you to record cues with different upfade and downfade times. These cues are said to have *split* fade times. On the console's display, the time to the left of the "*I*" refers to the upfade time; the number to the right refers to the downfade time.

Follow these steps to record a cue with split upfade and downfade times:

V.		
ĸe	ystrokes:	Action:
1.	Press [Stage] or [Blind].	Selects display mode
2.	Press [Cue].	Prompt reads: Select cue number To select cue type, press TYPE
3.	Press [4].	Selects cue 4 Corner reads: Cue 4
4.	Press [Time].	Prompt reads: Enter upfade time
5.	Press [1][0].	Enters an upfade time of ten seconds Corner reads: UpTime 10
6.	Press [Enter].	Prompt reads: Enter downfade time
7.	Press [1][5].	Enters a downfade time of 15 seconds Corner reads: DnTime 15
8.	Press [Record]. ^a	Prompt reads: To record cue, select number and press ENTER To cancel, press CLEAR
9.	Press [Enter].	Records cue 4 with upfade time of ten seconds and downfade time of 15 seconds

a. If the cue already exists, you may omit steps 8 and 9.

Recording a cue with a wait time

Wait time is the time that elapses between when you press [Go] and when the actual fade begins. You can record cues with a wait time of up to 99:59 minutes.

Wait time may be entered in normal time format or in decimal format. When entered with a decimal point, the number must be less than one minute (0.1 to 59.9 seconds) to be accepted. When entered without a decimal point, a 2-digit number will be treated as seconds if less than 60 and as a calculated value of minutes and seconds if between 60 and 99. For example, if you enter 70, the time will display as 1:10. If you enter either a 3-digit or a 4-digit number, the last two digits, up to 59, are interpreted as seconds. For example, if you enter 9930, the time will display as 99:30.

The console allows you to program a wait time for either the upfade or the downfade; not both. You can see which type of wait you have in the Wait field of the Attribute Bar. If an upwait, a small up arrow (\uparrow) is shown next to the time. If a downwait, a down arrow (\downarrow)is shown instead. If you do not enter a wait time, the console assigns the cue a wait time of zero.

Follow these steps to change the upfade and/or downfade wait time.

Ке	ystrokes:	Action:
1.	Press [Stage] or [Blind].	Selects display mode
2.	Press [Cue].	Prompt reads: Select cue number To select cue type, press TYPE
3.	Press [5]	Selects cue 5
4.	Press [Wait] once or Press [Wait] twice.	Prompt reads: Enter upfade wait time or Enter downfade wait time.
5.	Press [6].	Enters a wait time of six seconds Corner reads: UpWait 6 or DnWait 6
6.	Press [Enter].	Records cue 5 with wait time of six seconds

Recording cues with Link and Follow

When you record a cue, it automatically becomes part of the Cue List. The Cue List is a list of all cues, organized in numeric sequence. Normally, when you press [Go] to execute cues, the console plays them back in the sequence in which they appear in the Cue List. [Link] allows you to modify the sequence in which cues play back. [Follow] allows you to play back multiple cues automatically.

Link

[Link] allows you to play back cues out of sequence by linking them together. If you link cue 10 to cue 1, then cue 10 follows cue 1.

Follow these steps to record a linked cue.⁴⁶

Ке	ystrokes:	Action:		
1.	Press [Stage] or [Blind].	Selects display mode		
2.	[Cue] [1].	Selects cue 1		
3.	Press [Link].	Prompt reads: To link to cue, select cue number To link to macro, press ENTER MACRO		
4.	Press [1][0] [Enter]. ^a	Links cue 10 to cue 1. After you play cue 1, press [Go] to playback cue 10		

a. Press [Clear] in this step to remove an existing link.

^{46.} You can also link macros to cues. For more information, see Linking a macro to a cue, page 91.

Follow

[Follow] allows you to play a series of cues automatically. The [Follow] time indicates how long the console waits after the cue starts before the next cue runs. [Follow] plays back the next cue on the Cue List unless you use [Link] to specify a different sequence.

Follow times may be expressed in minutes and seconds, or as fractions of seconds, up to 99:59 minutes.

Action:

Follow these steps to record a cue with [Follow].

Keystrokes:

1.	Press [Stage] or [Blind].	Selects display mode
2.	Press [Cue] [7].	Selects cue 7 Prompt reads: Select cue number To select cue type, press TYPE
3.	Press [Follow].	Prompt reads: Enter follow time (or press ENTER to confirm default time (Press CLEAR to cancel follow time)
4.	Press [5] [Enter]. ^a	Records cue 7 with a Follow time of five seconds. After you start cue 7, the next cue in the Cue List plays automatically five seconds later

a. Press [Clear] in this step to remove an existing follow time.

Create playback loops with Link and Follow

You can use Link and Follow to create cue playback loops in which a group of cues play back automatically and repeat. $^{\rm 47}$

Stop a loop that was created by Link and Follow by pressing GO after the loop has played through at least one time. If you press GO before the loop plays through, you will only advance to the next cue in the loop sequence. If you press GO after it plays through at least one time, you temporarily override the Link sequence and advance instead to a non-loop cue. The non-loop cue that would play is the next one in order after the linked cue. For example, if cue 6 is linked to cue 10 in a loop, the non-loop cue played when you stop the loop would be cue 7.

Follow these steps to create a five-cue loop:

[Enter].

Ke	ystrokes:	Action:
1.	Create five cues numbered 1, 2, 3, 4, and 5.	Cue list displays cues 1 through 5
2.	Press [Cue], then press [1], the number of the first cue you want to include in the playback loop.	Selects the first cue
3.	Press [Follow] [5] [Enter].	Assigns a follow time of five seconds to the first cue
4.	Repeat steps 2 and 3 for cues 2 through 5.	Assigns a follow time of five seconds to the remaining cues
5.	Press [Cue], then press [5], the number of the last cue in the playback loop.	Selects the last cue in the playback loop
6.	Press [Link], then press [1], the number of the first cue in the playback loop. Press	Creates a loop by linking the last cue to the first cue

^{47.} You may also use effects to create loops. See Chapter 16 Effects for more information.

Linking a macro to a cue

[Link] allows you to automatically run a macro when a cue runs. If you link macro 6 to cue 1, then macro 6 runs when you play cue 1. If you want the macro to delay before running, one way is to start the macro with a Macro Wait of the desired length.⁴⁸ You can also delay the macro by assigning a follow time to the cue.⁴⁹

Follow these steps to link a macro to a cue:

Action: **Keystrokes**: 1. Press [Stage] or [Blind]. Selects display mode 2. [Cue] [1]. Selects cue 1 3. Press [Link]. Prompt reads: To link to cue, select cue number To link to macro, press ENTER MACRO Prompt reads: 4. Press [Enter Macro]. To link to macro, select macro number To link to cue, press CUE Records macro 7 linked to cue 1. 5. Press [7] [Enter]. When you press [Go] to play cue 1,

macro 7 will run at the same time

^{48.} See Chapter 18 Macros for information about creating macros.

^{49.} See Recording cues with Link and Follow, page 88.

Recording a cue using Solo

Solo is useful for setting existing channels to zero temporarily while you view or record selected channels. You can use Solo in Blind or Stage. When used in Stage, you can use solo to cut all lights except those selected, thus using it to identify specific lights. Or, you can use Solo a different way to cut all channels except those selected, which is a way of filtering channels for recording. Both procedures are given below.

Using Solo to record selected lights

In the Stage procedure below, all but selected lights are cleared the first time you press Solo. They are restored as before when you press Solo a second time (Stage only). This use of Solo will not NOT clear independent channels, such as those controlling most moving light attributes. It will, however, clear the intensity channel of a moving light fixture.

Ke	ystrokes:	Action:		
1.	Press [Stage].	Selects the Stage display mode		
2.	Press [Cue] [1][0] [Go].	Plays cue 10 in a fader pair to set a look on stage		
3.	Press [2][0] [Thru] [3][0].	Selects channels 20 through 30		
4.	Press [S7], More Softkeys , until [S3] reads Solo .			
5.	Press [S3], Solo .	Sets all channels other than 20 through 30 to zero Prompt reads: To clear all channel levels, press SOLO		
6.	Press [2][0] [Thru] [3][0] [Full].	Selects channels 20 through 30 and sets them to full		
7.	Press [Record] [Cue] [7] [Enter].	Records channels 20 through 30 into cue 7		
8.	Press [S3], Solo .	Restores the channels that were cleared by Solo		

Using Solo as a pre-recording filter

The following procedure, which has an equivalent in Blind, uses Solo to restrict the recording to selected channels, clearing all others whether independent or not. Stage levels are unaffected by this procedure.

Keystrokes:

1. Press [Stage].

[3][0] [Full].

[Solo].

2. Press [Cue] [1][0] [Go].

3. Press [Chan] [2][0] [Thru]

4. Press [Record] [Cue] [7]

Action:

Selects the Stage display mode

Plays cue 10 in a fader pair to set a look on stage

Selects channels 20 through 30 and sets them to full

Records selected channels into cue 7

Chapter 7 Cues

Labeling cues

If you have Expression Off-Line, you may assign labels to your cues.⁵⁰ Labels can consist of any combination of letters, numbers and symbols and may be up to 16 characters long.

Follow these steps to label a cue:

Keystrokes:

Keystrokes:		Action:
1.	Press [Stage] or [Blind].	Selects display mode
2.	Press [Cue] [1][2] [Label]. ^a	Selects Cue 12 Prompt reads: Type cue label (F6 = clear to end, F7 = last cue label, F8 = next cue label)
-		

- 3. Use the alphanumeric Enters cue label Corner reads: Label Toad exits keyboard to type the desired label. For example, call cue 12 "Toad exits."
- Records Cue 12 with label "Toad exits" 4. Press [Enter].^b
 - a. The Label key is not available on the Express console. You may type keyboard equivalent "B" in Expression Off-Line as a substitute for the Label key.
 - b. If the cue did not previously exist, press [Record] [Enter] in step 4. This will create the cue and label, all in one step.

^{50.} For information about Expression Off-Line and how to order it, see Expression Off-Line, page 312.

Modifying a recorded cue live

Previous examples in this chapter illustrated how to record new cues. If you want to modify channels in a recorded cue, you can play back the cue in Stage, make the changes, and then re-record the cue.⁵¹ The modifications immediately affect the look on stage. You can also record the live look you created to another cue.

Modifying channels in a cue

Add new channels or modify channel levels with the procedure given below. You can use all the same techniques for channel or fixture selection or for setting levels that are available to you for initial cue recording.

Keystrokes:		Action:
1.	Press [Stage].	Selects Stage display mode
2.	Press [Cue], enter cue number and press [Go].	Plays back selected cue
3.	Select channels and set channel levels to make the desired changes to the cue.	Selects channels, which can be the same as those already in the cue of additional ones, and set levels
4.	Press [Record] [Enter]. ^a	Re-records cue with desired modifications

a. Insert a different cue number between [Record] and [Enter] in this step to record the look to another cue. When you record to another cue, the modifications are not reflected in the fader. If you don't want to lose the look from stage, run the cue through a fader before you release channels.

^{51.} If you are not familiar with procedures for playing back cues, see Chapter 10 Playing back cues, page 119.
Modifying cue attributes

If all you want to do is modify a cue attribute, such as cue timing, you can do that in Stage without first playing back the cue. Use the procedure below to modify cue attributes.

Keystrokes: Action: 1. Press [Stage] or [Blind]. Selects display mode Selects the desired cue 2. Press [Cue] then enter the number of the desired cue. 3. Press the key that corresponds to the attribute you want to modify. Options include: Type, Time, Wait, Link and Follow. 4. Enter the new setting for Modifies cue attribute the attribute. Re-records cue with modifications 5. Press [Enter].^a

a. Note that if you change the cue's type, press [Record] [Enter] in step 5. Type changes will not take effect unless recorded.

Updating cues

Update allows you to modify previously recorded cues, groups, submasters or focus points in Stage. Update takes levels from all captured and selected channels, and those selected may be restricted with the Only command. 52

Updating an active cue

The following procedure illustrates how to update a cue that has been played back.

Action: **Keystrokes:** Selects Stage display mode 1. Press [Stage]. Plays back selected cue, bringing up 2. Press [Cue], enter cue its current levels number and press [Go]. 3. Modify channel levels as Sets cue levels or selects additional channels and sets their levels desired. 4. Press [S2], Update. Prompt reads: To update cue, select number and press ENTER (TRACK + ENTER for tracking) To cancel, press CLEAR 5. To restrict channels in the Selects channels to update Prompt reads: update, use Only here.^a Select channel numbers To cancel, press CLEAR Updates the active cue 6. Press [Enter].^b

- a. Optional step.
- b. If you want the update to track into subsequent cues, press [Track] before pressing enter.

^{52.} For an explanation of captured channels, see Channel modes, page 52. For an explanation of Only, see The Only command, page 8.

Updating a recorded cue

You need not play back the cue to update it. The following procedure illustrates how to update any recorded cue.

Ke	ystrokes:	Action:			
1.	Press [Stage].	Selects Stage display mode			
2.	Press [S8], Fixture , [1] [Thru] [8], [Full].	Selects fixtures 1 through 8 and sets their intensities to full			
3.	Set the pan and tilt levels. ^a	Sets the levels of the position attributes for all selected fixtures			
4.	Press [S2], Update , [3].	Selects cue 3 to update Prompt reads: To update cue, select number and press ENTER (TRACK + ENTER for tracking) To cancel, press CLEAR			
5.	Press [Only] [S8], Fixture , [6] and [7]. ⁶	Restricts the update to fixtures 6 and 7 Prompt reads: Select fixture number(s) To cancel, press CLEAR			
6.	Press [Enter]. ^c	Updates cue 3			
	a. Use your trackpad.				

- b. Optional step. If you don't use Only, all non-zero channels are included in the update.
- c. If you want the update to track into subsequent cues, press [Track] before pressing enter.

Using Update to modify fade rate

You may also use the Update function to record manually modified fade rates into cues.

Follow these steps to update a rate for a cue running in a fader:

Keystrokes:		Action:		
1.	Press [Rate] key for the fader in which the cue is running.	Activates rate control		
2.	Move rate wheel to adjust fade rate.	Fades are placed under control of the rate wheel. The Fader Status window shows the current rate		
3.	Press [S2], Update .	Prompt reads: To update cue, select number and press ENTER (TRACK + ENTER for tracking) (Press ONLY + ENTER to update only those channels already in cue)		
4.	Press [Enter].	New rate is recorded into cue		

Deleting cues

You can delete a cue in either Blind or Stage. Follow the procedure below to delete a cue in Blind. Follow the same procedure in Stage except press [S7], **More Softkeys**, after pressing [Stage] to display the **Delete** key as softkey [S6].

Ke	ystrokes:	Action:			
1.	Press [Blind].	Selects Blind mode			
2.	Press [S6], Delete Cue .	Prompt reads: To Delete cue, press ENTER - Delete cue and tracking, press TRACK + ENTER To cancel, press CLEAR			
3.	Enter number of cue to delete. ^a	Selects cue to delete			
4.	Press [Enter]. ^b	Prompt reads: To confirm, press ENTER To cancel, press CLEAR			
5.	Press [Enter].	Deletes cue			
	a. Optional if deleting the cu	urrently selected cue.			

b. To delete the cue and any channels that track, press [Track] before [Enter]. For more information on tracking, see Chapter 8 Track.

Copying cues

You may want to use a cue's channel levels as the foundation for a new cue, group or submaster.⁵³ Use the following procedure to perform a copy operation. This copy may be performed either in Blind or in Stage.

To copy a cue to another cue in Stage, follow the procedure below. If copying in Blind rather than in Stage, omit step 3 from this procedure.

Keystrokes:

Actions:

- Press [Stage].
 Press [Cue] [1].
 Prompt reads: Select cue number To select cue type, press TYPE
- 3. Press [Go].
- Press [Record].
 Prompt reads: **To record cue, select number and press ENTER To cancel, press CLEAR**
 Press [2].^a
 Corner reads: **Cue 2**
 Press [Enter].
 Cue copy is complete. Channel levels have been copied from cue 1 to cue 2. You can now modify the new cue
 - a. Press [Sub] or [Group] before the number in step 5 if you want to copy a look from a cue to a submaster or a group.

^{53.} You cannot copy an effect cue to a group.

Inserting cues

You may want to insert a cue between recorded cues. For example, you may want to modify cue 1 slightly and insert it between cues 1 and 2. You can number cues with a one-digit decimal. Therefore, you can insert up to nine cues between 1 and 2 (1.1, 1.2, etc.).

Follow these steps to insert a cue between existing cues:

		1	5			
Keystrokes:			Action:			
	1.	Press [Blind] or [Stage].	Selects display mode			
	2.	Press [Cue] and enter the number of the cue to modify, then press [Enter].	Selects the desired cue			
	3.	If you are working in Stage mode, press [Go].	Brings up cue on stage and on the display			
	4.	Add or modify channels and cue attributes.	Cue is modified			
	5.	Press [Record].	Prompt reads: To record cue, select number and press ENTER To cancel, press CLEAR			
	6.	Enter cue number with a decimal to insert it between cues (e.g., [1][.][5]). If you do not enter a new cue number, you will overwrite the existing cue.	Corner reads: Cue 1.5			
	7.	Press [Enter].	New cue 1.5 is recorded between			

New cue 1 is recorded between cues 1 and 2

Chapter 8 Track

Track record function

Track record is a way of recording new cues or modifying existing ones when you want certain channels or channel levels to continue unchanged in playback from cue to cue. Levels recorded into a tracked cue continue unchanged in subsequent cues until a new level is encountered. Track record gives you the power to modify a range of cues automatically by changing just the first in the sequence.⁵⁴ You can also use track record for new cue recording to pull levels from the previous cue into the new cue.

^{54.} **WARNING**: This procedure although automatic can be time-consuming. Attempting it while running a show could have serious consequences.

Track record

When you record a series of cues, you typically record the first cue, then build the second cue from the first. Some of the channels change, but many remain the same. The third cue is built from the second and so on. This procedure results in many channels being set to a level in one cue and staying at that level for several cues.

A channel whose level does not change through a series of consecutive cues is said to "track" from cue to cue. That same sequence of unchanged levels is also referred to as a "track." The [Track] key in Blind tracks into the new cue by pulling channel levels from the previous cue. In Stage or Blind, the [Track] key adds tracks to subsequent cues.

The following examples demonstrate how Track works. They include five cues, each with five channels. In these examples, when a channel changes level from one cue to the next it is printed in **bold**; tracked channels are printed normally. This corresponds to how Blind displays levels – channels that rise or fall are displayed in blue or green; tracked channels are displayed in purple.

Using record to create tracks

Use the following keystrokes in Stage to create the five cues illustrated below (see *Recording a cue in Stage, page 83*). Each cue adds channels to the previous cue.

Cue 1	[1] [Full] [Record] [1] [Enter]
Cue 2	[2] [Full] [Record] [2] [Enter]
Cue 3	[3] [Full] [Record] [3] [Enter]
Cue 4	[1] [At] [2][5] [4] [Full] [Record] [4] [Enter]
Cue 5	[1] [Thru] [4] [At] [0][0] [Record] [5] [Enter]

These keystrokes produce the results shown in the following illustration. Notice the channel tracks that develop as a channel remains at the same level through a number of cues. For example, channel 1 tracks from cue 1 to cue 3.55

	Chan 1	Chan 2	Chan 3	Chan 4	Chan 5	
Cue 1	FF					
Cue 2	FF	FF				
Cue 3	FF	FF	FF			
Cue 4	25	FF	FF	FF		
Cue 5	00	00	00	00		

^{55.} When a channel is not set at any level (such as channel 5 above) it is considered tracked at clear.

Recording modified cues

The difference between Record and Track is apparent when you modify a cue or insert a new cue between two existing cues. Record and Track produce different results.

Using Record

The following keys were pressed to release captured channels and play back cue 1.

Ke	ystrokes:	Actions:			
1.	Press [Stage] [Rel] [Rel].	Releases captured channels Prompt reads: Select channel numbers			
2.	Press [Cue] [1] [Go].	Plays back cue 1			
3.	Press [1] [At] [5][0].	Modifies channel 1			
4.	Press [Record].	Prompt reads: To record cue, select number and press ENTER To cancel, press CLEAR			
5.	Press [Enter].	Records cue 1			

With cue 1 in a fader, channel 1 is modified to 50 percent. Because cue 1 is re-recorded with [Record], none of the subsequent cues are affected by the procedure.

Following is an illustration of the use of [Record] when modifying cue 1. Note that channel 1 is not affected in cues 2 and 3. Also note that when you record a modified cue that is in a playback fader, the changes are reflected in the fader. That is, when you release the channels you have modified, they remain on stage.

	Chan 1	Chan 2	Chan 3	Chan 4	Chan 5
Cue 1	50				
Cue 2	FF	FF			
Cue 3	FF	FF	FF		
Cue 4	25	FF	FF	FF	
Cue 5	00	00	00	00	

Using Track

If you have tracked channels (all with the same level), you can make them track at a different level. Also, you can track channels at a focus point, but you cannot track through a channel set at a focus point. To illustrate, suppose you have tracked channels as shown in the example under *Using record to create tracks, page 102*. In that example, channel 1 is tracked at full through cues 1-3. Change the tracked level of channel 1 in those cues with the following procedure:

Ke	ystrokes:	Actions:			
1.	Press [Stage] [Rel] [Rel].	Releases captured channels Prompt reads: Select channel numbers			
2.	Press [Cue] [1] [Go].	Plays back cue 1			
3.	Press [1] [At] [5][0].	Modifies channel 1			
4.	Press [Track].	Prompt reads: To record cue & tracking, select number and press ENTER To cancel, press CLEAR			
5.	Press [Enter].	Re-records cue 1 and tracks channel 1 into subsequent cues			

The results of using Track rather than Record are illustrated below. The modified level is recorded in the current cue and carries through cues 2 and 3 until stopped at cue 4, where the level is different.

	Chan 1	Chan 2	Chan 3	Chan 4	Chan 5
Cue 1	50				
Cue 2	50	FF			
Cue 3	50	FF	FF		
Cue 4	25	FF	FF	FF	
Cue 5	00	00	00	00	

Inserting cues

If you insert a cue in this sequence, Record and Track produce different results. Record saves changes only in the cue you insert while Track saves the changes you make and tracks them through the following cues.

The example given below is in Stage. You can get the same results in Blind but with the additional advantage that you can pull channels from the immediately previous cue. An illustration of pulling channels when inserting a cue is given after the comparison between Record and Track in Stage.

Using Record

The following keys were pressed to release captured channels and play back cue 1. With cue 1 in a fader, channel 4 is added at 50 percent. The new look is inserted as cue 1.1.

Ке	ystrokes:	Actions:			
1.	Press [Stage] [Rel] [Rel].	Releases captured channels Prompt reads: Select channel numbers			
2.	Press [Cue] [1] [Go].	Plays back cue 1			
3.	Press [4] [At] [5][0].	Modifies channel 4			
4.	Press [Record].	Prompt reads: To record cue, select number and press ENTER To cancel, press CLEAR			
5.	Press [1][.][1] [Enter].	Records cue 1.1			

The following diagram illustrates what happens when you insert cue 1.1 using [Record]. Note that the channel in cue 1.1 is not added to the cues that follow it. In fact, that channel is faded out when cue 2 is played.

	Chan 1	Chan 2	Chan 3	Chan 4	Chan 5
Cue 1	50				
Cue 1.1	50			50	
Cue 2	50	FF		00	
Cue 3	50	FF	FF		
Cue 4	25	FF	FF	FF	
Cue 5	00	00	00	00	

Using Track

When you insert a cue with Track, new channels track through the following cues until the console encounters a cue with a level previously recorded for that channel.

The following procedure illustrates this use of Track, and the following illustration shows what results. Note that the channel in the new cue is tracked into subsequent cues until a pre-recorded level stops it.

Ke	ystrokes:	Actions:
1.	Press [Stage] [Rel] [Rel].	Releases captured channels Prompt reads: Select channel numbers
2.	Press [Cue] [1] [Go].	Plays back cue 1
3.	Press [4] [At] [5][0].	Modifies channel 4
4.	Press [Track].	Prompt reads: To record cue & tracking, select number and press ENTER To cancel, press CLEAR
5.	Press [1][.][1] [Enter].	Records cue 1.1 and tracks for channel 4 through subsequent cues

	Chan 1	Chan 2	Chan 3	Chan 4	Chan 5
Cue 1	50				
Cue 1.1	50			50	
Cue 2	50	FF		50	
Cue 3	50	FF	FF	50	
Cue 4	25	FF	FF	FF	
Cue 5	00	00	00	00	

Pulling channels in Blind

If you insert in Blind using [Track], you can get a start on a new cue by using levels already defined in the previous cue. You can then add channels or modify levels in the new cue. From that point on, you can use either [Record] or [Track] analogously to the procedures explained above, depending upon whether or not you want the channels in the inserted cue to track into subsequent cues.

Press the following keys to insert cue 2.5 in Blind by pulling in levels from previous cue 2.0 and adding channel 5 at 70 percent. Note that the new cue in this example will track into subsequent cues as well because of the second use of [Track] in step 5.

Ke	eystrokes:	Actions:
1.	Press [Blind] [2][.][5].	Displays empty cue 2.5 Prompt reads: Select cue number To select cue type, press TYPE
2.	Press [Track] [Enter].	Pulls in previous cue's channels
3.	Press [Channel] [5] [At] [5][0].	Adds channel 5 at 50 percent Prompt reads: Select channel numbers
4.	Press [Track].	Prompt reads: To record cue & tracking, select number and press ENTER To cancel, press CLEAR
5.	Press [Enter].	Records cue 2.5

The following illustration shows this insertion and subsequent tracking.

	Chan 1	Chan 2	Chan 3	Chan 4	Chan 5	
Cue 1	50					
Cue 2	50	FF		00		
Cue 2.5	50	FF		00	70	
Cue 3	50	FF	FF		70	
Cue 4	25	FF	FF	FF	70	
Cue 5	00	00	00	00	70	

Blackout cues and tracking

Sometimes you may add a channel to a sequence of cues that have not used that channel yet. For example, you may want to add a channel to all cues in a scene. To do this, add the channel to the first cue in the sequence and use Track to track the change through the remaining cues.

However, the last cue in sequence may be a blackout cue. When you track the channel, the new channel tracks until it runs into a different recorded level. To ensure that channels are not tracked through a blackout cue, make the blackout cue an allfade cue. An allfade cue assigns a level of zero to any unused channels. This blocks any potential tracks. An allfade cue also clears the opposite fader.

Figure 6 displays what happens when we track channel 5 through the sequence when cue 5 is a regular crossfade cue.

	Chan 1	Chan 2	Chan 3	Chan 4	Chan 5	
Cue 1	50				FF	
Cue 1.1	50			50	FF	
Cue 2	50	FF		00	FF	
Cue 3	50	FF	FF		FF	
Cue 4	25	FF	FF	FF	FF	
Cue 5	00	00	00	00	FF	

Figure 6

Channel 5 tracks through cue 5 and ruins the blackout cue.

If cue 5 is an allfade, the console records all unused channels at 00 percent. In the example below, an allfade enters 00 in channel 5, cue 5. When you track channel 5 through the sequence, it won't track through the blackout cue.

To select the allfade type for cue 5, enter these keystrokes:

[Blind] [5] [Type] [2]Selects allfade fade type. [Record] [Enter]Re-records cue.

Now when we track channel 5 through the sequence, cue 5 blocks the track. The result is illustrated in Figure 7.

	Chan 1	Chan 2	Chan 3	Chan 4	Chan 5	
Cue 1	50				FF	
Cue 1.1	50			50	FF	
Cue 2	50	FF		00	FF	
Cue 3	50	FF	FF		FF	
Cue 4	25	FF	FF	FF	FF	
Cue 5	00	00	00	00	00	

Figure 7

For more information on cue fade types, see Cue types, page 80.

Chapter 9 Multipart cues

A multipart cue consists of up to eight parts, each of which is essentially an independent cue with its own channel levels and timing information. You may set the upfade, downfade and wait times for each part of a multipart cue. Create a cue as a multipart cue or record it first as a standard, one-part cue and then split it later into parts.

Each part of a multipart cue may consist of any number of channels, but a channel may only be included in one part of a multipart cue. If you record a channel in a part and that channel is already included in another part, the channel will be placed in the new part and be removed from the older part automatically.

Wait times in multipart cues allow you to program fades that do not start immediately when you play the multipart cue. When you press [Go] to start a multipart cue, some parts may start immediately and others may start up to 99:59 minutes later, depending on the assigned wait time. The total duration of a multipart cue is equal to the combined wait and fade times of the longest part.

When you display a multipart cue, channel levels that are higher than they were in the previous cue are displayed in blue; channel levels that are lower than they were in the previous cue are displayed in green; and channel levels that are unchanged from the levels in the previous cue are displayed in purple. When a part is selected, channel colors remain the same in that part but channels in other parts are grayed.

Multipart cues can be recorded in either Stage or Blind mode. They are stored like normal cues in the console's memory and on disk.

This chapter includes the following sections:

- Recording a multipart cue
- Converting a standard cue to a multipart cue
- Wait times in multipart cues
- Editing a multipart cue

Recording a multipart cue

In the procedure below, one or more parts are recorded to a cue. The maximum number of parts you may record to a cue is eight. Follow, Link and Label attributes may be assigned to the overall cue.

Ke	ystrokes:	Action:
1.	Press [Stage].	Selects Stage display mode
2.	Press [S7], More Softkeys , until Part appears as softkey [S1].	Finds the Part softkey
3.	Select channels, enter channel levels and press [Enter].	Prompt reads: Select channel numbers
4.	Press [Record].	Prompt reads: To record cue, select number and press ENTER To cancel, press CLEAR
5.	Enter the cue's number followed by [Enter]. ^a	
6.	Press [S1], Part .	Indicates the selected cue us a multipart cue Prompt reads: Select part number to record To cancel, press CLEAR
7.	Enter the number of the part you want to record, followed by [Enter]. ^b	Records the part Prompt reads: Select channel numbers
8.	Press [Rel] [Rel].	Releases captured channels
9.	Repeat steps 2 through 8, adding channels for each part you want to include in the multipart cue.	Records subsequent parts.
	a If recording several parts	to the same multipart que you do

- a. If recording several parts to the same multipart cue, you do not need to enter the cue number for subsequent parts after recording the first part.
- b. You may select any part number in the range 1-8, regardless of previous parts recorded for this cue.

Converting a standard cue to a multipart cue

If you have already created a single-part cue, the console allows you to reconfigure it as a multipart cue. You can convert a standard cue to a multipart cue in either Stage or Blind mode, but it's easier in Blind because levels are highlighted.

Once you create the first part, all channels not assigned to that part are automatically assigned to part 8. As you create additional parts from channels in part 8, they are deleted from part 8 and added to the selected part.

Follow these steps to convert cue 1, assumed to be a standard cue, to a multipart cue. This example is in Blind.To perform the equivalent procedure in Stage, run the cue in the faders before preceding with step 3.

Action: **Keystrokes**: 1. Press [Blind]. Selects [Blind] display Selects cue 1 2. Press [Cue] [1]. 3. Press [Channel] and select the channels for a part.^a 4. Press [S7], More Finds the Part softkey Softkeys, until Part appears as softkey [S1]. 5. Press [S1], Part, followed Creates the designated part. by the part's number and then [Enter]. Creates more parts for this cue. 6. Repeat steps 3-5 to create the other parts, as desired.

a. If in Stage, selection defaults to channels so you do not need to press [Channel].

Wait times in multipart cues

You can set individual wait times of up to 99:59 minutes for each part of a multipart cue. The wait time is the delay between when you press [Go] and when the part begins. If no wait is recorded, all parts run simultaneously when you press [Go].

Follow these steps to assign a wait time to a part:

Keystrokes:

Action:

- 1. Press [Cue], then enter the cue number. Selects cue number Prompt reads: Select cue number
- 2. Press [S7], **More** Finds the Part softkey **Softkeys**, until **Part** appears as softkey [S1].
- 3. Press [S1], **Part**, then
enter the part number.Selects part number
Prompt reads:
- 4. Press [Wait] [1][0].

Prompt reads: Select part number

Selects wait time of ten seconds Prompt reads: Enter wait time

Enter wait time

5. Press [Enter]. Sets wait time for the part to ten seconds. Part will wait ten seconds, then run

Editing a multipart cue

Once you have created a multipart cue, you can add or delete parts, add or delete channels from the parts, change channel levels, or change fade and wait times. Except for Update, all multipart cue editing is done in Blind.

Deleting a part from a multipart cue

Deleting a part from a multipart cue is the reverse of creating a multipart cue from a standard cue. When a part is deleted, the channels in the deleted part do not leave the cue but transfer to part 8, where they can be reassigned if desired. Channel levels are unaffected.

Follow these steps to delete part 1 from a multipart cue in Blind:

Кеу	vstrokes:	Action:
1.	Press [Blind].	Selects Blind display mode
2.	Press [Cue] [4].	Selects the cue
3.	Press [S7], More Softkeys , until Part appears as softkey [S1].	Finds the Part softkey
4.	Press [S1], Part, [1].	Selects the part
5.	Press [S6], Delete Part .	Prompt reads: To delete part, press ENTER – Delete part & tracking, press TRACK + ENTER To cancel, press CLEAR
6.	Press [Enter]. ^a	Prompt reads: To confirm, press ENTER To cancel, press CLEAR
7.	Press [Enter].	Deletes part 1 from cue 4

a. If the part to be deleted has tracking channels and you want those tracking channels removed from subsequent cues, press [Track] before [Enter].

Adding, deleting and modifying channels

Follow these steps to edit channels in a multipart cue: Action: **Keystrokes:**

- Selects Blind display mode 1. Press [Blind].
- 2. Enter the cue number. Prompt reads: Select cue number

3. Press [S7], More Softkeys, until Part appears as softkey [S1].

- 4. Press [S1], Part, then press [+] or [-] until the desired part is displayed.
- 5. Press [Channel], and select the desired channels.
- 6. Set channel levels. Press [At] [Clear] to delete the selected channels.
- 7. Press [S7], More Softkeys, until Part appears as softkey [S1].
- 8. Press [Record] [S1], Part, [2] [Enter].

Select part number

Finds the Part softkey

Prompt reads:

To select cue type, press TYPE

Prompt reads: Select channel numbers

If the channels are new, this adds them to the part at the level indicated. If already in the part, this modifies their level

Finds the Part softkey again

Records the changes into part 2 of the cue

Using Update

With Update, you can do live editing of cue parts in Stage and see the results immediately on stage. Use the procedure below to add channels and set levels, assuming you previously created multipart cue 1.

Ke	ystrokes:	Action:
1.	Press [Stage]	Selects stage display
2.	Press [S8], Fixture , [4]	Selects fixture 4
3.	Set intensity, pan and tilt levels.	
4.	Press [S2], Update .	Prompt reads: To update cue, select number and press ENTER (TRACK + ENTER for tracking) To cancel, press CLEAR
5.	Press [Cue] [1].	Selects multipart cue 1 to update
6.	Press [S7], More Softkeys , until Part appears as softkey [S1].	Finds the Part softkey
7.	Press [S1], Part , [2] [Enter].	Updates part 2 of cue 1

Modifying fade and wait times

If you do not assign fade and wait times to a part, the console assigns default times.⁵⁶ No wait time will be recorded. Follow these steps to assign fade and wait times to parts to a multipart cue:

Action: **Keystrokes**: Selects Blind display mode 1. Press [Blind]. 2. Enter the cue number. Prompt reads: Select cue number To select cue type, press TYPE Finds the Part softkey 3. Press [S7], More Softkeys, until Part appears as softkey [S1]. Prompt reads: 4. Press [S1], Part, then Select part number press [+] or [-] until the part you want to edit is displayed. Prompt reads: 5. Press [Time]. Enter upfade time 6. Enter an upfade time Prompt reads: Enter downfade time between .1 second and 99:59 minutes and press [Enter]. Fade times are set for the part 7. If you want a downfade time that is different from the upfade, enter the desired time and press [Enter]. If not, just press [Enter]. 8. Press [Wait]. Prompt reads: Enter wait time Wait time is set for the part 9. Enter wait time and press

time of zero.

[Enter]. Wait time is the delay between when you press [Go] and when the part begins. If you do not enter a wait time, the console assigns a wait

^{56.} See Setting default fade times, page 24.

Chapter 10 Playing back cues

The console has two timed faders that allow you to play back recorded cues. Cue selection and playback can be automated, or you can control them manually.

This chapter includes the following sections:

- Selecting cues
- Timed faders
- Playback Cue List
- Fader Status display
- Selecting and playing cues
- Go to a different cue
- Controlling fades manually
- Quickstep

Timed faders

The console has two timed fader pairs, called the A/B and C/D fader pairs, that allow you to play back recorded cues (A/B pair illustrated at right). The left slider (A and C) of each fader pair controls upfades. The right slider (B and D) of each fader pair controls downfades. When reference is made in this and other sections of this User Manual to a fader, you should assume that both sliders of the fader pair are implied unless otherwise noted.

You may play back a cue using the timing information programmed into it, or you may take manual control of the slider(s). Taking manual control of faders is covered under *Controlling fades manually, page 125*.

You may play back cues one at a time through the same fader, or you may simultaneously play back a different cue in each fader. For example, you may play a ten-minute sunset cyc cue in one fader and play several cues during the same period in the other fader. You may also play a cue in one fader, leave it there, and then play another cue in the second fader.





The faders function in level override mode. This means that the fader sliders control the percentage of completion of the fade.

Fader keys

Clear

Each fader is equipped with a Clear key. To remove a cue from the fader, press the appropriate Clear key. Clear an effect cue by pressing either once or twice. If the effect cue is in an upfade or dwell time, pressing [Clear] once starts a downfade and pressing [Clear] again ends the downfade in the fader clear time. Pressing [Clear] while an effect is in a downfade ends the downfade in the fader clear time.⁵⁷

Go

Each fader has its own Go key. If you press [Go] before a cue finishes playing, the previous cue stops, and the new cue begins from the levels at which the previous cue was interrupted. Press [Go] to play back the cue selected on the Cue List. Press [Go] to resume a fade that has been interrupted by pressing [Hold].

Hold

Each fader has its own Hold key. If a cue is running, press [Hold] to pause playback of the cue. Press [Hold] a second time to cancel playback of the cue in the fader, leaving it in the fader where it stopped, or press [Go] to resume the fade.

Back

Each fader has its own Back key. Press [Back] to replay the cue most recently played on that fader. Press [Back] again to play the cue before it on the Cue List, and so forth, moving backward through the Cue List. Cues play back using the fade and wait times recorded with the cue.

The cue following the cue replayed by pressing [Back] becomes the first cue in the Cue List. If you then press [Go], that cue plays. Replaying with Back ignores cue links.

This example demonstrates the use of the Go, Hold and Back keys:

Ke	ystrokes:	Action:		
1.	Press [Stage].	Selects Stage mode display		
2.	Press [Cue] [2].	Selects cue 2		
3.	Press [Go].	Runs cue 2		
4.	While cue is running, press [Hold].	Running cue pauses		
5.	Press [Go].	Cue resumes		
6.	Once cue finishes, press [Back].	Previous cue fades up on stage		

^{57.} The default fader clear time is zero, which means that pressing [Clear] ends a downfade immediately. For instructions on changing fader clear time, see Setting default fader clear time, page 25.

Cue List

The Cue List in the Stage and Blind displays, shown below, is a short list of cues in the show. Shown along with cues are cue attributes, such as fade timing, linking and the cue's label, if any.

Cue/Type	Time	Wait	Link	Follow	Rate
101	5				
>103	5				

Cue indicators

The color in which a cue is displayed provides information about the cue's current status.

Gray..... Cue is not selected and is not in a fader.

- White..... Pending cue, will play back next time either Go key is pressed.
- Yellow Cue is in a fader, and is selected in Stage.

Gold.....Cue is in a fader, but is not selected in Stage.

Light red Cue is currently running and is selected in Stage.

Dark red Cue is currently running, but is not selected in Stage.

> Cue is selected in Stage or Blind.

Fader Status display

The fader status display consists of two windows located near the bottom of the Stage and Blind displays. These are illustrated below.



The fader status display provides information about the cues loaded to the console's faders, including fade times and rates. The left window monitors the A/B fader; the right window monitors the C/D fader. The display counts down wait times for cues and indicates which step is running when an effect is active.

Selecting cues

There are many ways that you can determine which cue will play next on stage, including the following.

- You can select a cue from the keypad and press [Go].
- Press [Go] without selecting a cue. The console will play either the next cue in the Cue List or the cue linked to the cue that played last. See *Link, page 88*.
- Run a macro that contains a command to play a particular cue.
- Run a subroutine that contains a list of cues to be played automatically.
- Program a cue with Follow (see *Follow, page 89*). After you run the cue that has been set with a Follow command, the next cue in sequence (or a linked cue) runs automatically.
- Press [Go] while a loop constructed with Link and Follow commands is running. A non-loop cue will be played in accordance with rules explained in *Create playback loops with Link and Follow, page 90*.

You must be in either the Stage or the Fader displays to select cues to play back, but you can run a selected cue from Blind as well as Stage or Fader. You see the cue running on the monitor in the Stage and Fader displays.

Playing a cue

Selecting a cue moves it to the top of the Cue List. It will not run until you press [Go]. Follow these steps to select a cue and play it on the fader of your choice.

Ке	ystrokes:	Action:
1.	Press [Stage].	Selects Stage display mode
2.	Press [Cue].	Prompt reads: Select cue number To select cue type, press TYPE
3.	Press [1][.][5].	Selects cue 1.5 to play. Cue List moves cue 1.5 to the top of the list
4.	Press [Go] on fader A/B.	Cue 1.5 runs on fader A/B; Cue 2 moves to the top of the Cue List
5.	Press [Go] on fader C/D.	Cue 2 starts to run on fader C/D

Go to a different cue

To play back a cue other than the cue highlighted on the Cue List, follow these steps:

Keystrokes:		Action:
1.	Press [Stage].	Selects Stage mode display
2.	Press [Cue] [2].	Selects cue 2
3.	Press [Go].	Runs cue 2

Controlling fades manually

The console provides two ways to take manual control of cue playback; manual override and rate override.

Manual override

Manual override allows you to use the fader sliders to take manual control of fade levels. When you take manual control of cue playback, moving the fader slider controls the fade.

Leave the fader sliders at ${\bf 10}$ before pressing [Go] to play cues back as recorded.

When you move the fader sliders below **10**, the cue runs until it reaches the slider setting. You can set the slider before you play the cue, or move the slider after the fade starts. The fade stops when it reaches the slider's level, and the slider then controls the fade. For example, if you set the sliders at **8**, the cue will play until it reaches 80 percent of its recorded levels, then give you manual control.

Set the sliders at **0** before you press [Go] to take manual control of fade from the beginning of cue.

Hint: If you start a cue, and the performers skip ahead to the next cue, you have two options for speeding up to the next cue. If you do not need the current cue to reach its full intensity level settings, press [Go] to interrupt the current cue and begin the next one. However, if you need the current cue to reach its full level settings, push the sliders down and then back up to **10** immediately. Then press [Go] to start the next cue.

Once the fade is complete, the cue is no longer controlled by the fader.

Rate override

Rate override allows you to control both the fade's rate and percentage of completion. When you play back a cue using rate override, the console controls the percentage of completion, but you control the rate.⁵⁸

Rate override allows you to play back a cue faster or slower than the rate at which it was recorded. The trackpad adjusts the fade rate.

Fade rate is expressed as a percentage. A cue with a fade rate of 100 percent plays back at its recorded fade time. A fade rate of 300 plays the cue back three times faster than its recorded fade time. A fade rate of 50 plays the cue back half as fast as its recorded fade time. For example, if you record a cue with a 10 second fade time, a rate of 200 causes it to play back in five seconds. A fade rate of 50 causes it to play back in 20 seconds.

You may take control of a cue's fade rate while the cue is running. In addition, you may press both [Rate] keys to control rate of both fades.

Action:

Follow this example to place a cue in a fader under rate override:

Keystrokes:

Press [Rate] key for the fader in which the cue is running. (Press both [Rate] keys if you wish to control both faders.) Activates rate control

2. Move your finger over the trackpad. Fades are placed under control of the trackpad. Fader Status window shows the current rate

^{58.} When finished with the manual rate override, you can record the modified fade rate into the cue if you wish. See Using Update to modify fade rate, page 98.

Quickstep

Quickstep allows you to run through a show, checking all cues, without having to wait for fades. When Quickstep is active, the faders ignore all upfade, downfade, follow, and wait times. Cues snap immediately to their completed levels when you press [Go] or [Back].

To enable Quickstep and run a cue check, follow these steps:

Keystrokes:		Action:
1.	Press [Stage].	Selects Stage display
2.	Press [S7], More Softkeys, [S1], Enable Quickstep.	Turns on Quickstep
3.	Press [Cue] [1].	Selects cue 1
4.	Press [Go].	Cue 1 comes up on stage instantly
5.	Continue to press [Go] until you have checked all cues.	Each cue comes up on stage instantly
6.	Once you are finished, press [S1], Disable Quickstep .	Turns off Quickstep; fades will operate normally

Chapter 11 Groups

The console allows you to record frequently used combinations of channels into units called groups. You may record up to 500 groups.

Once you record a group, it can be combined with other channels and groups to create cues, submasters, effects, focus points or other groups. The principal difference between a group and a cue is that a group cannot be played back through a fader or slider. Consequently, it has no fade times, wait times or other playback attributes.

Group numbers, which are independent of cue numbers, are whole numbers in the range of 1 to 999.

This chapter includes the following sections:

- Creating groups
- Working with groups in Blind
- Working with groups in Stage
- Modifying groups
- Labeling groups
- Deleting groups
- Copying groups
- Using cues or submasters as groups
- Using groups to modify cues, groups or submasters

Recording a group in Stage

The following example illustrates the creation of a group using newly selected channels.

Keystrokes:		Action:
1.	Press [Stage].	Selects the Stage display
2.	Press [1] [Thru] [5] [Full] [And] [8] [And] [1][0] [At] [5] [Enter].	Select channels and set levels
3.	Press [Record] [Group].	Prompt reads: To record group, select number and press ENTER
4.	Press [1].	Selects group 1 to record
5.	Press [Enter].	Records group 1

Recording a group from a look on stage

To create a group from the look that's already on stage, follow these steps.

Ke	ystrokes:	Action:
1.	Press [Stage].	Selects Stage display mode
2.	Press [Record] [Group].	Prompt reads: To record group, select number and press ENTER To cancel, press CLEAR
3.	Press [2].	Enters the group number you want to record Corner reads: Group 2
4.	Press [Enter].	Records group 2
Recording a group using Solo

You can use Solo to selectively record into a group in the same manner as using Solo to selectively record into a cue. There are two ways to select channels with Solo: while clearing other independent channels such as other lights and while clearing ALL other channels, including non-independent ones. See *Recording a cue using Solo, page 92*, for the procedures to use, substituting the [Group] key where those procedures specify the [Cue] key.

Working with groups in Blind

There are two modes of operation in Blind for changing groups—Group mode and Group Editing mode. In Group mode, the console brings up the channels from a group of your choice and allows you to use them to modify cues, submasters and other groups. In Group Editing mode, the console allows you to create or edit the group itself.

Group mode

You enter Group mode in Blind by specifying a level after identifying the group. The level is applied proportionally to all channels in the group. Follow the procedure below to work in Group mode.

Action:

Keystrokes:

1.	Press [Blind].	Selects Blind display mode
2.	Press [Group] [1].	Selects group 1's channels Prompt reads: Group mode – To recall a group, select the number and set it to a level To create or modify a group, select the number and press ENTER
3.	Press [At] [7][5].	Sets the channels to 75 percent of their recorded levels Prompt reads: Group mode – Press AT or use wheel or trackpad to alter levels, or select channel numbers to edit
4.	Press [Record] [Cue] [3] [Enter].	Records the current level settings as cue 3

Group Editing mode in Blind

Add or delete channels or change channel levels in a recorded group by first entering Group Editing mode in Blind. You can also set group levels with reference to a focus point. 59

Keystrokes:		Action:
1.	Press [Blind].	Selects Blind display mode
2.	Press [Group] [1].	Selects group 1's channels Prompt reads: Group mode – To recall a group, select the number and set it to a level To create or modify a group, select the number and press ENTER
3.	Press [Enter].	Sets channels to their levels recorded in the group Prompt reads: Select channel numbers
4.	Press [2][5] [Thru] [3][0] [At] [5][0].	Modifies look, adding channels 25 through 30 at 50 percent
5.	Press [Record].	Prompt reads: To record group, select number and press ENTER To cancel, press CLEAR
6.	Press [Enter]. ^a	Records the modified group

a. Specify a number here to record to a different group, such as [5][0] [Enter]. If that group exists, it is overwritten. If it does not exist, it is created.

^{59.} See Setting levels with focus points, page 150.

Working with groups in Stage

Displaying a group

To view a recorded group on stage, follow these steps:

Keystrokes:	Action:
1. Press [Stage].	Selects Stage display mode
2. Press [Group] [2].	Selects group 2 Prompt reads: Group mode – Select group number to use as group
3. Press [Full].	Prompt reads: Group mode – Press AT or use wheel or trackpad to alter levels, or select channel numbers to edit

Modifying a group

Follow the procedure below to modify a recorded group in Stage and then record the modifications into the same group or into a different group.

Keystrokes:		Action:
1.	Display the group on stage as illustrated above.	
2.	Select channels you want to modify and adjust channel levels.	Alters look
3.	Press [Record] [Group].	Prompt reads: To record group, select number and press ENTER To cancel, press CLEAR
4.	Press [Enter]. ^a	Records modifications into the group

a. Record the modifications into a different group by pressing the other group's number before you press [Enter] in this step.

Updating groups

Update allows you to modify previously recorded cues, groups, submasters or focus points in Stage. Update takes levels from all captured and selected channels, and those selected may be restricted with the Only command. 60

Updating an active group

The following procedure illustrates how to update a group that has been placed on stage.

Keystrokes:		Action:
1.	Press [Stage].	Selects Stage display mode
2.	Press [Group] [4] [Full].	Places group 4 on stage at full
3.	Modify channel levels as desired.	Sets group levels or selects additional channels and sets their levels
4.	Press [S2], Update .	Prompt reads: To update cue, select number and press ENTER To cancel, press CLEAR
5.	To restrict channels in the update, use Only here. ^a	Restricts channels in update Prompt reads: Select channel number(s) - To cancel, press CLEAR (Press 0 to reselect all non-zero channels)
6.	Press [Group] [4] [Enter].	Updates group 4

a. If not restricted with Only, all captured and selected channels are included in the update.

^{60.} For an explanation of captured channels, see Channel modes, page 52. For an explanation of Only, see The Only command, page 8.

Updating a recorded group

You need not place a group on stage to update it. The following procedure illustrates how to update any recorded group.

Keystrokes:		Action:
1.	Press [Stage].	Selects Stage display mode
2.	Press [5][0] [Thru] [7][5] [At] [9] [Enter].	Selects channels and sets levels
3.	Press [S2], Update , [Group] [3].	Selects group 3 to update Prompt reads: To update group, select number and press ENTER To cancel, press CLEAR
4.	To restrict channels in the update, use Only here. ^a	Selects channels to update Prompt reads: Select channel numbers - To cancel, press CLEAR (Press 0 to reselect all non-zero channels)
5.	Press [Enter].	Updates group 3

a. If not restricted with Only, all captured and selected channels are included in the update.

Labeling groups

If you have Expression Off-Line, you may assign labels to your groups. ⁶¹ Group labels can consist of any combination of letters, numbers and symbols, and may be up to 16 characters long.

Follow these steps to label a group:

Keystrokes: Action: Selects Blind display mode 1. Press [Blind]. Prompt reads: 2. Press [Group] [1]. Group mode - To recall a group, select the number and set it to a level To create or modify a group, select the number and press ENTER Prompt reads: 3. Press [Enter]. Select channel numbers Prompt reads: 4. Press [Label].^a Type group label (F6 = clear to end)F7 = last group label,F8 = next group label) Corner displays your label 5. Use the alphanumeric keyboard to enter a label.

- 6. Press [Enter]. Group 1 is labeled
 - a. Not available on the Express console. You may type keyboard equivalent "B" in Expression Off-Line as a substitute for the Label key.

^{61.} For information about Expression Off-Line and how to order it, see Expression Off-Line, page 312.

Deleting groups

Delete a group from memory in the Stage, Blind or Fader displays.⁶² Deleting a group has no effect on any cues, groups, submasters or focus points into which the deleted group was previously recorded.

Delete a group in Stage as follows:

Keystrokes:

Actions:

- Press [Stage].
 Press [S7], More Softkeys, [S6], Delete, [Group].
 Press [2].
 Selects Stage display
 Prompt reads: To delete group, press ENTER To cancel, press CLEAR
 Enters group number to delete
- 4. Press [Enter] [Enter]. Group 2 is deleted from your show

Corner reads: Group 2

Copying groups

You may copy a group in Stage or Blind, with small differences in the procedure and prompts that occur. The following procedure illustrates how to copy a group in Stage.

Keystrokes:		Actions:
1.	Press [Stage].	Selects Stage display
2.	Press [Group].	Prompt reads: Group mode – Select group number to use as group
3.	Press [1].	Enters the number of the group you wish to copy Corner reads: Group 1
4.	Press [Full].	Prompt reads: Group mode – Press AT or use wheel or trackpad to alter levels, or select channel numbers to edit
5.	Once the group is displayed, press [Record] [Group]. ^a	Prompt reads: To record group, select number and press ENTER To cancel, press CLEAR
6.	Press [5] [Enter].	Enters the number of the new group and completes the Copy. Corner reads: Group 5
	a To conv a group's ch	pappals and lovals to a sup or a

a. To copy a group's channels and levels to a cue or a submaster, press [Cue] or [Sub] in place of [Group] in step 5.

^{62.} You can delete all groups at once with the Clear Groups option from the Clear Functions menu. See Clear and reset options, page 255.

Using cues and submasters as groups

You may treat channels recorded in a cue or submaster as if they were in a group, such as to bring them up in Stage or record them into other cues or submasters. 63

For example, follow this procedure to bring up a cue in Stage as a group:

Keystrokes:

Actions:

- 1. Press [Stage]. Selects Stage display mode 2. Press [Group]. Tells the console to treat the next entry as a group Prompt reads: Group mode - Select group number to use as group 3. Press [Cue] and enter the Prompt reads: number of the cue you Group mode - Select cue number to want to bring up.^a use as group 4. Press [At] and enter the The cue's channels are brought up on level at which you wish to stage at the specified level bring up the cue. (Or press Prompt reads: [Full]) **Group mode – Enter intensity**
 - a. To use a submaster as a group, follow the same procedure, but press [Sub] instead of [Cue] in step 3.

^{63.} You may not use this procedure to group the channels in a cue part, an effect cue or an effect submaster.

Modifying cues or submasters

You can use groups to modify cues or submasters. In the illustration below, a submaster is modified by a group. If any of this group's channels are already in the submaster, the levels of those channels are modified to match the levels in the group. If the group has channels not already in the submaster, those are added to the submaster.

Keystrokes:

Action:

1. Press [Blind]. Selects Blind display mode 2. Press [Sub] [2]. Prompt reads: Select submaster number To select submaster type, press TYPE 3. Press [Group] [3]. Selects group 3's channels Prompt reads: Group mode -To recall a group, select the number and set to a level To create or modify a group, select the number and press ENTER 4. Press [At] [5][0]. Group's channels are set proportionally to 50% Prompt reads: Group mode – Enter intensity 5. Press [Record]. Prompt reads: To record submaster, press BUMP or select number and press ENTER To cancel, press clear 6. Press [Enter] to re-record Records submaster 2 as modified by the modified submaster. group 3's channels

Chapter 12 Focus points

When working with moving lights, sometimes the attributes of several lights are stored together in a group and the group recorded into one or more cues. If the group changes, such as if the lights are repositioned toward another point on stage, the cues need to be manually updated or replaced to account for that change.

Focus points can be used to provide automatic updating in situations like this and others, such as when colors are changed after show programming is essentially complete. Channels referencing focus points that store color information automatically update when the color channels in the focus point change. If many references are made to these focus points in the show, all will change when the focus point changes, making widespread updating a convenient operation.

The console allows up to 99 user-definable focus points.

The topics covered in this chapter include:

- Creating focus points
- Displaying focus points on Stage
- Working with focus points in Stage
- Editing focus points in Blind
- Labeling focus points
- Deleting focus points
- Copying focus points
- Setting levels with focus points

Recording a focus point

You can create a focus point in Stage, Blind or Fader displays using all the same techniques available to create groups.

Recording a focus point in Stage

The following example illustrates the creation of a focus point containing settings for the intensity and position attributes of several fixtures. Note the use of Only to conveniently identify the position category.

Key	strokes:	Action:
1. F	Press [Stage].	Selects the Stage display
2. P	Press [S8], Fixture , [1].	Selects fixture 1
3. S I€	Set intensity, pan and tilt evels.	
4. F s	Press [+], [–] or [S8] to elect another fixture.	
5. F	Repeat steps 3-4.	Repeat procedure for all fixtures to be included in the focus point
6. F P	Press [Record] [Focus Point].	
7. F	Press [3].	Enters number of focus point
8. F	Press [Enter].	Records focus point 3

Creating a focus point from a look on stage

To create a focus point from the look that is already on stage, follow these steps:

Keystrokes:		Action:
1.	Press [Stage].	Selects Stage display mode
2.	Press [Record] [Focus Point].	Prompt reads: To record focus point, select number and press ENTER To cancel, press CLEAR
3.	Press [2].	Enters the focus point number you want to record Corner reads: Focus 2
4.	Press [Enter].	Records focus point 2

Recording a focus point using Solo

You can use Solo to selectively record into a focus point in the same manner as using Solo to selectively record into a cue or group. There are two ways to select channels with Solo: while clearing other independent channels such as other lights and while clearing ALL other channels, including non-independent ones. See *Recording a cue using Solo, page* 92, for examples of these two procedures. When using those procedures to record channels into a focus point rather than into a cue, press the [Focus Point] key where they call for pressing the [Cue] key.

When working with focus points, you are more likely to record selected attribute settings for moving lights than the intensities of ordinary fixtures. For example, you might use a focus point to store the pan and tilt settings for several lights aimed at a particular location on stage. Or, you might want to store the settings of colors for those moving lights so that you can use them later when recording cues, groups or submasters.

Remembering that all attributes but the intensity of moving lights are independent, only the Solo procedure that can clear either of these allows you to select out moving light attributes such as position and color. This was procedure was explained under Using Solo as a pre-recording filter, page 92. An example of its use for moving lights is given below.

Keystrokes:

Action: Selects the Blind display mode 1. Press [Blind]. 2. Press [S8], Fixture, [1][0] Selects moving light fixtures 10 [Thru] [1][5]. through 15 Restricts the selection to the color 3. Press [Only] [Color]. attributes of these fixtures 4. Press [Record] [Focus Point] Records the color attribute settings [7] [Solo]. into cue 7

Working with focus points in Stage

Placing a focus point on stage

You can place an entire focus point on stage with or without the focus point references, then record those channels into something else. If the references are present, you know the channels will automatically update where they were recorded if their levels change in the focus point.

Follow the procedure below to place a focus point on stage with the references. Note the footnote showing how to place the focus point channels on stage without the references.

Keystrokes:

- 1. Press [Stage]. Selects Stage display mode
- 2. Press [Focus Point] [2] Selects the channels of focus point 2 [Focus Point] [2].^a and links them to the focus point itself Prompt reads:

Action:

Select focus point and press ENTER

3. Press [Enter].

Prompt reads:

Group mode – Press AT or use wheel or trackpad to alter levels, or select channel numbers to edit

a. To drop the reference (and also the updating capability), you need only select the focus point channels and set a proportional level, such as press [Focus Point] [2] [Full] (no need to press [Enter] in step 3).

Modifying a focus point

Follow the procedure below to modify a recorded focus point in Stage:

Keystrokes:		Action:
1.	Display focus point 2 in Stage as illustrated above.	
2.	Press [S8], Fixture , [3] [Thru] [8] [Full].	Sets the intensity of fixtures 3 through 8 to full
3.	Press [Record] [Focus Point] [2]. ^a	Prompt reads: To record focus point, select number and press ENTER To cancel, press CLEAR
4.	Press [Enter].	Records modifications into focus point 2

a. You can record to the same or to a different focus point.

Updating focus points

Update allows you to modify previously recorded cues, groups, submasters or focus points in Stage. Update takes levels from all captured and selected channels, and those selected may be restricted with the Only command. 64

Updating an active focus point

The following procedure illustrates how to update a focus point that has been placed on stage.

Keystrokes:		Action:
1.	Press [Stage].	Selects Stage display mode
2.	Press [Focus Point] [4] [Full].	Places focus point 4 on stage at full
3.	Modify channel levels as desired.	Sets focus point levels or selects additional channels and sets their levels
4.	Press [S2], Update .	Prompt reads: To update cue, select number and press ENTER To cancel, press CLEAR
5.	To restrict channels in the update, use Only here. ^a	Restricts channels in update Prompt reads: Select channel number(s) - To cancel, press CLEAR (Press 0 to reselect all non-zero channels)
6.	Press [Focus Point] [4] [Enter].	Updates focus point 4

a. If not restricted with Only, all captured and selected channels are included in the update.

^{64.} For an explanation of captured channels, see Channel modes, page 52. For an explanation of Only, see The Only command, page 8.

Updating a recorded focus point

You need not place a focus point on stage to update it. The following procedure illustrates how to update any recorded focus point.

Ke	ystrokes:	Action:
1.	Press [Stage].	Selects Stage display mode
2.	Press [S8], Fixture , [8], [Full].	Sets fixture 8 intensity to full
3.	Press [Only] [Color] [At] [5][0].	Sets levels for fixture 8 color category at 50%
4.	Press [S7], More Softkeys.	Returns to main Stage softkeys
5.	Press [S2], Update , [Focus Point] [3].	Selects focus point 3 to update Prompt reads: To update focus point, select number and press ENTER To cancel, press CLEAR
6.	To restrict channels in the update, use Only here. ^a	Selects channels to update Prompt reads: Select channel number(s) - To cancel, press CLEAR (Press 0 to reselect all non-zero channels)
7.	Press [Enter].	Updates focus point 3

a. If not restricted with Only, all captured and selected channels are included in the update.

Editing a focus point in Blind

You may modify a focus point in Blind. For example, add or delete fixtures or set levels of fixture attributes.

Follow the procedure below to set fixture attribute levels in a focus point. The selected fixtures need not already be represented in the focus point.

Keystrokes:

Action:

1.	Press [Blind].	Selects Blind display mode
2.	Press [Focus Point] [1].	Selects focus point 1's channels Prompt reads: Group mode – To recall a focus point, select the number and set it to a level To create or modify a focus point, select the number and press ENTER
3.	Press [Enter].	Displays non-zero levels of all focus point channels Prompt reads: Select channel numbers
4.	Press [S8], Fixture, [8] [Thru] [1][2] [Only] [Color] [At] [5][0].	Sets the color attribute(s) of fixtures 8 through 12 to 50
5.	Press [Record] [Enter]. ^a	Re-records focus point 1 as modified

a. Specify a number here to record to a different focus point, such as [Record] [5][0] [Enter]. If that focus point exists, it is overwritten. If it does not exist, it is created.

Labeling focus points

If you have Expression Off-Line, you may assign labels to your focus points. 65 Focus point labels can consist of any combination of letters, numbers and symbols and may be up to 16 characters long.

Follow these steps to label a focus point:

Keystrokes:		Action:
1.	Press [Blind].	Selects Blind display mode
2.	Press [Focus Point] [1].	Prompt reads: Group mode – To recall a focus point, select the number and set it to a level To create or modify a focus point, select the number and press ENTER
3.	Press [Enter].	Prompt reads: Select channel numbers
4.	Press [Label]. ^a	Prompt reads: Type focus point label (F6 = clear to end, F7 = previous focus point label, F8 = next focus point label)
5.	Use the alphanumeric keyboard to enter a label.	Corner displays your label
6.	Press [Enter].	Focus point 1 is labeled

a. Not available on the Express console. You may type keyboard equivalent "B" in Expression Off-Line as a substitute for the Label key.

^{65.} For information about Expression Off-Line and how to order it, see Expression Off-Line, page 312.

Deleting focus points

Delete a focus point from memory in the Stage, Blind or Fader displays.⁶⁶ If any cues, groups or submasters are linked to the deleted focus point, the links are retained but the levels of the linked channels are set to zero.

Delete a focus point in Stage as follows:

Keystrokes:

Actions:

Prompt reads:

Selects Stage display

To cancel, press CLEAR

- 1. Press [Stage].
- 2. Press [S7], More Softkeys, [S6], Delete, [Focus Point].
- 3. Press [2].

Enters focus point number to delete Corner reads: **Focus 2**

To delete focus point, press ENTER

4. Press [Enter] [Enter]. Focus point 2 is deleted from your show

Copying focus points

You may copy a focus point in Stage or Blind with small differences in the procedure and prompts. Proceed as follows in Stage:

Ke	ystrokes:	Actions:
1.	Press [Stage].	Selects Stage display
2.	Press [Focus Point].	Prompt reads: Group mode – Select focus point to use as group
3.	Press [1].	Selects focus point 1 to copy Corner reads: Focus 1
4.	Press [Full].	Prompt reads: Group mode – Press AT or use wheel or trackpad to alter levels, or select channel numbers to edit
5.	Once the focus point is displayed, press [Record] [Focus Point]. ^a	Prompt reads: To record focus point, select number and press ENTER To cancel, press CLEAR
6.	Press [5] [Enter].	Enters the number of the new focus point and completes the Copy. Corner reads: Focus 5
	a. To copy a focus point's submaster, press [Cue] step 5.	s channels and levels to a cue or a or [Sub] in place of [Focus Point] in

^{66.} You can delete all focus points at once with the Clear Focus Points option from the Clear Functions menu. See Clear and reset options, page 255.

Setting levels with focus points

Focus points are commonly used as level setting devices for fixtures, but they can be used to set levels for individual channels as well. First, create a focus point with a certain characteristic, such as all fixtures pointed to a particular location or set to a certain color. Then, set individual fixtures at the levels contained in the focus point as part of your recorded cues, groups or submasters. Since those recordings are linked to the focus point, if levels in the focus point change, the corresponding levels in the recordings change to match those in the focus point. For example, if you change the position levels in the focus point, any cues, groups or submasters recorded with reference to those fixture positions in the focus point change at the same time.

Sometimes, however, you may want to use a focus point to set channel or attribute levels without preserving the link to the focus point. You can do that with a unique application of the [Level] key.

The following procedure illustrates how to use a focus point in Blind to set the position attributes of fixtures, link the levels to the focus point and record the result into a cue. The footnote to the procedure explains how to accomplish the same purposes but without the link.

1.	Press [Blind].	Selects the Blind display
2.	Press [S8], Fixture, [1] [And] [2].	Selects fixtures 1 and 2
3.	Press [Only] [Position] [Focus Point] [6] [Enter] ^a .	Sets the pan and tilt attributes of fixtures 1 and 2 at focus point 6
4.	Press [Record] [1][0].	Records into cue 10

a. For level setting without a link, substitute [Level] for [Enter] in this step.

Chapter 13 Submasters

Express provides you with 24 submaster sliders. A submaster is a group of channels recorded at proportional levels and controlled by a slider and a bump button. Submasters enable you to save complex looks you use frequently and play them back manually. They can also be used as building blocks when you create scenes, cues or other submasters.

NOTE: On the Express 24/48, in one scene mode, you may set the bottom row of channel sliders to be your 24 submasters. In two scene mode you will not be able to use submasters. See Chapter 23 Two scene preset, page 257, for more information.

A channel may be included in any number of submasters. You can record a total of 240 submasters (24 submasters in each of ten pages of submaster memory).

Each submaster slider is accompanied by a bump button and one LED. The slider allows you to bring up the submaster look manually. The bump button allows you to flash the submaster to its full recorded level or to begin its programmed fade, if it has one. The LEDs show you which sliders control recorded submasters.

This chapter includes the following sections:

- Submaster types
- Submaster pages
- Playback Submaster List
- Submaster LEDs
- Submaster bump buttons
- Recording submasters
- Creating inhibitive submasters
- Modifying submasters in Blind
- Modifying submasters in Stage
- Using Update to modify submasters
- Live control of a submaster
- Controlling submaster fades manually
- Labeling submasters
- Copying submasters
- Loading cues or groups to submasters
- Copying cues or groups to submasters
- Clearing submasters

Submaster types

Submasters can be pile-on, inhibitive or effect.

Pile-on submaster

A pile-on submaster consists of channels recorded at proportional levels. If a pile-on submaster's channel levels are higher than established channel levels, the submaster's levels take precedence (except as noted below). If they are lower, the established levels take precedence. If a submaster slider contains a recorded pile-on submaster, the LED glows.

Note: Channel levels set on the keypad and inhibitive submasters both override pile-on submaster levels.

Inhibitive submaster

An inhibitive submaster holds the output of channels below a specified level. An inhibitive submaster doesn't actually set channel levels, it just prevents them from exceeding a specified level. All Express submasters may be inhibitive. If a submaster slider contains a recorded inhibitive submaster, the LED glows.

Effect submaster

An effect submaster has an effect recorded in it. Press an effect submaster's bump button or move its slider to start the effect running. See *Chapter 16 Effects, page 197* for more information on effect submasters. Any submaster may be programmed with an effect. If a submaster slider contains a recorded effect submaster, the LED glows.

Changing type

type.

You can change a submaster's type by using the [Type] key. When you change a submaster type, levels recorded in the submaster are retained. This means that you can change a submaster from pile-on to inhibitive and back without losing any level or timing information. If you change the type to effect, channel and level information is erased.

To change a submaster's type, follow these steps:

Keystrokes:Action:1. Press [Blind].Selects Blind display2. Press [Sub] [#].Prompt reads:
Select submaster number3. Press [Type].Prompt reads:
Select submaster type
(1 = Pile-on, 2 = Inhibitive, 3 = Effect)4. Press [1], [2] or [3] to selectNew type is entered in submaster

Type changes do not take effect while the submaster is active. An active submaster's bump button LED blinks after you change its type. To deactivate it, move its slider to zero or to **10**.⁶⁷

status bar

^{67.} See Submaster LEDs, page 156, for more information about the LED.

Submaster pages

Express has ten pages of submasters. A page is a block of console memory that contains one set of recorded submasters, corresponding to the submaster sliders. The ten pages of memory increases the number of possible submasters to 240.

The console displays the message **Sub page 1** (**2**, **3**...) in the upper left corner of the display to indicate the current submaster page. To switch from one page to the other, press [Page], enter the desired page number, and press [Enter].

When you switch submaster pages, any submasters on stage remain on stage until you move their sliders to the home position. Until the new submaster loads, submaster LEDs flash slowly, indicating that the submaster on stage is from the previously loaded page. When you move the slider to its home position the new submaster is loaded and the LED stops flashing. This prevents the stage from going black or changing levels when you switch pages. (Fast flashes designate a submaster with a dwell time of **Hold**. See *Submaster LEDs, page 156*, for more information about LEDs.)

Note: When you read a new show into the console from a disk, the console loads the same page number that was loaded from the previous show. Any submasters on stage when you read a new show into the console remain on stage until you move their sliders to the home position. Until the new submaster loads, submaster LEDs flash, indicating that the submaster on stage is from the previously loaded show. When you move the slider to its home position the new submaster is loaded and the LED stops flashing.

Submaster bump buttons

A bump button is located immediately below each submaster slider. The bump button's function depends on its status (see below) and on whether the submaster has a programmed fade.

If the submaster does not have a programmed fade, the bump button allows you to bring up the submaster's contents on stage instantly. Press the bump button to raise the submaster to its full recorded level. Hold the button to maintain the levels on stage. Release the button to remove the submaster's levels.

If the submaster has a programmed fade, the bump button allows you to start the fade, or to reverse the direction of an ongoing fade. Press the bump button to start the upfade. Press the button again to interrupt the upfade and start the downfade.

Bump button status

Submaster bump buttons may be individually enabled, disabled or placed in Solo mode. An enabled bump button functions normally, a disabled button doesn't function at all, and a button in Solo mode brings its channels to their recorded level and reduces all other channels to zero.

If a submaster's bump button is disabled or in Solo mode a **D** or an **S** appears next to the submaster's number on the Playback Submaster List and the Status Bar.

To set a bump button's status, follow these steps:

Ke	ystrokes:	Action:
1.	Press [Blind].	Selects Blind display mode
2.	Press [Sub] [5].	Selects submaster 5
3.	Press [S7], More Softkeys , [S1], Bump Status .	Prompt reads: Select bump status and press ENTER (1 = enabled, 2 = disabled, 3 = solo)
4.	Press [2].	Selects disabled . The keypad corner indicates the choice you have made

5. Press [Enter]. Submaster 5's bump button is disabled

Submaster LEDs

Each submaster bump button contains an LED. The state of the LED indicates the current state of that submaster, as shown in the chart below:

<u>Color</u>	<u>State</u>	Meaning
	Off	Submaster not loaded.
Green	Solid	Submaster loaded.
Green	Slow Blink	New submaster. Loads when slider reaches home position.
Green	Fast Blink	Submaster on timed hold. Press bump button to begin downfade.

If the LED on a slider is blinking slowly, it means that you have changed pages and a new submaster is waiting to load. The old submaster stays loaded until you move the slider to the home position. When the slider reaches home, the channel levels from the new page replace the old levels.

Note: If a submaster slider has both a submaster loading and a submaster on hold, the submaster on hold takes priority and the LED blinks fast. Press the bump button to downfade the old submaster.

Recording submasters

You can create submasters in Stage or Blind mode. Follow these steps to record a simple, pile-on submaster:

Keystrokes:		Action:
1.	Press [Stage].	Selects Stage display mode
2.	Select channels and set channel levels.	Creates look
3.	Press [Record].	Prompt reads: To record cue, select number and press ENTER To cancel, press CLEAR
4.	Press [Sub] [5] [Enter] or Press Submaster 5's bump button.	The current stage look is recorded into submaster 5

Note: Use Solo to record specific channels into the submaster (rather than the full stage look). For example: [5] [Thru] [1][0] [S7], **More Softkeys**, [S3], **Solo**, [Solo] [Record] [Sub] [5] [Enter] records only the current levels of channels 5 through 10 in submaster 5, regardless of what other channel levels may be up on stage.

Fade and dwell times for submasters

Normally, pressing a sub bump brings channel levels to their recorded level immediately. Channels stay at full recorded levels as long as the bump button is held.

You can also set upfade, dwell and downfade times for submasters. These times are activated for each submaster by its bump button. Upfade time is the length of time it takes a submaster's channels to fade to their recorded levels when the submaster bump button is pressed. Dwell time is the length of time the submaster's channel levels stay at their full recorded levels before the downfade starts. A manual dwell time means that you can override the bump button fades with the slider (see *Controlling submaster fades manually, page 167* for more information). Downfade time is the length of time it takes a submaster's channels to fade from their recorded levels to zero.⁶⁸

Fade times may be programmed from 0.1 seconds to 99:59 minutes. The number may be entered in normal time format or in decimal format. When entered with a decimal point, the number must be less than one minute (0.1 to 59.9 seconds) to be accepted. When entered without a decimal point, a 2-digit number will be treated as seconds if less than 60 and as a calculated value of minutes and seconds if between 60 and 99. For example, if you enter 70, the time will display as 1:10. If you enter either a 3-digit or a 4-digit number, the last two digits, up to 59, are interpreted as seconds. For example, if you enter 9930, the time will display as 99:30.

^{68.} Defaults for upfade/dwell/downfade dwell times are 0/Manual/0. These default times are true for pile-on or inhibitive submasters, but not for effect submasters. See Effect fade times, page 214.

Adding fade and dwell times

You can add fade and dwell times to a submaster from Stage or Blind mode. To add fade times to a submaster, follow these steps in either mode:

Key	/strokes:	Action:
1.	Press [Sub].	Prompt reads: Select submaster number To select submaster type, press TYPE
2.	Press [5].	Selects submaster 5 Corner reads: Sub 5
3.	Press [Time].	Prompt reads: Enter upfade time
4.	Use keypad to enter upfade time and press [Time].	Prompt reads: Enter dwell time (For hold or manual operation, press CLEAR until desired setting appears)
5.	Use keypad to enter dwell time and press [Time]. (See next page for information about using a Hold dwell.)	Prompt reads: Enter downfade time
6.	Use keypad to enter downfade time and press [Enter].	New fade times are recorded into submaster 5

Note: Once a timed submaster is running, press the bump button to change the direction of the fade. For example, if the upfade is half finished, pressing the bump button starts the downfade from 50 percent. If a downfade is running, pressing the bump button begins an upfade again from the current level.

Hold dwell time

If you record a submaster with a dwell time of **Hold**, the submaster fades up when you press the bump button, then holds until you press it again.

To add a dwell time of **Hold** to a submaster, follow these steps:

Keystrokes:		Action:
1.	Press [Sub].	Prompt reads: Select submaster number To select submaster type, press TYPE
2.	Press [5].	Selects submaster 5 Corner reads: Sub 5
3.	Press [Time] [Time].	Prompt reads: Enter dwell time (For hold or manual operation, press CLEAR until desired setting appears)
4.	Press [Clear].	Corner reads: Dwell Hold
5.	Press [Enter] [Enter].	Dwell time is set to Hold for submaster 5

Manual dwell time

If you record a submaster with a dwell time of **manual** and an upfade time other than zero, the upfade starts when you press and hold the bump button. It runs until channels reach full recorded levels, then holds at full as long as you hold the bump button; the downfade begins when you release it. If you don't hold the bump button for the duration of the upfade time, channels do not reach their full recorded levels.

Follow this procedure in Blind to convert a timed dwell to a manual dwell.⁶⁹

Keystrokes:		Action:
1.	Press [Blind] [Sub].	Prompt reads: Select submaster number To select submaster type, press TYPE
2.	Press [5].	Selects submaster 5 Corner reads: Sub 5
3.	Press [Time] [Time].	Prompt reads: Enter dwell time (For hold or manual operation, press CLEAR until desired setting appears)
4.	Press [Clear] [Clear].	Corner reads: Dwell Man
5.	Press [Enter] [Enter].	Dwell time is set to Manual for submaster 5

Adding a rate to a submaster

Rate allows you to record submasters that play back faster or slower than their recorded fade times. This can be especially helpful when you are trying to calculate complex timing information for effects loaded to a submaster.

Note: If you adjust the rate on a submaster containing an effect, the rate adjustment affects individual step timing but does not change the overall effect timing.

Rate is expressed as a percentage. A submaster with a rate of 100 plays back at its recorded fade time. A rate of 300 plays the submaster back three times faster than its recorded fade time. A rate of 50 causes it to play back half as fast as its recorded fade time. You may assign a rate of up to 2,000 percent.

To add a rate to submaster 7, follow these steps:

Action:		Keystrokes:
1.	Press [Blind].	Selects Blind display mode
2.	Press [Sub] [7].	Prompt reads: Select submaster number To select submaster type, press TYPE
3.	Press [S5], Rate .	Prompt reads: Use keypad to select submaster rate (0 to 2000, 100 = Normal)
4.	Press [1][5][0].	Corner reads: Rate 150
5.	Press [Enter].	Rate of 150 percent is recorded into submaster 7

^{69.} If you do not enter a dwell time for a submaster, the submaster defaults to a manual dwell.

Specifying a submaster's page

You may specify the page to which you record submasters. For example, if page 1 is loaded, you can record a submaster to page 2. To do so, follow these steps:

Keystrokes:		Action:
1.	Create a look in Stage.	
2.	Press [Record] [Sub].	Prompt reads: To record submaster, press BUMP or select number and press ENTER To cancel, press CLEAR
3.	Press [Page] [2].	Prompt reads: Select page on which to record submaster, then press submaster bump button
4.	Press submaster 6's bump button.	Current levels are recorded into submaster 6 on submaster page 2

Using Except to record a submaster

The console allows you to program a submaster containing all the current levels on stage except for those contributed by a specific cue, group, or another submaster. 70

This example illustrates how you record a submaster without including levels contributed by the specified submaster.

Keystrokes:		Action:
1.	Press [Stage].	Selects Stage display mode
2.	Select desired channels and set channel levels.	
3.	Press [Record] [Sub].	Prompt reads: To record submaster, select number and press ENTER To cancel, press CLEAR
4.	Press [5].	Selects submaster 5 to be recorded
5.	Press [Except] [Sub] [3]. ^a	Instructs that levels raised by submaster 3 be ignored Prompt reads: Select excepted submaster number
6.	Press [Enter].	Records submaster 5 minus submaster 3's levels

^{a.} Press [Cue] or [Group] in place of [Sub] in step 5 to leave out the channels supplied by a cue or group.

^{70.} [Except] will not work with effect cues or effect submasters.

Inhibitive submasters

Creating

Inhibitive submasters allow you to limit the output of a group of channels. Channel outputs are limited to the level at which you set the slider. An inhibitive submaster set at **10** (100 percent), does not affect channel output. An inhibitive submaster controls the levels of its assigned channels in the same way the Grandmaster controls the levels of all channels.

Note: If channels that you expect to see on stage are missing or at the wrong levels, check to see if a submaster is inhibiting them. If a channel is fully inhibited by a submaster, its level will be displayed as a yellow zero.

Follow these steps to create and add channels to an inhibitive submaster:

Keystrokes:		Actions:
1.	Press [Stage].	Selects Stage display
2.	Press [Sub] and enter the number of the submaster (1 to 24) you wish to be inhibitive.	Selects sub to change Prompt reads: Select submaster number To select submaster type, press TYPE
3.	Press [Type] [2].	Specifies sub is inhibitive Prompt reads: Select submaster type (1 = Pile-on, 2 = Inhibitive, 3=Effect)
4.	Press [1][0] [Thru] [2][0].	Adds channels 10 through 20 to the sub
5.	Press [Record] [Sub] [Enter].	Records new inhibitive sub

Follow the same procedure to convert back to pile-on.

- You may include the same channel in more than one inhibitive submaster.
- If you press an inhibitive submaster's bump button, the submaster fades from its current slider location to zero and back, using its recorded fade times.

Adding channels

Once you have an inhibitive submaster, use the following procedure in Blind to add channels to it.

Keystrokes:		Actions:
1.	Press [Blind].	Selects Blind display
2.	Press [Sub] [1][5] [Enter].	Selects sub 15. All channels in sub 15, if an inhibitive submaster, are displayed with "IN" in their level fields. Prompt reads: Select channel numbers
3.	Press [5][2] [Enter].	Adds channel 52. The channel is shown with "IN" in its level field. Specifies sub is inhibitive
4.	Press [Record][Sub] [Enter].	Records sub 15 with the added channel

Deleting channels

[Enter].

Channels may be deleted from an inhibitive submaster either in Stage or Blind. Follow the procedure below to delete in Blind.

Key	ystrokes:	Actions:
1.	Press [Blind].	Selects Blind display
2.	Press [Sub] [1][5] [Enter].	Selects sub 15. All channels in sub 15, if an inhibitive submaster, are displayed with "IN" in their level fields. Prompt reads: Select channel numbers
3.	Press [5][2] [Clear].	Clears channel 52.
4.	Press [Record][Sub]	Records sub 15 without channel 52

Modifying submasters in Blind

To modify a submaster in Blind, follow these steps:

Key	ystrokes:	Actions:
1.	Press [Blind].	Selects Blind display
2.	Press [Sub] [1].	Prompt reads: Select submaster number To select submaster type, press TYPE
3.	Press [Enter].	Brings up current level settings for submaster 1 Prompt reads: Select channel numbers
4.	Enter channel numbers and set desired new levels.	Sets new levels
5.	Press [Record].	Prompt reads: To record submaster, select number and press ENTER To cancel, press CLEAR
6.	Press [Enter].	Changes to submaster 1 are recorded

Modifying submasters in Stage

Re-recording submasters

To modify a submaster in Stage with Record, follow these steps:

Keystrokes:		Actions:
1.	Press [Stage].	Selects Stage display
2.	Use the submaster slider to raise submaster 2 to full on stage.	Submaster 2's channels rise on stage to recorded levels
3.	Enter channel numbers and set desired new levels.	New levels are set on stage
4.	Press [Record], then press submaster 2's bump button.	Submaster 2 is recorded with the new levels. Submaster LED blinks, indicating that submaster 2 has been changed and the changes have not been loaded
5.	Press [Rel].	Releases newly set levels
6.	Slide submaster slider to zero, then back to full.	Loads submaster 2's new levels and brings them up on stage

Updating submasters

Update allows you to modify previously recorded cues, groups, submasters or focus points in Stage. Update takes levels from all captured and selected channels, and those selected may be restricted with the Only command.⁷¹

Updating an active submaster

The following procedure illustrates how to update a submaster that has been brought up on Stage. Note that you can update all submasters at once by entering 0 instead of a submaster number in step 4 below. No new channels are added when updating all submasters at once.

Keystrokes: Action:

1.	Press [Stage].	Selects Stage display mode
2.	Set submaster 6's slider to 10. ^a	Puts submaster 6's full look on stage
3.	Modify channel levels as desired.	Sets submaster levels or selects additional channels and sets their levels
4.	Press [S2], Update , [Sub].	Prompt reads: To update submaster, press bump or select number and press ENTER Press 0 + ENTER to select all submasters (only those channels already in sub)
5.	To restrict channels in the update, use Only here. ^b	Selects channels to update Prompt reads: Select channel numbers To cancel, press CLEAR
6.	Press submaster 6's bump button.	Updates submaster 6

- ^{a.} You cannot update a channel in a submaster to a level higher than the submaster slider's level. For example, if you have the slider set to 5, the highest level to which you can update the sub is 50.
- b. If not restricted with Only, all captured and selected channels are included in the update.

^{71.} For an explanation of captured channels, see Channel modes, page 52. For an explanation of Only, see The Only command, page 8.

Updating a recorded submaster

You need not bring up the submaster to update it. The following procedure illustrates how to update any recorded submaster.

Ke	ystrokes:	Action:
1.	Press [Stage].	Selects Stage display mode
2.	Press [S8], Fixture , [1] [Thru] [8], [Full].	Selects fixtures 1 through 8 and sets their intensities to full
3.	Set the pan and tilt levels. ^a	Sets levels for fixture 8 pan and tilt attributes
4.	Press [S2], Update , [Sub].	Prompt reads: To update submaster, press BUMP or select number and press ENTER Press 0 + ENTER to select all submasters (only those channels already in sub)
5.	Press [Page] [3].	Selects submaster page 3 Prompt reads: Select submaster page to update and press ENTER or submaster BUMP To cancel, press CLEAR
6.	To restrict channels in the update, use Only as explained under <i>The Only</i> <i>command, page 8</i> . ^b	Selects channels to update Prompt reads: Select channel number(s) - To cancel, press CLEAR (Press 0 to reselect all non-zero channels)
7.	Press submaster 6's bump button.	Updates submaster 6 on submaster page 3

- ^{a.} Use your trackpad.
- b. Optional step.
Live control of a submaster's rate

In Stage mode, selecting a submaster and pressing [S5], **Rate**, allows the timing of the submaster to be controlled by the trackpad or by keyboard entry.

Follow these steps to change the rate of an active submaster in Stage. (This procedure also works if the submaster is not active. In either case, the new rate is automatically recorded in the submaster.)

Keystrokes:

Action:

- 1. Press [Stage]. Selects Live display
- 2. Press [Sub] [5]. Selects submaster 5
- 3. Press [S7], **More Softkeys**, until **Rate** appears at [S5].
- 4. Press [S5], **Rate**.

Activates rate control Prompt reads: Select submaster rate and press ENTER, or use wheel or trackpad to alter rate (0 to 2000, 100 = Normal)

- 5. Move a finger on the trackpad.^a Sets and records fade rate for submaster 5. If submaster is running, fade proceeds at new rate
- 6. Press [Enter]. Accepts the new rate
 - ^{a.} When the submaster rate is controlled dynamically by the trackpad, the submaster number turns blue in the Submaster List. See Submaster List, page 173, for more information.

Controlling submaster fades manually

When you press the bump button on a timed submaster, recorded fade times play back as you recorded them. The console allows you to use the slider to take manual control of submasters recorded with fade times.

The Submaster List shows the progress of the submaster's fade. To override the fade, push the submaster's slider to a higher level than the fade (lower, if inhibitive).

Once the slider passes the fade (or meets it at Full on pile-on submasters or zero on inhibitive submasters), control of the fade transfers to the slider and you have full manual control of the submaster. Move the slider to set the fade level.

Labeling submasters

If you have Expression Off-Line, you may assign labels to your submasters. ⁷² Submaster names can consist of any combination of letters, numbers and symbols, and may be up to 16 characters long.

Follow these steps to add the name "Bedroom wash" to submaster 4:

Key	/strokes:	Action:	
1.	Press [Stage].	Selects Stage display	
2.	Press [Sub] [4].	Prompt reads: Select submaster number To select submaster type, press TYPE	
3.	Press [Label]. ^a	Prompt reads: Type submaster name	
4.	Use the alphanumeric key- board to enter the label. Type Bedroom wash .	Corner reads: Label: Bedroom wash	
5.	On the console keypad, press [Enter].	Submaster 4 is labeled Bedroom wash	

^{a.} Not available on the Express console. You can type keyboard equivalent "B" in Expression Off-Line as a substitute for the Label key.

^{72.} For information about Expression Off-Line and how to order it, see Expression Off-Line, page 312.

Copying submasters

You can copy a look from a submaster to another submaster, to a cue, a group or a focus point. Follow the procedure below:

Keystrokes: Actions: 1. Press [Blind]. Selects Blind display mode 2. Press [Sub]. Prompt reads: Select submaster number To select submaster type, press TYPE 3. Enter the number of the Corner reads: submaster you wish to Sub 1 copy. Prompt reads: 4. Press [Record] [Sub].^a To record submaster, select number and press ENTER To cancel, press CLEAR 5. Enter the number of the Corner reads: Sub 9 new submaster. 6. Press [Enter]. Submaster Contents of submaster 1 are copied to

^{a.} To copy the submaster to a cue, group or focus point, press [Cue], [Group] or [Focus Point] in place of [Sub] in step 4.

submaster 9

Loading cues or groups to submasters

copy is complete.

[Load Sub] allows you to load the contents of one or more recorded groups or cues into submasters.

To load a look from a range of cues or groups to submasters, follow these steps:

Key	vstrokes:	Actions:	
1.	Press [Load Sub].	Prompt reads: Select submaster(s) to load To cancel, press CLEAR	
2.	Press [9] [Thru] [1][2].	Selects submasters 9 through 12 Corner reads: Sub 12	
3.	Press [Cue] (or [Group]).	Prompt reads: Select cue(s) to load into submaster(s) To cancel, press CLEAR	
4.	Press [1] [And] [3] [Thru] [5].	Selects cues 1, 3, 4, and 5 to copy to submasters 9 through 12 Corner reads: Cue 5	
5.	Press [Enter]. Submaster copy is complete.	Contents of cues 1, 3, 4, and 5 are copied to submasters 9, 10, 11, and 12, respectively	

Copying cues or groups to submasters

To copy a look from a cue or a group to a submaster, follow these steps:

Ke	ystrokes:	Actions:
1.	Press [Blind].	Selects Blind display mode
2.	Press [Cue] (or [Group]).	Prompt reads: Select cue number To select cue type, press TYPE
3.	Press [1].	Selects cue to copy Corner reads: Cue 1
4.	Press [Record] [Sub].	Prompt reads: To record submaster, select number and press ENTER To cancel, press CLEAR
5.	Press [9].	Selects submaster 9 Corner reads: Sub 9
6.	Press [Enter]. Submaster copy is complete.	Contents of cue 1 are copied to submaster 9

Clearing submasters

You must be in Blind or Stage display mode to clear the contents of individual submasters. This process erases all level setting instructions and attributes from the submaster. To clear all submasters, use the Clear Submasters option from the Clear Functions menu as described in Clear and reset options, page 255.

To clear submasters, follow these steps:

Ке	ystrokes:	Actions:		
1.	Press [Blind].	Selects Blind display		
2.	Press [Sub].	Prompt reads: Select submaster number		
3.	Press [S6], Delete Sub .	Prompt reads: To delete submaster(s), select number(s) and press ENTER To cancel, press CLEAR		
4.	Enter the number of the submaster you want to clear.	Corner reads: Sub 2		
5.	Press [Enter].	Prompt reads: To confirm, press ENTER To cancel, press CLEAR		
6.	Press [Enter] to delete the submaster or [Clear] to cancel the action.	Contents of submaster 2 are cleared		

Chapter 14 Lists and spreadsheets

You can display lists of cues, submasters, groups and focus points on the monitor using a softkey in the Blind display.⁷³ These lists allow you to change the timing of cues and submasters and label items on the list.⁷⁴ They also allow you to delete items from a list.

Also available by softkey from the Blind display are spreadsheets for cues, submasters, groups and focus points. Spreadsheets allow you to add or delete items from the list, such as to create new cues or groups.

Following are the topics included in this chapter:

- Cue List
- Submaster List
- Group List
- Focus Point list
- Editing in lists
- Cue, Submaster, Group and Focus Point spreadsheets
- Editing in spreadsheets

^{73.} Sub List can also be displayed with a softkey in Stage.

^{74.} You may assign labels in lists with Expression Off-Line using the keyboard equivalent "B". See Expression Off-Line, page 312, for details.

Cue List

The Cue List allows editing of upfade, downfade and wait times; link and follow settings; rate; and cue label.⁷⁵ This list also allows you to delete cues from your show.

Up to 18 cues are displayed on this Cue List at one time. Screens can be paged if there are more than 18 cues in the show. Press [Blind] [S2], **Cue List**, to display the Cue List.



Editing cues

Edit one cue or multiple cues at a time in the Cue List with the following procedure. Changes made are recorded immediately.

Keystrokes:

wish to edit.^a

Action:

- 1. Press [Blind]. Selects Blind display
- 2. Press [S2], **Cue List**. Displays Cue List
- 3. Press [1] [Thru] [3]. Selects cues 1, 2 and 3 Prompt reads:

Select cue number(s)

- Press [→] until the cursor reaches the attribute you
 The prompt indicates your options or prompts you to enter a new setting
- 5. Enter the new setting for Changes the cue the attribute and press [Enter].
 - ^{a.} Alternatively, you may press [Type], [Time], [Link], [Follow] or [Wait] keys to enter the field you want. You cannot gain access to the label field from the console. In Expression Off-Line, type the keyboard equivalent "B" to enter the label field.

^{75.} Use keyboard equivalent "B" in Expression Off-Line to assign labels. See Expression Off-Line, page 312, for details.

Submaster List

The Submaster List allows editing of bump button status; upfade, downfade and dwell times; type; rate and label.⁷⁶ This list also allows you to delete submasters from your show.

Enter the Submaster List from softkeys in either Blind or Stage. In Blind, press [Sub] [S2], **Sub List**. In Stage, press [Sub] [S7], **More Softkeys**, [S2], **Sub List**.



The first 17 submasters are shown initially in the Submaster List. Page through the rest of the submasters using the [S5], **Next Page** and [S4], **Previous Page**, keys.

Unrecorded submasters are shown with a gray number in the Sub (first) column. A recorded pile on submaster has a green Sub number; an inhibitive submaster has a red Sub number; an effect submaster has a white Sub number. The Submaster List on the playback monitor has the same color coding.

The currently selected submaster page is shown following the words "Sub Page" at the top left of the display. Change submaster pages as explained in *Specifying a submaster's page, page 161*. In general, the Page Loaded shown in column two will agree with Sub Page except for those submasters that were on stage when the current Sub Page was selected (see *Submaster pages, page 154*). The column marked "%" shows the submaster's current level on stage as determined by its slider.

^{76.} Use keyboard equivalent "B" in Expression Off-Line to assign labels. See Expression Off-Line, page 312, for details.

Note the following with regard to defaults in the Submaster List display:

- Pile-on is the default type for a newly defined submaster.
- Bump status does not display unless changed from the default, which is "enabled."
- Dwell time defaults to "manual."
- Rate does not display unless changed from the default, which is 100.

Navigation and Feedback - Submaster List					
	7 8 9 4 5 6 1 2 3	[S]	^↓	4	±
Select a submaster	Х		Х		Х
Select a field		Х		Х	
White row selecte		ed submaster			
Yellow field	selected field				

Editing submasters

Changes made to a submaster in the Submaster List are immediately recorded. Edit in the Submaster List as follows.⁷⁷

Ke	ystrokes:	Actions:		
1.	Press [Blind].	Selects Blind display		
2.	Press[Sub] [S2], Sub List.	Displays Submaster List Select submaster number(s)		
3.	Press [1][3] [Enter].	Selects submaster 23. Prompt reads: Select bump status and press ENTER (1=enabled, 2=disabled, 3=solo)		
4.	Press [1] [Enter]. ^a	Enables bump status for the submaster. Prompt reads: Enter upfade time		
5.	Press [5] [Enter].	Specifies 5 second upfade time Prompt reads: Enter dwell time (For hold or manual operation, press CLEAR until desired setting appears)		
6.	Press [1][5] [Enter].	Specifies 15 seconds dwell time Prompt reads: Enter downfade time		

^{a.} If not changing the bump status, for example if the submaster is already enabled, you may just press [Enter].

^{77.} Alternatively, you may press [Type] or [Time] keys to reach the field you want.

7.	Press [5] [Enter].	Specifies 5 second downfade time Prompt reads: Select submaster type (1=Pile-on, 2=Inhibitive, 3=Effect)
8.	Press [2] [Enter].	Specifies inhibitive type. Prompt reads: Use keypad to select submaster rate (0-2000, 100=Normal)
9.	Press [2][0][0] [Enter]. ^a	Specifies rate 200. Prompt reads: Select submaster numberType submaster label (F6=clear to end, F7=previous submaster level, F8=next submaster label)
10.	Enter your label on the keypad, then press [Enter].	Labels submaster 23

^{a.} You cannot gain access to the label field from the console. In Expression Off-Line, type the keyboard equivalent "B" here instead of [Enter] to produce the prompt shown in Step 9 and to enter the label field.

Deleting submasters

All recorded information can be removed for one or more submasters using the Submaster List. Follow the procedure below.

Keystrokes:

Action:

1.	Press [Blind] [Sub] [S2], Sub List.	Displays Submaster List. Prompt reads: Select submaster number(s)
2.	Press [S6], Delete Sub .	Prompt reads: Top delete submaster(s), select number(s) and press ENTER to cancel, press CLEAR
3.	Press [5][And][7] [Enter].	Specifies submasters 5 and 7 to be deleted. Prompt reads: To confirm, press ENTER To cancel, press CLEAR
4.	Press [Enter].	Deletes submasters 5 and 7

Group List

The Group list shows all the recorded groups in the show by number and label. The list can be paged if there are more than 54 groups in the show (18 groups shown per column). Groups may be labeled in the Group list⁷⁸ or deleted there from the show, either individually or in ranges.

In the Group List display, a selected group is identified by a highlighted white row and a selected field is highlighted in yellow.



Labeling a group

If you have Expression Off Line, follow this procedure to label a group in the Group List display.⁷⁹

Keystrokes:

- 1. Press [Blind] [Group] [Enter] [S2], Group List. Prompt reads:
- 2. Press [4] [B].

Action:

- **Displays Group List** Select group number(s)
- Selects group 4 Prompt reads: Type group label (F6=clear to end, F7=previous group level, F8=next group label)
- Completes labeling of group 4 3. Enter your label, then press [Enter].

^{78.} You can label with Expression Off-Line, not the console.

^{79.} See Expression Off-Line, page 312, for more information about this program.

Deleting a group

Follow this procedure to delete one or more groups in the Group List display.

Key	/strokes:	Action:	
1.	Press [Blind] [Group] [Enter] [S2], Group List .	Displays Group List Prompt reads: Select group number(s)	
2.	Press [S6], Delete Group .	Prompt reads: To delete group(s), press number(s) and press ENTER To cancel, press CLEAR	
3.	Press [4] [And] [5] [Enter] [Enter].	Deletes groups 4 and 5 Prompt reads: Select group numbers(s)	

Focus Point List

The Focus Point list shows all the focus points in the show by number and label. The list can be paged if there are more than 54 focus points in the show (18 focus points shown per column). Focus points may be labeled in the Focus Point List⁸⁰ or deleted there from the show, either individually or in ranges.

In the Focus Point List display, a selected focus point is identified by a highlighted white row and a selected field is highlighted in yellow.

				Foc	us Point 10:21 AM	List			Focus	10
	Focus 1 2 10	Label Spot on Red wash Finale	chair	Focus	Label		Focus	Label		
			Sel	ect fo	cus poin	t number((s)			
S	1	S2	S3	S4		S5	S6	S7	S8	
				Prev	ious ge	Next Page	Focus		Refu	Jinn

^{80.} You can label with Expression Off-Line, not the console.

Labeling a focus point

If you have Expression Off Line, follow this procedure to label a focus point in the Focus Point List display. $^{\rm 81}$

Ke	ystrokes:	Action:		
1.	Press [Blind] [Focus Point] [Enter] [S2], Focus List .	Displays Focus Point List Prompt reads: Select focus point number(s)		
2.	Press [4] [B].	Selects focus point 4 Prompt reads: Type focus point label (F6=clear to end, F7=previous focus point level, F8=next focus point label)		
3.	Enter your label, then press [Enter].	Completes labeling of focus point		

Deleting a focus point

Follow this procedure to delete one or more focus points in the Focus Point List display.

Ke	ystrokes:	Action:
1.	Press [Blind] [Focus Point] [Enter] [S2], Focus List.	Displays Focus Point List Prompt reads: Select focus point number(s)
2.	Press [S6], Delete Focus .	Prompt reads: To delete focus point(s), press number(s) and press ENTER To cancel, press CLEAR
3.	Press [4] [And] [5] [Enter] [Enter].	Deletes focus points 4 and 5 Prompt reads: Select focus point numbers(s)

4

^{81.} See Expression Off-Line, page 312, for more information about this program.

Working in spreadsheets

Cues, submasters, groups and focus points each have their own spreadsheets. You can modify or delete in all spreadsheets and create in all but the submaster spreadsheet. Channels and groups may be added to all spreadsheets singly or in multiples or ranges. Channels may be set at focus points and focus points may be added, singly and in multiples or ranges, in all but the focus point spreadsheet.

In spreadsheets, it is not necessarily to press [Record] to record changes. These changes are made immediately, but they don't update in any cue, submaster, group or focus point already displayed on stage until these are replaced on stage.

Cue spreadsheet

In the cue spreadsheet, you have the option of tracking any cues you create or modify. Press [Blind] [S3], **Spreadsheet**, to go to the cue spreadsheet.

			Spread	dsheet			Chan
Track Dis	abled		01:22	2 PM			
			Char	nels			
Cue 100	01 02 03	3 04 05 (06 07 08 09 FL	10 11 12	13 14 15	16 17 18 1 FL	9 20 21
101	04 34 04	4 71		04 34	04 71		04
103	02 23 03 01 01 0	3 00 00 0 1 01 01 0	00 00 00 00 01 01 01 01	00 03 85 01 01 01	03 86 00 01 01 01	00 00 00 0 01 01 01 0	0 00 00
			Select ch	annel(s)			
S1	S2	S3	S4	S5	S6	S7	S8
Cue	Créate Cue	Level	Previous Page	Next Page	Delete	Endble Tracking	Return

Creating cues

Cues may be created in the cue spreadsheet with or without tracking enabled. After entering the cue spreadsheet as explained on the previous page, create a cue with the tracking option enabled as follows.

Key	/strokes:	Actions:		
1.	Press [S7], Enable Tracking. ^a	Sets tracking enabled		
2.	Press [S2], Create Cue .	Prompt reads: To create a new cue, select cue number and press ENTER To cancel, press CLEAR		
3.	Press [5] [Enter].	Selects cue 5. Prompt reads: Select channel(s)		
4.	Press [5] [Thru] [1][0].	Selects channels to include		
5.	Press Full].	Sets channels 5 through 10 to full Prompt reads: Enter intensity		
6.	Repeat steps 4-5.	Continue selecting channels and setting levels until done		

^{a.} Use either the [Track] key or the cue spreadsheet softkey to toggle the tracking mode. Press once or twice until the yellow message in the upper right corner of the spreadsheet display confirms your choice.

Editing cues

Follow the procedure above for creating a cue in spreadsheet except press [S1], **Select Cue**, rather than softkey [S2] in step 2.

Deleting cues

In the cue spreadsheet, delete one or more cues as follows.

Key	ystrokes:	Actions:		
1.	Press [S6], Delete Cue .	Prompt reads: To delete cue(s), select number(s) and press ENTER To cancel, press CLEAR		
2.	Press [5] [And] [6] [Enter].	Selects cues 5 and 6 Prompt reads: To confirm, press ENTER To cancel, press CLEAR		
3.	Press [Enter] [Enter].	Deletes cues 5 and 6		

Replacing channel level

As a convenient editing technique, you may specify a particular level to change for a channel or number of channels. After entering the cue spreadsheet as explained earlier in this section, replace channel level as follows.

Кеу	vstrokes:	Actions:
1.	Press [S1], Select Cue.	Prompt reads: Select cue(s)
2.	Press [5] [Enter].	Selects cue 5 Prompt reads: Select channel(s)
3.	Press [5] [Thru] [1][0] [S3], Replace Level , [5][0].	Selects channels 5 through 10 at level 50 to change Prompt reads: Select level to replace and press ENTER
4.	Press [Enter].	Prompt reads: Select new level and press ENTER
5.	Press [Full] [Enter].	Changes all channels in the range 5 though 10 with level 50 to level full

Submaster spreadsheet

Press [Blind] [Sub] [S3[, **Spreadsheet**, to go to the submaster spreadsheet.

			Spreads	sheet			Chan
			01:53	PM		Sut	o Page 1
			Chanr	iels			
Sub 1	01 02 03 FL FL FL	3 04 05 . FL FL	06 07 08 09 [.] FL FL FL FL F	11 12	13 14 15	16 17 18 ·	19 20 21
2	FL FL FL	. FL FL	FL FL FL FL F	Ľ			
8	FL FL FL	. FL FL	FL FL FL FL F	L 50 50	50 50		
4							
5							
6							
7							
8							
			Select cho	nnel(s)			
S1	S2	S3	S4	S5	S6	S7	S8
Select Sub		Replace Level	Previous Page	Next Page	Delete Sub		Return

Editing submasters

After entering the submaster spreadsheet as explained above, edit a submaster with the following procedure.

Actions:

Keystrokes:

Prompt reads: 1. Press [S1], Select Sub. Select submasters Selects submaster 5 2. Press [5] [Enter]. Prompt reads: Select channel(s) Selects channels to include 3. Press [5] [Thru] [1][0]. Prompt reads: Select intensity Sets channels 5 through 10 to full 4. Press [Full]. Continue selecting channels and 5. Repeat steps 3-4. setting levels until done

Deleting submasters

After entering the submaster spreadsheet as explained above, delete a submaster as follows.

Ke	ystrokes:	Actions:		
1.	Press [S6], Delete Sub .	Prompt reads: To delete submaster(s), select number(s) and press ENTER To cancel, press CLEAR		
2.	Press [5] [And] [6].	Selects submasters 5 and 6 Prompt reads: To confirm, press ENTER To cancel, press CLEAR		
3.	Press [Enter] [Enter].	Deletes submasters 5 and 6		

Replacing channel level

As a convenient editing technique, you may specify a particular level to change for a channel or number of channels. After entering the submaster spreadsheet as explained on the previous page, replace channel level as follows.

Ke	ystrokes:	Actions:		
1.	Press [S1], Select Sub.	Prompt reads: Select submaster(s)		
2.	Press [5] [Enter].	Selects submaster 5 Prompt reads: Select channel(s)		
3.	Press [5] [Thru] [1][0] [S3], Replace Level, [5][0].	Selects channels 5 through 10 at level 50 to change Prompt reads: Select level to replace and press ENTER		
4.	Press [Enter].	Prompt reads: Select new level and press ENTER		
5.	Press [Full] [Enter].	Changes all channels in the range 5 though 10 with level 50 to level full		

Group spreadsheet

Go to the group spreadsheet as follows.

Keystrokes:

Actions:

- 1. Press [Blind] [Group] [Enter].
- Selects the group mode of the blind display
- 2. Press [S3], Spreadsheet.
- Shows the group spreadsheet



Creating a group

After entering the group spreadsheet as explained above, create a group as follows.

Actions: **Keystrokes**: 1. Press [S2], Create Group. Prompt reads: To create a new group, select group number and press ENTER To cancel, press CLEAR 2. Press [5] [Enter]. Selects group 5 Prompt reads: Select channel(s) Selects channels to include 3. Press [5] [Thru] [1][0]. Sets channels 5 through 10 to full 4. Press [Full]. Prompt reads: **Enter intensity** Continue selecting channels and 5. Repeat steps 3-4.

setting levels until done

Editing groups

You may edit a group in the group spreadsheet. Follow all steps in the procedure under **Creating a group** on the previous page except Press [S1], **Select Group** in step 1.

Deleting groups

After entering the group spreadsheet as explained on the previous page, delete a group as follows.

Ke	ystrokes:	Actions:		
1.	Press [S6], Delete Group .	Prompt reads: To delete group(s), select number(s) and press ENTER To cancel, press CLEAR		
2.	Press [5] [And] [6] [Enter].	Selects groups 5 and 6 Prompt reads: To confirm, press ENTER To cancel, press CLEAR		
3.	Press [Enter] [Enter].	Deletes groups 5 and 6		

Replacing channel level

As a convenient editing technique, you may specify a particular level to change for a channel or number of channels. After entering the group spreadsheet as explained on the previous page, replace channel level as follows.

Ke	ystrokes:	Actions:
1.	Press [S1], Select Group.	Prompt reads: Select group(s)
2.	Press [5] [Enter].	Selects group 5 Prompt reads: Select channel(s)
3.	Press [5] [Thru] [1][0] [S3], Replace Level, [5][0].	Selects channels 5 through 10 at level 50 to change Prompt reads: Select level to replace and press ENTER
4.	Press [Enter].	Prompt reads: Select new level and press ENTER
5.	Press [Full] [Enter].	Changes all channels in the range 5 though 10 with level 50 to level full

Focus point spreadsheet

Go to the focus point spreadsheet as follows.

Keystrokes:

Actions:

- 1. Press [Blind] [Focus Point] Selects the focus point mode of the [Enter]. Blind display
- 2. Press [S3], Spreadsheet. Shows the focus point spreadsheet

			Spread	sheet			Chan
Thack Dis	abled		02:12				
Focus 1	01 02 03 50 50 50	04 05 50 FL	06 07 08 09 FL FL 80 80 3	10 11 12 80 80 80	13 14 15 80 90 90	16 17 18 ⁻ 90	19 20 21
2	50 50 50) 50 FL	FL FL 80 80 8	80 80 80	80 90 90	90	
10	15 62 09	5 78	FL	05 66	07 75	FL	10
			Select ch	annel(s)			
<u>S1</u>	S2	S3	S4	S5	S6	S7	S8
- Select Focus	- Create - Focus	Replace Level	Previous Page	Next Page	- Delete - Focus		Return

Creating focus points

After entering the focus point spreadsheet as explained above, create a focus point as follows.

Actions:

Keystrokes:

Prompt reads: 1. Press [S2], Create Focus. To create a new focus point, select focus point number and press ENTER To cancel, press CLEAR Selects focus point 5 2. Press [5] [Enter]. Prompt reads: Select channel(s) Selects channels to include 3. Press [5] [Thru] [1][0]. Prompt reads: **Enter intensity** Sets channels 5 through 10 to full 4. Press [Full]. Continue selecting channels and 5. Repeat steps 3-4. setting levels until done

Editing focus points

You may edit a focus point in the focus point spreadsheet. Follow all steps in the procedure under **Creating a focus point** on the previous page except Press [S1], **Select Focus** in step 1.

Deleting in spreadsheet

After entering the focus point spreadsheet as explained on the previous page, delete a focus point as follows.

Ke	ystrokes:	Actions:		
1.	Press [S6], Delete Focus .	Prompt reads: To delete focus point(s), select number(s) and press ENTER To cancel, press CLEAR		
2.	Press [5] [And] [6] [Enter].	Selects focus points 5 and 6 Prompt reads: To confirm, press ENTER To cancel, press CLEAR		
3.	Press [Enter] [Enter].	Deletes focus points 5 and 6		

Replacing channel level

As a convenient editing technique, you may specify a particular level to change for a channel or number of channels. After entering the focus point spreadsheet as explained on the previous page, replace channel level as follows.

Ke	ystrokes:	Actions:
1.	Press [S1], Select Focus.	Prompt reads: Select focus point(s)
2.	Press [5] [Enter].	Selects focus point 5 Prompt reads: Select channel(s)
3.	Press [5] [Thru] [1][0] [S3], Replace Level, [5][0].	Selects channels 5 through 10 at level 50 to change Prompt reads: Select level to replace and press ENTER
4.	Press [Enter].	Prompt reads: Select new level and press ENTER
5.	Press [Full] [Enter].	Changes all channels in the range 5 though 10 with level 50 to level full

Chapter 15 Park

Park allows you to set channels, dimmers and fixtures at levels that are maintained on stage. These levels are not recorded into cues and are independent of most other instructions, except as follows:

- [Blackout] will turn off parked dimmers, channels and fixtures unless they are independent channels.
- Channels parked at a focus point will update the parked levels if the levels change in the focus point.

If a dimmer is parked and the channel that controls it also is parked, the dimmer's parked level takes priority over the channel's parked level. If the dimmer is then unparked, the channel will revert to the channel's parked level. When a dimmer, channel or fixture is unparked, the levels revert to the level the console is currently assigning to it.

The following options are described in this chapter:

- Parking and unparking dimmers
- Parking and unparking channels
- Parking and unparking fixtures
- Parking channels and fixtures at a focus point
- Parking and unparking cues, submasters, groups and focus points

Using the Park display

Illustrated below is the Park display that you reach with a softkey in the Stage display. The parked channels and dimmers are displayed in the Park display with their levels and focus point links, if any.

						P 10 : 1:	ark 2 AM				Dim
Par	ked D 1 80	limmers 3 80	: 5 80								
Par	ked C 1 00 02	hannel 2 00 02	s: 3 00 02	4 00 02	5 50 02	6 50 02	7 50 02	8 50 02	9 50 02	10 50 02	
9	\$1		Selec ress	t dimme AT to s <u>S3</u>	r numi elect	ber(s); level; S4	or pi	press ress R 5	ENTER ELEASE S6	to park; to unpark 	
		B		в	P	revious Page	N P	ext age			

Parking dimmers

Park a dimmer by specifying the dimmer number and level. You may park multiple dimmers at once. When dimmers are parked, the message **Park Enabled** appears near the top of the Stage display.

Action:

Park one or more dimmers as follows:

Kev	strokes:	
ILC 1	Stiones.	

	-	
1.	Press [Stage].	Selects Stage display
2.	Press [S6], Park , [Dim].	Prompt reads: Select dimmer number(s), then press ENTER to park, press AT to select level, or press RELEASE to unpark
3.	Enter the dimmer number(s) to park, then press [At]. ^a	Selects the dimmer to park Prompt reads: Enter intensity for park dimmer(s)
4.	Enter the level at which to park the dimmer.	Parks the dimmer at the selected level Alert appears: Parked Dimmers

^{a.} In all references in this chapter to the use of [At] to set a level, you may substitute the [Full] or [Level] keys.

Unparking dimmers

Unparking one dimmer

Unpark one dimmer at a time as follows:

Keystrokes:

Action:

- 1. Press [Stage]. Selects Stage display
- 2. Press [S6], **Park**, [Dim]. Prompt reads:

Select dimmer number(s), then press ENTER to park, press AT to select level, or press RELEASE to unpark

3. Enter the dimmer number Unparks the dimmer to unpark and press [Rel].

Unparking all dimmers

Unpark all dimmers at once as follows:

Ke	ystrokes:	Action:
1.	Press [Stage].	Selects Stage display
2.	Press [S6], Park , [Dim].	Prompt reads: Select dimmer number(s), then press ENTER to park, press AT to select level, or press RELEASE to unpark
3.	Press [Rel].	Prompt reads: To release all parked dimmers, press ENTER. To cancel, press CLEAR
4.	Press [Enter].	Unparks all parked dimmers

Parking channels

Park a channel by specifying the channel number and level. You may park multiple channels at once. Set the level using the keyboard or with reference to a preset focus point. When channels are parked, a yellow alert appears near the top of the command display that reads **Park Enabled**.

Using the keyboard

Park one or more channels at levels taken from the keyboard as follows.

/strokes:	Action:						
Press [Stage].	Selects Stage display						
Press [S6], Park .	Prompt reads: Select channel number(s), then press ENTER to park, press AT to select level, or press RELEASE to unpark						
Press [1] [Thru] [1][0] [Full].	Parks the channel at Full. Alert appears: Parked Channels						
	/strokes: Press [Stage]. Press [S6], Park . Press [1] [Thru] [1][0] [Full].						

Parking at a focus point

You can park channels at a focus point as well as park focus point channels themselves. See *Parking recorded channels, page 194*, for information about parking focus point channels.

When you park channels at a focus point, they are linked to the focus point and take whatever levels are set for the channels in the focus point. If those levels in the focus point change, the link causes the same change to occur for the parked channels. Channels parked at a focus point are shown in the Park display with both the channel's current level in the focus point and the focus point number.

Park channels at a focus point using the following procedure.

Keystrokes:		Action:					
1.	Press [Stage].	Selects Stage display					
2.	Press [S6], Park .	Prompt reads: Select channel number(s), then press ENTER to park, press AT to select level, or press RELEASE to unpark					
3.	Press [Chan] [1] [Thru] [1][0] [Focus Point] [6].	Prompt reads: Select focus point and press ENTER					
4.	Press [Enter].	Parks the channel at focus point 6 Alert appears: Parked Channels					

Unparking channels

Unparking one channel

Unpark one channel at a time as follows:

Keystrokes:

Action:

- 1. Press [Stage]. Selects Stage display
- 2. Press [S6], Park. Prompt reads:

Select channel number(s), then press ENTER to park, press AT to select level, or press RELEASE to unpark

3. Enter the channel number Unparks the channel to unpark and press [Rel].

Unparking all channels

Unpark all channels at once as follows:

Keystrokes:	Action:
1. Press [Stage].	Selects Stage display
2. Press [S6], Park .	Prompt reads: Select channel number(s), then press ENTER to park, press AT to select level, or press RELEASE to unpark
3. Press [Rel].	Prompt reads: To release all parked channels, press ENTER. To cancel, press CLEAR
4. Press [Enter].	Unparks all parked channels

Parking recorded channels

Cues, submasters, groups and focus points may all be parked, either at the levels recorded for their channels or at a proportional level.⁸² For example, if all your worklights are recorded in a group, you could park that group at once, rather than park the worklight channels individually.

Following is an example of how to park a group's channels. Use the same procedure to park the channels of a cue, submaster or focus point except press the [Cue], [Sub] or [Focus Point] key in place of the [Group] key in step 2 of this procedure.

Ke	ystrokes:	Action:					
1.	Press [Stage].	Selects Live display					
2.	Press [S6], Park , [Group].	Prompt reads: Group mode - Select group number then press AT to park, or press Release to unpark					
3.	Enter the group number and press [At].	Selects the group to park Prompt reads: Group mode - Enter intensity					
4.	Enter the level at which to park the group's channel.	Parks the channels at the selected level					

Unparking recorded channels

You can unpark all channels that are recorded into a cue, submaster, group or focus point.

Follow the procedure below to unpark the channels in a cue. To unpark channels in a submaster, group or focus point, press the [Sub], [Group] or [Focus Point] key in place of the [Cue] key in step 2 of this procedure.

Ke	ystrokes:	Action:					
1.	Press [Stage].	Selects Stage display					
2.	Press [S6], Park , [Cue].	Prompt reads: Group mode - Select cue number to use as group, then press AT to park, or press Release to unpark					
3.	Press [5] [Rel].	Unparks cue five's channels					

^{82.} Parking focus point channels only takes the current levels in the focus point. It does not create a link to the focus point.

Parking fixtures

You can park fixtures, one at a time or in ranges, either at levels set from the keypad or at a focus point. When you park a fixture, all channels patched to the fixture are parked whether you select them to set levels or not.

After setting attribute levels from the keypad

Follow the procedure below to park fixtures with their intensity and position attributes set from the keypad.

Keystrokes:		Action:
1.	Press [Stage].	Selects Live display
2.	[S8], Fixture , [1] [Thru] [3].	The fixture box appears and is set to fixture 3
3.	Press [Full].	Sets fixture intensities to full
4.	Set pan and tilt with encoders or your mouse.	Sets position attribute levels
5.	Press [S6], Park .	Prompt reads: Press ENTER to park channel(s), press AT to select level, or press RELEASE to unpark channel(s)
6.	Press [Enter].	Parks the fixture

After setting attribute levels at a focus point

You can park a fixture that has attributes set at a focus point. If you do not select fixture attributes, all attributes are parked at the focus point. If you select attributes before parking, those selected are parked at the focus point, and the remaining attributes are parked at their existing levels.⁸³

Follow the procedure below to park all attributes of a fixture at a focus point.

Ке	ystrokes:	Action:
1.	Press [Stage].	Selects Live display
2.	[S8], Fixture , [1].	The fixture box appears and is set to fixture 1
3.	Press [Focus Point] [5].	Sets all attributes at focus point 5
4.	Press [S6], Park.	Prompt reads: Press ENTER to park channel(s), press AT to select level, or press RELEASE to unpark channel(s)
5.	Press [Enter].	Parks the fixture

^{83.} See The Only command, page 8, to select fixture attributes.

Unparking fixtures

When you unpark a fixture, all channels patched to that fixture are unparked. After unparking a fixture, its attribute levels revert to the levels the console assigns to them.

Keystrokes:

Action:

- Press [Stage]. Selects Live display
 [S8], Fixture, 1. The fixture box appears and is set to fixture 1
 Press [Park]. Prompt reads: Press ENTER to park channel(s), press AT to select level, or press RELEASE to unpark channel(s)
 Press [Rel]. The fixture is unparked December 2014
 - Prompt reads: Select channel numbers

Chapter 16 Effects

An effect is a cue or a submaster that can run in a variety of patterns called chases. Each effect step contains channels. When the step runs, channel level is controlled when the channel is specifically addressed.

An effect can be positive, with lights starting off and being turned on in patterns, or negative, with lights starting on and being turned off in patterns. It can have up to 100 steps, each of which can last up to 99:59 minutes. The effect may be created in Blind or while viewing the steps in Stage. Steps in the effect are individually controlled for level and timing, and the effect is subject to a separate, overall timing parameter.

This chapter includes the following sections:

- The Blind Effects display
- Creating an effect in Blind
- Creating an effect in Stage
- Modifying the effect
- Modifying step timing and levels
- Effect fade times
- Setting a random effect rate
- Running an effect cue
- Using an effect submaster

Blind Effects display

Effects may be created or edited in the Blind Effects display. You enter the Blind Effects display from Blind as soon as you specify the effect type for a new cue or submaster. You also enter the Blind Effect display as soon as you specify a cue or submaster that already exists as an effect. An illustration of the Blind Effects display for a cue is shown below.

							B1 08:3	ind O AM						Ste	р 3	
Attr	ibute	s: Po	sitiv	e			00.0	ю ни			Rando	m rai	tes: 1	00 /	' 10	0
Step 1	Chani 1 FL 01	nel 2 FL 01	3 FL 01	4 FL 01	5 FL 01	6 FL 01	7 FL 01	8 FL 01	9 FL 01		Time 0.2	In 5	Dwell 1	Out 5	Lo O	Hi FL
2	8 90	18 90	28 90	38 90	48 90	68 90									0	FL
3	5 50	6 50	7 50	8 50	9 50						0.2	5	1	5	0	FL
Not I	Recor	(To ded	olean	step	(s),	Sele selec	ot st ste	ep nu p num	mber ber(:	(s) s), th	ien pr	ess (LEAR)			
Cue, 1	/Type EF	Up 0	Dw Ho	ell [Id	lown O	Link	Follo	w Rat 200	re Lat)	bel			Cues	left	: 5	97
S'	1 tep		i2 We list	Sp Sh	is iread ieet	Pre P	4 Vilous lage	s h	lext Page	De	18 21ete Cue	h Sof	in Iore Ptkeys	F Cho	ldd Inne	ls

Features

The following information is contained in the Blind Effects display.

- **Attributes** There are seven attributes of an effect which control how it plays its steps.⁸⁴
- **Random rates** When an effect has random rates, its steps run at randomly selected step times and step fade times. The randomness varies between two, editable limits that are shown in the display.
- **Step** Each effect is composed of steps. There can be up to 100 steps in an effect and each step contains one or more individual channels. The number of channels in an effect step is limited only by the number of channels available to the console.
- **Channel** This field in the effect display shows the channels in each step.
- **Time** The Step Time, which is measured from the beginning of a step to the beginning of the next step. Default Step Time is 0.2 seconds.
- In The In Time, the meaning of which depends upon whether the effect has a positive or negative attribute. For a positive effect, the In Time is the time the effect step takes to fade from its starting level to its High Level. For a negative effect, the In Time is the time the effect step takes to fade from its starting level to its Low Level. Default In Time is zero seconds.
- **Dwell** The time between the end of the infade and the start of the outfade is called the dwell. Default Dwell time is zero seconds.⁸⁵

^{84.} See Modifying effect attributes, page 212.

- **Out** The Out Time, the meaning of which depends upon whether the effect has a positive or negative attribute. For a positive effect, the Out Time is the time the effect step takes to fade from its High Level to its Low Level. For a negative effect, the Out Time is the time the effect step takes to fade from its Low Level to its High Level. Default Out Time is zero seconds.
- Lo Known as Low Level, this is the lowest level the effect is allowed to reach. The default Low Level is zero.
- **Hi** Known as High Level, this is the highest level the effect is allowed to reach. The default High Level is Full.

Effects in Stage

You can also create effects in the normal Stage display, where you can see effect steps as you create them. The only difference between effects and other types of cues in this display lies in the information provided in the Attribute Bar.

Below is an illustration of the Stage display for an effect cue. The illustration shows the softkeys presented and information contained in the Attribute Bar when step 7 of this cue is identified.

	Stage											Step 7													
											03	3:32	2 PI	1											
	001	02	03	04	05	006	07	08	09	10	011	12	13	14	15	016	17	18	19	20	021	22	23	24	25
	026	27	28	29	30	031	32	33	34	35	036	37	38	39	40	041	42	43	44	45	046	47	48	49	50
	051	52	53	54	55	056	57	58	59	60	061	62	63	64	65	066	67	68	69	70	071	72	73	74	75
	076	77	78	79	80	081	82	83	84	85	086	87	88	89	90	091	92	93	94	95	096	97	98	99	00
	101	02	03	04	05	106	07	08	09	10	111	12	13	14	15	116	17	18	19	20	121	22	23	24	25
	Select step number																								
l	Cue/ 1	′Ste Zī	P ,	Tin O,	ne 2	In O	[Jwe O		001 (l)	_0 0	H I FL	i -	Lat	bel					Cue	s I:	ef†	: 5	98
	S	1		s	32		5	33			S4			S5			S6			S	7		S	в	
																Γ				Me Sofi	one tkey	5	s	tep	

^{85.} For the default condition of 0/0/0 for In/Dwell/Out, however, the step has an instantaneous In fade, remains there for the entire Step Time and then has an instantaneous Out fade.

Creating an effect in Blind

The first step in creating an effect is the same for Stage or Blind. Following is the procedure for creating the effect in Blind.

Кеу	vstrokes:	Actions:						
1.	Press [Blind] [1] [Type].	The blind display defaults to cue selection and you specify cue 1 Prompt reads: Select fade type (1=Crossfade, 2=Allfade, 3=Effect, 4=Subroutine, 5=Blocking)						
2.	Press [3].	Specifies an effect type. You are presented with the Blind Effects display. Prompt reads: Select step number(s) (To clear step(s), select step number(s), then press CLEAR)						

Following is a table illustrating how to navigate in the Blind Effects display and the resulting feedback.

Navigation and Feedback - Blind Effects Display								
	7 8 9 4 6 6 1 2 3	[S]	≜ ♦	44	±			
Select a step	х	Х	Х		Х			
Select a field		Х		Х				
White row	selected step							
Yellow field ^a	selected field							

^{a.} If the channel field is selected, all channels are highlighted white except for a selected channel, which is colored yellow.

Once you have specified an effect type, you may proceed to specify steps, either one at a time or in ranges, and add channels to them. Specify steps by identifying the next one in sequence or by moving through steps with the up/down arrow keys.

Only steps that contain channels will be active in the effect. Add channels to an effect step in any of the following ways:

- directly, either individually or in a range
- in groups, focus points or channels linked to a focus point⁸⁶
- in grouped cues or submasters

^{86.} Channels added in a focus point or linked to a focus point automatically change in the step whenever they change in the focus point.

Notes on working with steps in Blind

- Steps may be specified one at a time or in ranges.⁸⁷ •
- Channels at Full in the Blind Effects display do not show the level (except when set at a focus point).
- If you add a channel more than once to a step, it takes the last level assigned.

Adding channels directly

The procedure for creating steps by adding channels to them in the Blind Effects display is shown below.

Keystrokes:

Actions: Specifies next step to be created. 1. Press [S1], Step, and enter Prompt reads: the step number. A new Select step number(s) step must always have the (To clear step(s), select step next highest number. number(s), then press CLEAR) beginning with step 1. Specifies channels to be added. 2. Press [Chan] [1] [Thru] [5]. Prompt reads: Select channel number(s) and press ADD CHANNELS to add to step(s), or press AT to edit existing channel levels Adds channels to step at level 50. 3. Press [S8], Add Channels, Prompt reads: [At] [5][0]. Select channel number(s) and press ADD CHANNELS to add to step(s). or press AT to edit existing channel levels Records the channels to the effect 4. Press [Record] [Enter]. step. Prompt reads: Select cue number To write effect, press STEP

^{87.} Channels, groups, focus points, or grouped channels may be added one at a time or in multiples. If added in multiples and the number to be added exceeds the number of steps specified, they are assigned on a one-to-one basis in a rotating order to all specified steps. For example, adding channels 1 through 10 to steps 1 through 4 results in the following assignment:

<u>Channels</u>	
Step 1	1, 5, 9
Step 2	2, 6, 10
Step 3	3, 7
Step 4	4, 8

Adding groups or focus points

The procedure for creating steps by adding groups or focus points to them in the Blind Effects display is shown below. All channels in a group or focus point are added to the step(s) together but they may be edited individually later.

Keystrokes:

Actions:

- Specifies next step to be created. 1. Press [S1], Step, and enter Prompt reads: the step number. A new Select step number(s) step must always have the (To clear step(s), select step next highest number, number(s), then press CLEAR) beginning with step 1. 2. Press [Group] [5] [Thru] Selects groups 5 through 10. [1][0].^a Prompt reads: Group mode - Select group(s) and press ADD CHANNELS to add to step(s), or press AT to edit existing channel level(s) 3. Press [S8], Add Adds groups' channels to step. Channels. Prompt reads: Group mode - Select group(s) and press ADD CHANNELS to add to step(s), or press AT to edit existing channel level(s) Records the channels to the effect 4. Press [Record] [Enter]. step. Prompt reads: Select cue number To write effect, press STEP
 - ^{a.} To add focus points rather than groups, press [Focus Point] rather than [Group] in this step.
Adding grouped channels

The procedure for creating steps in the Blind Effects display by adding grouped channels from cues or submasters to them is shown below. All channels in a group or focus point are added to the step(s) together but they may be edited individually later.

Keystrokes:

Actions:

1.	Press [S1], Step , and enter the step number. A new step must always have the next highest number, beginning with step 1.	Specifies next step to be created. Prompt reads: Select step number(s) (To clear step(s), select step number(s), then press CLEAR)
2.	Press [Group] [Cue] [5] [Thru] [1][0]. ^a	Selects the channels of cues 5 through 10. Prompt reads: Group mode - Select focus point(s) and press ADD CHANNELS to add to step(s), or press AT to edit existing channel level(s)
3.	Press [S8], Add Channels , [At] [5][0].	Adds channels to step at level 50 Prompt reads: Group mode - Select focus point(s) and press ADD CHANNELS to add to step(s), or press AT to edit existing channel level(s)
4.	Press [Record] [Enter].	Records the channels to the effect step. Prompt reads: Select cue number To write effect, press STEP

^{a.} To add grouped submasters rather than grouped cues, press [Submaster] rather than [Cue] in this step.

Creating an effect in Stage

Build an effect in Stage while viewing the results with captured channels. You can work with individual channels or with channels in cues, groups or focus points. Channels may be added to steps in any of the following ways:

- directly, either individually or in a range
- in groups or focus points
- linked to a focus point⁸⁸
- in grouped cues or submasters

Notes on working with steps in Stage

- You may only add channels to one step at a time.
- Steps may be specified in any order but always default to the next highest one in order. To specify a step number, Press [S7], More Softkeys, until [S8] reads Step. Then press [S8] and enter the step number
- If a channel is added to a step more than once, its level will be the last one assigned.

Adding channels directly

The procedure for creating an effect in Stage and adding channels to its steps is shown below.

Keystrokes:		Actions:
1.	Press [Stage] [Cue] [5].	Specifies cue 5 Prompt reads: Select cue number To select cue type, press TYPE
2.	Press [Type] [3].	Defines the cue as an effect type Prompt reads: Select channel numbers
3.	Press [1] [Thru] [9] [Full].	Selects channels to add and assigns them a level Prompt reads: Select channel numbers
4.	Press [Record] [Enter]. ^a	Records the step and advances the step indicator to the next in sequence Prompt reads: Select channel numbers
5.	Repeat steps 3-4 to create other steps. ^b	

- ^{a.} Specify the step number after [Record] if you do not want to create the next step in order. See Notes on working with steps in Stage, page 204.
- ^{b.} You may also use either of the other two methods discussed in this section to create additional steps.

^{88.} The level of a channel linked to a focus point automatically changes in the step if the level changes in the focus point.

Adding groups or focus points

The procedure for creating an effect in Stage and adding one or more recorded groups or focus points to its steps is shown below.⁸⁹

Ke	ystrokes:	Actions:	
1.	Press [Stage] [Cue] [6].	Specifies cue 6 Prompt reads: Select cue number To select cue type, press TYPE	
2.	Press [Type] [3].	Defines the cue as an effect type Prompt reads: Select channel numbers	
3.	Press [Group] [5] [And] [8] [Full]. ^a	Captures groups 5 and 8 at full on stage Prompt reads: Group mode - Press AT or use wheel or trackpad to alter levels, or select channels numbers to edit	
4.	Press [Record] [Enter]. ^b	Records the step and advances the step indicator to the next in sequence Prompt reads: Select channel numbers	
5.	Repeat steps 3-4 to create other steps. ^c		

- ^{a.} Substitute [Focus Point] for [Group] to add one or more focus points.
- ^{b.} Specify the step number after [Record] if you do not want to create the next step in order. See Notes on working with steps in Stage, page 204.
- ^{c.} You may also use either of the other two methods discussed in this section to create additional steps.

^{89.} Channels added in Stage in focus points do not update in the effect whenever the focus point changes.

Adding grouped channels

The procedure for creating steps in the Stage by adding channels grouped from cues or submasters is shown below.

Key	/strokes:	Actions:
1.	Press [Stage] [Cue] [7].	Specifies cue 7 Prompt reads: Select cue number To select cue type, press TYPE
2.	Press [Type] [3].	Defines the cue as an effect type Prompt reads: Select channel numbers
3.	Press [Group] [Cue] [1] [And] [2] [Full]. ^a	Captures the channels of cues 1 and 2, setting all to full Prompt reads: Group mode - Press AT or use wheel or trackpad to alter levels, or select channels numbers to edit
4.	Press [Record] [Enter]. ^b	Records the step and advances the step indicator to the next in sequence channels to the effect step Prompt reads: Select channel numbers
5.	Repeat steps 3-4 to create other steps. ^c	
	^{a.} To add grouped submast	ers rather than grouped cues, press

- [Submaster] rather than [Cue] in this step.
 b. Specify the step number after [Record] if you do not want to create the next step in order. See Notes on working with
- steps in Stage, page 204.
 ^{c.} You may also use either of the other two methods discussed in this section to create additional steps.

Modifying the effect

You can set channel levels or add channels to steps with Update in Stage. In Blind, however, you can do these and many more editing functions, such as deleting channels from steps, inserting or deleting steps and modifying the attributes of the effect. The first procedure, below, applies to Stage, and all the rest in this section apply only to Blind.

Using Update

With Update, you can do live editing of effect steps in Stage and see the results immediately on stage. Use the procedure below to add channels and set levels for effect cue 100, assumed to have been previously created.

Кеу	/strokes:	Action:
1.	Press [Stage] [Cue] [1][0][0].	Selects effect cue 100 in Stage
2.	Press [S8], Fixture , [4] [Thru] [6] [Full].	Selects fixture 4 and 6 and sets their intensity levels to full
3.	Set the pan and tilt levels. ^a	Sets the levels of the position attributes of all selected fixtures
4.	Press [S2], Update .	Prompt reads: To update cue, select number and press ENTER To update step, press STEP
5.	Press [S7], More Softkeys , until you see Step at softkey [S8].	
6.	Press [S8], Step , [1].	Selects step 1 Prompt reads: Select step number
7.	Press [Only] [S8], Fixture , [5]. ^b	Restricts the update to fixture 5 Prompt reads: Select fixture number(s) To cancel, press CLEAR
8.	Press [Enter].	Updates step 1 of cue 100
9.	Press [Rel][Rel].	Clears captured channels
10.	Repeat steps 2 through 8.	Update other steps in the same cue

^{b.} Optional step. If not restricted with Only, all captured and selected channels are included in the update. For more information on the uses of Only, see The Only command, page 8.

Editing channel levels

Regardless how channels were added to the effect, channels may be individually edited in the effect, either individually or in ranges. Levels may be set with the keypad or with reference to focus points.

Follow the procedure below to edit channel levels in a recorded effect cue that has at least 5 steps. Levels are set with reference to a focus point.

Keystrokes:

Actions:

1.	Press [Blind] [Cue] [1].	Go to the Blind Effects display Prompt reads: Select cue number
		To write effect, press STEP
2.	Press [S1], Step , [5].	Specifies step 5 Select step number(s) (To clear step(s), select step number(s), then press CLEAR)
3.	Press [Chan] [5] [And] [8].	Selects channels 5 and 8 Prompt reads: Select channel number(s) and press ADD CHANNELS to add to step(s), or press AT to edit existing channel level(s)
4.	Press [At] [Focus Point] [1] [Enter].	Sets levels of channels 5 and 8 to their levels in focus point 1
5.	Repeat steps 2-4 to set levels in other steps. Alternatively, use the up/ down arrow keys to move to other steps for editing.	Continue to edit channels
6.	Press [Record] [Enter].	Records your changes to the cue

Adding channels

Add additional channels to an effect step using any of the procedures used to add channels when the step was created. See *Creating an effect in Blind, page 200*.

Deleting channels

Delete channels from a previously created effect step with the following procedure.

Key	ystrokes:	Actions:
1.	Press [Blind] [Cue] [1].	Go to the Blind Effects display Prompt reads: Select cue number To write effect, press STEP
2.	Press [S1], Step , [5].	Specifies step 5 Select step number(s) (To clear step(s), select step number(s), then press CLEAR)
3.	Press [Chan] [5] [And] [8].	Selects channels 5 and 8 Prompt reads: Select channel number(s) and press ADD CHANNELS to add to step(s), or press AT to edit existing channel level(s)
4.	Press [Clear].	Deletes channels
5.	Press [Record] [Enter].	Records your changes to the cue

Inserting steps

You may insert a new step in place of an existing one in an effect. The inserted step takes the place of the selected step and other steps are renumbered. For instance, if inserting a step at number 5, the existing step 5 becomes step 6; step 6 becomes step 7, and so on. The timing and level settings from step 4 are set as initial settings in the new step 5.

For example, to insert a step between steps 4 and 5, follow these steps:

Keystrokes:		Action:	
1.	Press [Blind] [Cue] [2].	Selects cue 2	
2.	Press [S7], More Softkeys.		
3.	Press [S5], Insert Step .	Prompt reads: Select step number to insert, then press ENTER To cancel, press CLEAR	
4.	Use the $[\uparrow]$ and $[\downarrow]$ keys to highlight the step you wish to insert or Enter the number of the step.	Prompt reads: Select step number to insert, then press ENTER To cancel, press CLEAR	
5.	Press [Enter].	Prompt reads: Select channel number(s) and press ADD CHANNELS to add to step(s), or press AT to edit existing channel level(s)	
6.	Add channels using one of the techniques available.		
7.	Press [Record] [Enter].	Records your changes to the cue	

Deleting steps

You may delete any step from an effect, which causes other steps to be renumbered. For instance, if deleting step 5, step 6 becomes step 5; step 7 becomes step 6, and so on.

For example, to delete step 5, follow these steps.:

Keystrokes:		Action:
1.	Press [Blind] [Cue] [2].	Selects cue 2
2.	Press [S7], More Softkeys.	
3.	Press [S6], Delete Step .	Prompt reads: Select step number to delete, then press ENTER To cancel, press CLEAR
4.	Use the [↑] and [↓] keys to highlight step 5.	Selects step 5
5.	Press [Enter].	Deletes step 5 Prompt reads: Select step numbers
6.	Press [Record] [Enter].	Records your changes to the cue

Modifying effect attributes

Attributes control how the effect plays its steps. Set effect attributes by pressing [S7], **More Softkeys**, [S8], **Attribute**. Except for setting a random rate, make one or more softkey selections. Each softkey toggles the effect attribute, so pressing it can either add or remove the selection.

Effect attributes are defined as follows:

- **Positive/Negative** Softkey [S1] toggles between the positive and negative attributes. Steps in a positive effect set their channels to their High Level and set the channels of the previous step to their Low Level. Steps in a negative effect set their channels to their Low Level and set the channels of the previous step to their High Level.
- **Alternate** Sets the effect to alternate between positive and negative chases through its steps. The first pass is positive if the effect is positive, negative if the effect is negative.
- **Reverse** Effect steps run in reverse numerical order.
- **Bounce** Steps run first in forward, then in reverse order. Subsequent passes alternate between forward and reverse.
- **Build** All channels are set to their Low Level at the beginning of the chase. Each step turns its channels to their High Level and leaves the previous step at the High Level. At the end of the chase, all channels are at the High Level. They are all set at their Low Levels to start the next pass. In a negative effect, all steps are at their High Levels at the beginning of the chase. Each step turns its channels to the Low Level and leaves previous channels at the Low Level. At the end of the chase, all channels are at the Low Level. At the end of the chase, all channels are at the Low Level. They are all set at their High Levels to start the next pass.
- **Random** A Random effect plays steps back in random order. An effect with a random rate runs at varying speeds, changing at random, within a range that you select. The console applies a random rate to the assigned step time and to the step fade times. Random is ideal for creating lightning and fire effects.

The rules for assigning effect attributes are as follows.

- All effects are either Positive or Negative. An effect is initially positive when it is created.
- Alternate, Reverse, Bounce, and Build can be applied in any combination to a Positive or a Negative effect.
- Random can be applied to any Positive or Negative effect. Random may not be combined with Alternate, Reverse, Bounce, or Build.

Modifying step timing and levels

Once all steps are defined for an effect, you can either accept the defaults or you can change one or more settings in a single operation. The step defaults are as follows:

- Step Time 0.2 seconds
 - In Time 0 seconds
- Dwell Time 0 seconds
- Out Time 0 seconds
- Low Level Zero
- High Level
 Full

٠

Set step timing and levels of a recorded effect with the following procedure. $^{90}\,$

Ке	ystrokes:	Actions:
1.	Press [Blind] [Cue] [1].	Go to the effects display for a previously recorded effect cue Prompt reads: Select cue number To write effect, press STEP
2.	Press [S1], Step , [5].	Specifies step 5 Prompt reads: Select step number(s) (To clear step(s), select step number(s), then press CLEAR)
3.	Press [S7], More Softkeys , [S2], Step Time .	Selects step time field Prompt reads: Select step time
4.	Press [1][0] [Enter].	Sets step time to 10 seconds and advances to the next field Prompt reads: Select step in time
5.	Press [2] [Enter].	Sets step in time to 2 seconds and advances to the next field Prompt reads: Select step dwell time
6.	Press [6] [Enter].	Sets dwell time to 6 seconds and advances to the next field Prompt reads: Select step out time

 $^{^{90.}}$ Press [\rightarrow] or [Enter] without a number to skip any selection.

7.	Press [2] [Enter].	Sets step out time to 2 seconds and advances to the next field Prompt reads: Select low level
8.	Press [1][0]. ^a	Sets low level to 10 and advances to the next field Prompt reads: Select high level
9.	Press [9][0]. ^b	Sets high level to 90 and advances to the next field Prompt reads: Select step number(s) (To clear step(s), select step number(s), then press CLEAR)
10.	Press [↑] or [↓] and repeat steps 3-9 above.	Make changes to another step
11.	Press [Record] [Enter],	Records your changes to the cue
	a. A one-digit entry must	be followed by [Enter] and is

- ^{a.} A one-digit entry must be followed by [Enter] and is interpreted as the digit times 10.
- ^{b.} A one-digit entry must be followed by [Enter] and is interpreted as the digit times 10.

Effect fade times

Each effect has an overall upfade, dwell and downfade time. When you create an effect cue, the times default to the cue fade times in your system settings. If you have not changed the default settings, this means an upfade of zero seconds, a dwell of **hold**,⁹¹ and a downfade⁹² of zero seconds. Press [Time] to set the effect's upfade, dwell and downfade times.

Fade times may be programmed from 0.1 seconds to 99:59 minutes. The number may be entered in normal time format or in decimal format. When entered with a decimal point, the number must be less than one minute (0.1 to 59.9 seconds) to be accepted. When entered without a decimal point, a 2-digit number will be treated as seconds if less than 60 and as a calculated value of minutes and seconds if between 60 and 99. For example, if you enter 70, the time will display as 1:10. If you enter either a 3-digit or a 4-digit number, the last two digits, up to 59, are interpreted as seconds. For example, if you enter 9930, the time will display as 99:30.

^{91.} Dwell time is the length of time the effect runs between the upfade of the first step and the downfade of the last step. **Hold** assigns an infinite dwell time, meaning the effect runs until an associated [Clear], [Go] or bump button is pressed to start the downfade.

^{92.} See Setting default fade times, page 24.

Changing upfade, dwell and downfade

Follow these steps to change the effect's fade times:

Keystrokes:		Action:
1. Press [Blind] [Cue] [2].	Selects cue 2 in the Blind display
2. Press [Time] a upfade time.	ind enter the	Prompt reads: Enter effect upfade time
3. Press [Time] a dwell time.	ind enter the	Prompt reads: Enter effect dwell time
4. Press [Time] a downfade tim [Clear] for hold	ind enter the e. Press d dwell.	Prompt reads: Enter effect downfade time
5. Press [Enter].		Fade time entry is complete Prompt reads: Select step numbers

Changing upfade only

Follow these steps to change only the effect's upfade time:

Keystrokes:		Action:
1.	Press [Blind] [Cue] [2].	Selects cue 2 in the Blind display
2.	Press [Time].	Prompt reads: Enter effect upfade time
3.	Enter the upfade time.	Prompt reads: Enter effect upfade time
4.	Press [Enter] [Enter] [Enter].	Prompt reads: Select step numbers

Changing downfade only

Follow these steps to change only the effect's downfade time:

Ke	ystrokes:	Action:	
1.	Press [Blind] [Cue] [2].	Selects cue 2 in the Blind display	
2.	Press [Time] [Time] [Time].	Prompt reads: Enter effect downfade time	
3.	Enter the downfade time.	Prompt reads: Enter effect downfade time	
4.	Press [Enter].	Prompt reads: Select step numbers	

Changing dwell only

Follow these steps to change only the effect's dwell time:

Action:
Selects cue 2 in the Blind display
Prompt reads: Enter effect dwell time
Prompt reads: Enter effect dwell time
Prompt reads: Select step numbers

Resetting hold dwell time

4. Press [Enter] [Enter].

If the dwell time is set to **Hold**, an effect submaster will continue to run until you press the bump button. An effect cue will continue to run until you press either [Go] or [Hold] [Hold]. To reset the dwell time to **Hold** follow these steps:

Keystrokes:

Action:

- Press [Blind] [Cue] [2]. Selects cue 2 in the Blind display
 Press [Time] [Time]. Prompt reads: Enter effect dwell time (Press CLEAR for hold)
 Press [Clear]. Hold appears in the Dwell box of the cue attribute line
 - Dwell time set to **Hold** Prompt reads: **Select step numbers**

Setting a random effect rate

An effect runs at a rate set by the submaster or cue in which the effect is recorded.⁹³ It can also run at a random rate within minimum and maximum parameters. Set the minimum and maximum parameters with the following procedure to control the range of randomness of the effect.

Key	ystroke:	Action:
1.	Press [Blind] [Cue] [2].	Selects cue 2 in the Blind display
2.	Press [S7], More Softkeys, [S8], Attribute.	Displays available attributes across the bottom of the screen
3.	Press [S7], Random Rate.	Prompt reads: Select low random rate (0 to 2000, 100=Normal)
4.	Press [5][0] [Enter].	Specifies the slowest effect rate Prompt reads: Select high random rate (0 to 2000, 100=Normal)
5.	Press [2][0][0][Enter].	Specifies the highest effect rate
	 1. 2. 3. 4. 5. 	 Press [Blind] [Cue] [2]. Press [S7], More Softkeys, [S8], Attribute. Press [S7], Random Rate. Press [5][0] [Enter]. Press [2][0][0][Enter].

Running an effect cue

Play back effects recorded as cues on the console's A/B or C/D faders, just as you would any other cue. The effect will run, using the cue's Up, Dwell and Down times to determine how long the cue lasts. To run the cue, press [Stage] [Cue], enter the effect cue number, and press [Go].

An effect cue with a **Hold** dwell time runs on the fader until you press that fader's [Clear] key to begin the downfade. Press [Clear] once to fade out an effect cue in the recorded downfade time. Press the fader's [Clear] key twice to cancel an effect from the fader immediately.

You may use the playback sliders to manually control the cue, allowing you to fade the effect up and down with the playback slider.

Using an effect submaster

An effect recorded to a submaster interacts with cues and other submasters on a pile-on basis.⁹⁴ Bring up the effect by pressing the submaster's bump button or raising the slider.

An effect submaster fades proportionally between zero and the effect's high level. The slider acts as a master. If the effect's low level is normally 10 percent, moving the slider to 50 percent will reduce the effect's low level to 5 percent.

^{93.} Adjusting the rate does not affect the overall Up/Dwell/Down times for the cue or submaster. It does, however, speed up or slow down the individual steps. For information about controlling cue or submaster rates, see pages Rate override, page 126 and Live control of a submaster's rate, page 167.

^{94.} See Adding a rate to a submaster, page 160 for information on changing the rate of a submaster.

Chapter 17 Subroutines

A subroutine is a cue that controls the playback of a series of recorded cues. Subroutines are similar to linked cues, except that they have more playback options.

You can use subroutines and effects to create similar looks. However, subroutines have some advantages over effects. You can also create nested loops or even use an effect cue as a step in a subroutine.

This chapter contains the following sections:

- Steps
- Cue steps
- Style steps
- Creating a subroutine
- Editing a subroutine
- Deleting a step
- Inserting a step

Steps

All subroutine steps are either cue steps or style steps. A cue step contains an existing recorded cue, which may be an effect cue. The subroutine lets you change levels and fade rates for the cue step without changing the original cues.

A style step contains an instruction that controls the subroutine's playback pattern. This allows you to run loops, run bounces, pause the subroutine until you press go, or end the subroutine and jump to any other cue. The following display shows a subroutine that runs a series of cues in a loop.

		02	Blind ∶31 PM			Cue 77
Step 1 2 3 4 5 6 7 8 9 10	Subroutine Cue 33 Cue 36 Cue 38 Cue 38 Cue 34 Cue 37 Cue 37 Cue 35 Cue 39 Loop to Stor	Crossfade † Crossfade † Crossfade † Crossfade † Crossfade † Crossfade † Crossfade † Crossfade †	o 100% o 100% o 100% o 100% o 100% o 100% o 100% o 100% o 100% Times	អ្ន ភ្នេស ទេ ទេ ទេ ទេ ទេ ភ្ន	Down 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5	Follow 5555555555555555555555555555555555
	1	Select To write subr	cue number outine, pres	s STEP		
Cue/Type 77 SR	Time Subroutine	Rat	e Lobel SUBCUE7	7	Cues	left: 579
S1 Step	S2 S3 Cue List Ro	3 S4 Previo ate Page	us Next Page	S6 Delete Cue	S7 More Softkeys	<u>\$8</u>

The next two pages describe the types of cue and style steps that are available.

Cue steps

There are three types of cue steps.

Crossfade
 A crossfade step is a cue in which all increasing levels fade in the upfade time and all decreasing levels fade in the downfade time.
 Allfade
 An allfade step is a cue in which all channels in both faders fade to a level that you choose and assign to the step.
 Blocking
 A blocking step is a cue that first stops all background cues from running before it runs in a physical fader.

Style steps

The following playback styles are available for subroutines. A style is assigned to a step. When the subroutine runs, the steps play back in numeric order, until the subroutine reaches a style step. The style step then determines whether the subroutine will loop, bounce, hold, or end and run a different cue.

- **Loop** The subroutine runs through steps until it reaches a Loop step. It then returns to the first step, and repeats the sequence for the number of times you specify. When you create the Loop step, enter the number of times you want the loop to return to the top of the step list. If you enter **5**, the sequence will play six times. Enter **0** to create a continuous loop.
- **Bounce** The subroutine runs through steps until it reaches a Bounce step. It then runs back through the steps in reverse order, and repeats the sequence for the number of times you specify. When you create the Bounce step, enter the number of times you want the subroutine to bounce. One bounce equals running through the sequence forward once and reverse once. Enter **0** for a continuous bounce.
- **Jump-to-cue** The subroutine runs through steps until it reaches a Jump-to-cue step. It then automatically starts another cue which is not included in the subroutine. You can jump to any type of cue: regular, subroutine or effect. When you create the Jump-to-cue step, enter the number of the cue to which to jump.
- **Hold-for-Go** The subroutine runs through steps until it reaches a Hold-for-Go step. It then pauses until you press [Go].

Subroutine attributes

The following attributes may be applied to each cue step.

- Level Sets an intensity level for the cue within the subroutine. The level proportionally affects the channel levels assigned to the original cue. Levels must be entered as two-digit numbers (e.g., **20** for 20 percent, **05** for five percent). Use [Full] for 100 percent.
- **Fade times** Upfade times may range from 0.1 seconds to 99:59 minutes. If you do not enter a time, the downfade will match the upfade.
- **Follow time** Follow time is the time between the start of one step and the start of the next. Follow times may range from 0.1 seconds to 99:59 minutes.

Creating subroutines

Create subroutines in the Blind display. A subroutine can have up to 100 steps. Each step lists a cue or a style.

To create a subroutine, follow these steps:

Key	strokes:	Action:
1.	Create the cues you want to use in your subroutine.	
2.	Press [Blind].	Displays Blind mode screen
3.	Press [Cue] [7].	Selects cue 7
4.	Press [Type].	Displays fade type menu Prompt reads: Select fade type (1 = Crossfade, 2 = Allfade, 3 = Effect, 4 = Subroutine or 5=Blocking)
5.	Press [4], Subroutine .	Select subroutine fade type Prompt reads: Select step number(s), then press ENTER
6.	Press [1] [→].	Selects step 1. Prompt reads: Enter cue number to fade, or press STYLE to change step type
7.	Press [1] [→].	Selects cue 1 for step 1 Prompt reads: Enter type of cue (1 = Crossfade, 2 = Allfade, 3 = Blocking)
8.	Press [1].	Designates cue as a crossfade within the subroutine. Prompt reads: Enter intensity
9.	Press [5][5].	Selects a level of 55 percent for the cue within the subroutine Prompt reads: Enter upfade time
10.	Press [8] [→].	Sets an upfade time of 8 seconds Prompt reads: Enter downfade time
11.	Press [→].	Sets a downfade time of 8 seconds Prompt reads: Enter follow time
12.	Press [2][0].	Sets a follow time of 20 seconds. Step 1 is now complete
13.	Press [S1], Step , [2] [Enter].	Selects step 2 to edit
14. l	Repeat steps 7 through 13.	Adds additional steps to the subroutine

15. Press [S1], **Step**, [6] [Enter].

17. Press [3] [Enter].

18. Press [8] [Enter].

16. Press [S8], Style, to select a subroutine style. (You may need to press [S7],

Selects step 6 to edit

Prompt reads: Select style of subroutine command (1 = Loop, 2 = Bounce,3 = Jump to cue, 4 = Hold for go) More Softkeys, first.)

> Selects Jump to cue style for step 6 Prompt reads:

Select cue number

Selects cue 8 for Jump to cue. When subroutine reaches step 6, the subroutine ends and runs cue 8. Prompt reads:

Enter blocking status for jump to cue (1=Blocking, 2=No blocking)

Specifies that the cue will not cause blocking

- 19. Press 2.^a
- 20. Complete entering all cue steps and style steps as described above.
- 21. Press [Record], enter cue number, and press [Enter] to record subroutine cue.
 - ^{a.} Blocking is the default.

Editing a subroutine

To edit a subroutine, select the step you wish to change by pressing [S1], **Step**, and entering the step number. Use [And] and [Thru] to select multiple steps. ⁹⁵ You can either use softkeys to find your way around the Step Display or navigate with other console controls, as shown in the following table.

Navigation and Feedback - Step Display					
	7 8 9 4 6 6 1 2 3	[S]	≜ ♦	4	±
Select a step	Х	Х	Х		Х
Select a field		Х		Х	
White row	selected step				
Yellow field		sel	ected fi	eld	

The softkeys available in the display are as follows.

[S2], Style	Allows you to select a style from the style menu.
[S3], Select Cue	Allows you to enter a cue number for the selected step.
[S4], Type/Level	Allows you to select a crossfade or an all- fade and to set intensity level.
[S8], Up/Down/Follow	Allows you to set upfade and downfade times and to set follow time.

Once you finish editing the subroutine, press [Record] [Enter] to save your changes.

Deleting a step

Press [S6], **Delete Step**, and enter the step number. Then press [Enter]. The console deletes the selected step and renumbers the remaining steps.

Inserting a step

Press [S1], **Step**, and enter the step number where you want to insert the new step. Then press [Enter]. The console inserts a blank step before the selected step.

^{95.} If you select a range of steps, only cue steps will be selected. Style steps may only be edited individually and will be left out of selected ranges.

Chapter 18 Macros

A macro allows you to record a series of keystrokes and later replay it with one or two keystrokes. This can simplify complex tasks that you perform often. You can record up to 2,000 macros, depending on how large they are.

This chapter includes the following sections:

- Creating macros
- Playing macros
- Modifying macros
- Clearing macros
- Copying macros
- Sample macros

Creating macros

There are two ways to create a macro. You can create it in Macro Editing mode, entering and editing keystrokes without actually executing the instructions, or you can use the console's macro Learn mode to record a sequence of keystrokes as you perform the operation.

You can include any key or button on the console except [Enter Macro] in a macro.⁹⁶ You cannot enter slider settings or wheel movements. Each macro can contain up to 50 keystrokes. You can also link macros.

Caution: The console does not check the sequence of keystrokes to confirm that it will work. It is possible to create macros that don't work. When you run the macro, you will receive whatever error messages are appropriate.

To avoid problems, you should plan your macro before you start recording it by determining exactly what keystrokes you want to include. You might want to do this by running through the task and writing down each keystroke.

Using Learn

The Learn function allows you to create a macro by performing an actual sequence of keystrokes. The console records the keystrokes as you make them. The recorded keystroke sequence can then be played by pressing the appropriate macro key. Once you record a macro in Learn mode you can edit the sequence in Macro Editing mode to adjust its operation. Learn works in any display mode except the Macro Editing display and the Designer's Worksheet Editing display.

Action:

To create a sample macro using Learn, follow these steps:

Keystrokes:

Selects Live display mode 1. Press [Stage]. 2. Press [Learn]. Prompt reads: Select macro number to learn, then press ENTER To cancel, press CLEAR 3. Press [7] [Enter]. Learning Macro 7 flashes in red in the upper left corner of the monitor Prompt reads: Select operation(s) for this macro press ENTER MACRO when done (Wheels, trackpad and sliders are not valid entries in macros) 4. Enter [Channel] [1] [Thru] Sets channels 1 through 5 at 50 [5] [At] [5] [Enter]. percent Prompt reads: 5. Press [Macro Wait]. Enter wait time Press ENTER when done

^{96.} Macros cannot execute MIDI commands.

6.	Press [5] [Enter].	Inserts a five second wait into the macro Prompt reads: Select operation(s) for this macro – press ENTER MACRO when done (Wheels, trackpad and sliders are not valid entries in macros)
7.	Enter [Channel] [1] [Thru] [1][0] [Full].	Sets channels 1 through 10 at Full
8.	Press [Macro Wait].	Prompt reads: Enter wait time Press ENTER when done
9.	Press [5] [Enter].	Inserts a five second wait into the macro Prompt reads: Select operation(s) for this macro – press ENTER MACRO when done (Wheels, trackpad and sliders are not valid entries in macros)
10.	Enter [Channel] [1] [Thru] [1][0] [At] [0] [Enter].	Sets channels 1 through 10 at zero
11.	Press [Enter Macro].	Concludes macro recording
12.	Press [M*] [7] [Enter].	Macro 7 runs. Channels 1 through 5 rise to 50 percent. After five seconds, channels 1 through 10 rise to Full. After five seconds, levels drop to zero

Using Macro Editing

The Macro Editing display allows you to create or edit macros without affecting channel levels. Some of the softkeys in this display, such as [S2], **Replace**, and [S7], **More Softkeys**, are for editing purposes only and cannot be entered into a macro. Others, such as [S1], **Select Macro**, and several softkeys available after first pressing [S7], **More Softkeys**, may be entered into a macro. Three keys that cannot be entered into a macro in the Macro Editing display are **Enter Macro**, [\leftarrow], and [\rightarrow].⁹⁷

Insert	Mode Macro Editing Macro 1 11:04 AM		
Масго	Operation(s)		
1	Setup 1 Enter 7 Enter 0 Enter Enter Stage		
2	Setup 1 Enter 7 Enter 1 Enter Enter Stage		
з	Вимр24		
4	Setup 1 Enter 1 0 Enter DWS-Sliders Stage		
5	M6		
6	Bump1 Mwait-0 Bump2 Mwait-0 Bump3 Mwait-0 Bump4 Mwait-0 Bump5 Mwait-0 Bump6 Mwait-0 Bump7 Mwait-0 Bump8 Mwait-0 Bump9 Mwait-0 Bump10 Mwait-0 Bump11 Mwait-0 Bump12 Mwait-0 Bump13 Mwait-0 Bump14 Mwait-0 Bump15 Mwait-0 Bump16 Mwait-0 Bump17 Mwait-0 Bump18 Mwait-0 Bump19 Mwait-0 Bump20 Mwait-0 Bump21 Mwait-0 Bump22 Mwait-0 Bump23 M6		
10	Setup 1 Enter PurgeFlexi Stage		
Select macro number, then press ENTER			
1 Selec Масго	t 2 3 Delete 4 5 6 Delete 7 More 8 Replace Entry Macro Softkeys Return		

^{97.} If your macro needs to contain softkeys that are unavailable in the Macro Editing display, you must use Learn to create it.

Follow these steps to create a macro to record a show to diskette:

Ke	ystrokes:	Action:		
1.	Press [Setup].	Selects Setup display screen		
2.	Select 8, Macro Editing , and press [Enter].	Selects Macro display screen Prompt reads: Select macro number, then press ENTER		
3.	Press [8] [Enter].	Blank macro created Prompt reads: Select operation(s) for this macro – press ENTER MACRO when done (Wheels, trackpad and sliders are not valid entries in macros)		
4.	Press [Setup] [3] [Enter].	Enters setup display Macro contents line reads: SETUP 3 ENTER		
5.	Press [1] [Enter].	Selects Write Show To Disk Macro contents line reads: SETUP 3 ENTER 1 ENTER		
6.	Press [Enter].	Confirms selection Macro contents line reads: SETUP 3 ENTER 1 ENTER ENTER		
7.	Press [Enter Macro].	Stores macro 8		

Macro wait

To program a pause in the macro, press [Macro Wait] at the point in the macro where you want the pause to occur. Enter the time you would like the macro to hold, then press [Enter]. Continue to enter remaining macro commands.

To program a pause in the macro, in the Macro Editing display, press [S7], **More Softkeys**, and insert [S8], **Macro Wait**, at the point in the macro where you want the pause to occur. Enter the time you would like the macro to hold, then press [Enter].

Times may be expressed in minutes and seconds, or as fractions of seconds (in decimal format). Times can be programmed from 0.1 seconds to 99:59 minutes. Acceptable time values include: 0.2 (.2 seconds), 00:12 (12 seconds), 5.5 (5.5 seconds), or 5:30 (five minutes, 30 seconds).

Linking macros

Any macro may end with a link to another macro. When macros are linked, the first macro runs, then the second macro follows automatically. Press the appropriate macro key at the end of your sequence to create the link. Pressing the macro key automatically ends and stores the macro.

For example, to create a macro that sets all active channels to 50 percent, fades them out, then runs another macro, follow these steps:

Keystrokes:

Action:

- Selects Macro editing mode 1. Press [Setup] [8] [Enter]. Selects macro 1 to create 2. Press [1] [Enter]. Prompt reads: Select operation(s) for this macro press MACRO ENTER when done (Wheels, trackpad and sliders are not valid entries in macros) Sets all active channels to 50 percent 3. Press [Enter] [At] [5][0]. Macro line reads: ENTER AT 5 0 Macro pauses for ten seconds 4. Press [Macro Wait][S7], Macro line reads: More Softkeys, [S8], ENTER AT 5 0 Mwait-10 Macro Wait, [1][0] [Enter]. 5. Press [At] [0] [Enter]. Fades all active channels out Macro line reads: ENTER AT 5 0 Mwait-10 **ENTER AT 0 ENTER**
- Stores macro. Links macro to macro 3 6. Press [M3]. Macro line reads: ENTER AT 5 0 Mwait-10 **ENTER AT 0 ENTER M3**

Note: You may also link a macro to a cue so the macro will run at the same time the cue does. See Linking a macro to a cue, page 91, for more details.

Using submasters in macros

Submaster bump buttons can function in macros in three different ways:

- 1. as a normal bump button;
- 2. to always fade a submaster to full (regardless of its current condition);
- 3. to always fade a submaster out (regardless of its current condition).

To include a bump button that starts a timed submaster or changes the direction of a running fade, press the submaster bump button while programming the macro.

Use [S1], **On Sub-Bump**, to fade the submaster up, regardless of its current setting. Use [S2], **Off Sub-Bump**, to fade a submaster out, regardless of its current setting.

To create a macro that turns a submaster on for five seconds, then turns it off, follow these steps:

Key	/strokes:	Action:
1.	Press [Setup] [8] [Enter].	Selects Macro editing mode
2.	Press [4] [Enter].	Selects macro 4 to create Prompt reads: Select operation(s) for this macro – press ENTER MACRO when done (Wheels, trackpad and sliders are not valid entries in macros)
3.	Press [S7], More Softkeys, [S1], On Sub- Bump.	Macro line reads: OnBump Prompt reads: Enter submaster number
4.	Press [3] [Enter].	Macro line reads: OnBump3
5.	Press [Macro Wait][S8], Macro Wait.	Macro line reads: OnBump3 Mwait-0
6.	Enter [5] and press [Enter].	Macro line reads: OnBump3 Mwait-5
7.	Press [S2], Off Sub-Bump.	Macro line reads: OnBump3 Mwait-5 OffBump Prompt reads: Enter submaster number
8.	Press [3] [Enter].	Macro line reads: OnBump3 Mwait-5 OffBump3
9.	Press [Enter Macro].	Records macro 4; leaves editing mode
10.	Press [Stage] [M4].	Macro runs

Playing macros

As a macro runs, the LED in the macro's key flashes. Only one macro may run at a time.

To run macros 1 through 5, press the appropriate macro key. For example, to run macro 1, press [M1].

To play a macro recorded in [M1] - [M5], follow these steps:

Keystrokes:

Action:

- 1. Press [Stage].
 Selects Stage display mode
- 2. Press [M#]. Macro runs; prompt shows sequence of activity as if you were entering the keystrokes

To run any other macro, press [M*], the number of the macro, and [Enter]. For example, to run macro 10, press [M*] [1][0] [Enter].

To play a macro without its own key, follow these steps:

Keystrokes:Action:1. Press [M*] and enter the
macro number.Prompt reads: Select macro number,
then press ENTER2. Press [Enter].Macro runs; prompt shows sequence of
activity as if you were entering the
keystrokes

Canceling a macro

To cancel a running macro, press [M*].

Powerup macro

You may run a macro automatically each time you turn on your console, such as to turn on lights or load a show. To enable the powerup macro feature and select the macro, follow the procedure below.

Keystrokes:Action:1. Press [Setup].Selects the Setup menu2. Press [6] [Enter].Selects the Options Settings menu3. Press [1][0] [Enter].Selects the Powerup Macro option
Prompt reads: Select powerup macro
number (Enter 0 to disable)4. Press [2][0] [Enter].Selects macro 20 as your powerup
macro. Each time you turn on the
console, macro 20 runs

Modifying macros

Editing mode

In the Macro mode display, you can edit macros in Insert or Replace modes. In Insert mode, if you highlight a keystroke and type another keystroke, the console inserts the new keystroke before the highlighted one. In Replace mode, if you highlight a keystroke and type another keystroke, the console replaces the highlighted keystroke with the new one.

To switch from Insert mode to Replace mode, press [S2], **Replace**. To switch from Replace mode to Insert mode, press [S2], **Insert**. The console indicates the editing mode in the upper left corner of the command display.

Editing keys

 $[\leftarrow]$ and $[\rightarrow]$ move the highlight left or right when you are editing a macro.

[S3], Delete entry, deletes highlighted keystroke.

Clearing macros

You must be in Macro display mode to clear individual macros. To clear all macros, you can use the Clear Macros option from the Clear Functions menu, as described on , *page 255*.

To clear identified macros, follow these steps:

Key	/strokes:	Actions:				
1.	Press [Setup].	Selects Setup display				
2.	Press [8], Macro Editing , and press [Enter].	Selects Macro display mode				
3.	Press [S6], Delete Macro .	Prompt reads: To delete macro(s), select macro number(s) and press ENTER To cancel, press CLEAR				
4.	Press [7]. ^a	Corner reads: Macro 7				
5.	Press [Enter].	Prompt reads: To confirm, press ENTER To cancel, press CLEAR				
6.	Press [Enter].	Clears macro 7				

^{a.} In step 4, you may use [And] and [Thru] to enter multiple macros to clear.

Copying macros

You may want to copy a macro or use macros as building blocks for new macros. To copy contents of one macro to another, follow these steps:

Actions: **Keystrokes:** Selects Setup display 1. Press [Setup]. Selects Macro display mode 2. Press [8], Macro Editing, Prompt reads: Select macro number, and press [Enter]. then press ENTER Prompt reads: 3. Press [S7], More To copy macro(s), select macro Softkeys, [S5], Copy number(s) to copy and press ENTER Macro. To cancel, press CLEAR Enters the number of the macro you 4. Press [2].^a wish to copy Corner reads: Macro 2 Prompt reads: 5. Press [Enter]. To copy selected macro(s), select target macro and press ENTER To cancel, press CLEAR Corner reads: Macro 25 6. Press [2][5], the number of the new macro. Macro copy is complete. The contents 7. Press [Enter]. of macro 2 have been copied into macro 25

^{a.} In step 4, you may use [And] and [Thru] to enter multiple macros to copy. If you do, the new macros will be numbered consecutively, starting with the macro you enter in step 6.

Sample macros

To create these sample macros, go to Macro display mode ([Setup] [8] [Enter]), select a macro and enter the keystroke sequences as shown below. More sample macros, created by Expression style console users, are available on ETC's website at www.etcconnect.com.

Channel check

This macro brings each channel up to full for a channel check. Before you begin, you'll probably want to bring up at least one channel for working light, then clear all other channels from stage. Press [Stage] and start macro. Press macro key again to check each subsequent channel.

[At] [0] [Enter] [+] [Full] Macro line reads: **At 0 Enter + Full**

Auto channel check

This macro automatically runs through each channel with a two second wait between each channel, beginning with channel 1. You can effectively pause the check by cancelling the macro at any channel. If you replay the macro after the cancellation, the check begins at the next channel in sequence.

[At] [0] [Enter] [+] [Full] [Macro Wait] [2] [Enter] [M#] Macro line reads: At 0 Enter + Full Mwait2 M# (# = this macro's macro number)

Turn off all lights except work lights

This macro captures all channels and sets them to zero. This overrides all faders and submasters. Then the macro sets work lights at full. You can easily return to previous settings by pressing [Rel] to release captured channels.

[Channel] [1] [Thru] [–] [At] [0] [Enter] [#] [Full] Macro line reads: Chan 1 Thru - At 00 Enter Chan # Full (#=work lights channel)

Clear faders and turn work lights on

This macro clears both faders and selects work lights.

[Clear AB] [Clear CD] [Channel] [#] [Full] Macro line reads: Clear-AB Clear-CD Chan # Full (#=work lights channel)

Clear unused channels in Flexichannel mode

This macro clears channels that are visible, but no longer in use. (Because this macro uses a softkey, you must create it using Learn.)

[Setup] [1] [Enter] [S1] [Stage] Macro line reads: **Setup 1 Enter PurgeFlexi Stage**

Record show on disk

This macro records the current show on disk.

[Setup] [3] [Enter] [1] [Enter] [Enter] Macro line reads: **Setup 3 Enter 1 Enter Enter**

Chapter 19 Link lists

Console channels can control devices that have more than one controllable feature, such as a color scroller. By linking channels using the console's Link List, you can link channels together for simultaneous control on the trackpad. Any channel not used in ML Fixture Patch may be linked.

This chapter contains the following sections:

- Link List overview
- Setting up a link
- Using a link
- Modifying links

Link List overview

Press [Setup] [1][1], **Channel Attributes**, [Enter] [S7], **Link List**, to reach the Link List display

						Link	List				Link 1
						11:39	AM				
	Link	X Chan	Y Chan	Pos	Link	X Chan	Y Chan	Pos	Link	X Chan	Y Chan Pos
	1 200	22 42 152	82 102 212	y y y							
					Se	leot li	nk numbe	en			
(Channels in ML fixture patch cannot be linked)											
1	Link	2) Char	K 3 hnel 1	Y Channe I	4 Por	sition	5 Inseri Link	t 6 D	elete Link	7 Move Link	8 Return

When two or more channels are used together, such as the color and intensity channels for a color scroller, the Link List allows you to determine which axis of the trackpad will control each channel. When you select a channel, it is placed under the control of one axis of the trackpad and all channels linked to it are also selected and placed under control of the other trackpad axis.

Links may contain up to ten channels on each of the X and Y lists. Channels on the X list are controlled by the X-axis and are shown in gold in displays; channels on the Y list are controlled by the Y-axis and are shown in yellow in displays. Each channel may appear in only one link. All channels in a link from one list are selected if any channel is selected from the other list.
Setting up a link

To set up a link, you must assign at least one channel to the X channel list and one channel to the Y channel list. In the following example, two color scrollers are linked so that their color settings are controlled by the trackpad. For the two scrollers, color is controlled by channels 1 and 11, respectively.

To link two channels, follow these steps:

Key	/strokes:	Action:
1.	Press [Setup] [1][1] [Enter].	Selects Channel Attributes display
2.	Press [S7], Link List .	Selects Link List display Prompt reads: Select link number (Channels in ML fixture patch cannot be linked)
3.	Press [1] [Enter].	Selects link number, for instance 1. Prompt reads: Select X channel number(s) (Precede with AND to add to existing link, or EXCEPT to delete from link)
4.	Press [1] [→].	Channel 1 is assigned to the link's X list. Prompt reads: Select Y channel number(s) (Precede with AND to add to existing link, or EXCEPT to delete from link)
5.	Press [1][1] [→].	Channel 11 is assigned to the link's Y list. Set the trackpad mode for this link Prompt reads: Select fixture type, then press ENTER (1=XY position, 0=other) Select link number (Channels in ML fixture patch cannot be edited)
6.	Press [0] [→]. ^a	The link sets the trackpad to double mode. Link entry is complete
7.	Go back to step 3.	Create additional links, if needed

^{a.} The position column pertains to the mode in which the trackpad operates for linked channels. See Using the trackpad, page 9, for information about the XY and double modes of trackpad operation.

Inserting a link

Use the edit features softkey [S5], **Insert Link**, to insert an empty link number ahead of the selected or specified link. All subsequent links will be renumbered.

Note: The order in which links are recorded does not affect their operation. However, your numbering may be useful to you in terms of logical organization.

To insert a link, follow these steps:

Keystrokes:		Action:
1.	Press [Setup] [1][1] [Enter].	Selects Channel Attributes display
2.	Press [S7], Link List .	Selects Link List display Prompt reads: Select link number
3.	Press [S5], Insert Link .	Prompt reads: Select link number to insert, then press ENTER. To cancel, press CLEAR.
4.	Press [1] [Enter].	Selects link 1 to insert. All links higher than 1, up to the first gap in the Link List (if any), are renumbered to make room Prompt reads: Select X wheel channel number (Precede with AND to add to existing link, or EXCEPT to delete from link)
5.	Proceed with normal link	

- 5. Proceed with normal link entry.^a
 - ^{a.} See Setting up a link, page 239.

Moving a link

Use [S7], **Move Link**, to renumber a link or a group of links. All links in a group will be renumbered sequentially.

To move a link to an empty space on the Link List, follow these steps:

Keystrokes:	Action:
1. Press [Setup] [1][1] [E	nter]. Selects Channel Attributes display
2. Press [S7], Link List.	Selects Link List display Prompt reads: Select link number
3. Press [S7], Move Lin	k. Prompt reads: Select link number(s) to move, then press ENTER To cancel, press CLEAR.
4. Press [6] [Enter].	Prompt reads: To move selected link(s), select target link and press ENTER To cancel, press CLEAR
5. Press [9] [Enter].	Link 6 is renumbered as link 9

Merging two links

If you move a link to a space on the Link List which already contains a link, the channels in the moved link are added to the existing link.

To move a link to an occupied space on the Link List, follow these steps:

Ke	ystrokes:	Action:
1.	Press [Setup] [1][1] [Enter].	Selects Channel Attributes display
2.	Press [S7], Link List .	Selects Link List display Prompt reads: Select link number
3.	Press [S7], Move Link .	Prompt reads: Select link number(s) to move, then press ENTER To cancel, press CLEAR.
4.	Press [6] [Enter].	Prompt reads: To move selected link(s), select target link and press ENTER To cancel, press CLEAR
5.	Press [7] [Enter].	Prompt reads: Link already exists – To confirm, press ENTER To cancel, press CLEAR
6.	Press [Enter].	The channels in link 6 are added to the channels in link 7

Note: To split a link apart, create a new link with the channels you want to move. Since a channel can only be in one link at a time, it will be deleted from the original link and recorded in the new link.

Deleting a link

Use [S6], **Delete Link**, to remove a link from the Link List. All subsequent links will be renumbered.

To delete a link, follow these steps:

Ке	ystrokes:	Action:
1.	Press [Setup] [1][1] [Enter].	Selects Channel Attributes display
2.	Press [S7], Link List .	Selects Link List display Prompt reads: Select link number
3.	Press [S6], Delete Link .	Prompt reads: Select link number(s) to delete, then press ENTER (Enter 0 to delete all links)
4.	Press [5] [Enter].	Prompt reads: To confirm, press ENTER To cancel, press CLEAR
5.	Press [Enter].	The link is deleted from the Link List. All links with higher numbers are renumbered one lower

Using a link

Once you have linked the color control channels for the two color scrollers, the console allows you to control them simultaneously on the trackpad. If you move in just the X or Y direction only, the color will change only on the corresponding scroller.

To control the scrollers, follow these steps:

10	To control the scrollers, rollow these steps.	
Keystrokes:		Action:
1.	Press [Stage].	Selects Stage display
2.	Press [1].	Selects channel 1. Channel number is gold, signifying that it is assigned to the X list. Through the link, selects channel 11. Channel number is yellow, signifying that it is assigned to the Y list
3.	Place your finger in the lower left corner of the trackpad and slowly move it toward the upper right corner.	The levels on both channels rise together, each controlled by an axis of the trackpad. As they do, the colors change on the color scrollers, corresponding to the levels. Both axis' levels are displayed in the prompt corner

Chapter 20 Diskette functions



This chapter includes instructions for using console diskette options. The console is equipped with a 3.5-inch disk drive on the console's right end panel.

The following options are described in this chapter:

- Diskette management
- Formatting diskettes
- Writing to diskette
- Reading show, configuration or all information from diskette

Diskette management

The console lets you save one show on a double-sided, high density (1.44 MB) 3.5-inch diskette. This feature allows you to back up your shows for safety. It also allows you to transfer your shows to other consoles, work on more than one show at a time and use more than 600 cues in a show by loading a second show into memory.⁹⁸

Label each diskette carefully and clearly to help you keep track of what show is on the diskette. You can also use any of the Read options to find out the name of the show and when it was transferred to diskette.⁹⁹

Before you can use a diskette in the console, you must format it on the console or on an IBM PC-compatible with a high-density drive. Formatting instructions using the console are given in this chapter.

Storing diskettes

- Store diskettes at a temperature between 50 and 140 degrees Fahrenheit.
- Keep diskettes away from magnets, magnetized objects or heavy electrical equipment, including large lighting equipment.
- Do not touch the magnetic disk inside the plastic diskette case.

Formatting diskettes

WARNINGS: Formatting a diskette erases all information recorded on the diskette. Formatting stops any fade in progress. When formatting is complete, the fade jumps to the point it would have reached if it hadn't been interrupted.

Before you can use a diskette in the console, you must format it on either the console or an IBM-compatible personal computer.

To format a diskette with the console, insert a diskette into the console's disk drive and follow these steps:

Keystrokes:		Action:
1.	Press [Setup].	Selects Setup display
2.	Press [3], Disk Functions , [Enter].	Selects Diskette Functions menu
3.	Press [4], Format Disk , [Enter].	
4.	Press [Enter].	Formats the diskette. Prompt appears: Formatting disk - Do not remove from drive.

^{98.} See The oversized show, page 82.

^{99.} See Expression Off-Line, page 312, to name a show in Expression Off-Line.

Contents of the showfile

When you write to diskette, everything that you programmed into your show and everything that you set in the console to make that show happen are stored in a single showfile. Show and configuration information, however, may be read separately from the showfile.¹⁰⁰

The System Configuration contents of the showfile are defined as all those things you set in the console that commonly remain the same for all shows. Show contents of the showfile contain certain other settings, such as changes in defaults that are likely to be set for a specific show, and all those programmed elements of the show that directly control the lights, including the patching, cues and dimmer settings. A complete accounting of showfile contents, broken down into Show and System Configuration components, is given in *Appendix D Showfile, page 339*.

Writing to diskette

Write a showfile to diskette with the following procedure. ¹⁰¹

Keystrokes:

Action:

- 1. Insert a formatted diskette in disk drive.
- Press [Setup].
 Selects Setup display
 Press [3], Disk Functions, [Enter].
 Press [1], Write All to Disk, [Enter].
 Press [Enter], or press [Clear] to cancel the operation.
 Selects Setup display
 Selects Diskette Functions menu
 Screen clears and Record window appears
 Message in record window appears and remains until show is recorded: To disk in progress.

^{100.} System configuration information was not saved on diskette for shows recorded prior to version 3.03 software.

^{101.} When writing, any fades executing at that time are interrupted. These fades resume when writing to diskette is complete.

Reading from diskette

You can read either the show or the system configuration contents of a showfile, or you can read both together. See *Appendix D Showfile, page 339*, for a breakdown of what components are stored in each.

CAUTION: The information you read from diskette takes the place of whatever you had before the read in your console's memory.¹⁰² If you want to keep the show and configuration settings currently in memory, write them to diskette before the read.

You may read from diskette in the middle of a performance, but you should wait until no fades are taking place. Any fades in progress are stopped during the read and resume when the read is complete. Fader and submaster outputs are maintained as the new show loads.

Read show and configuration

Follow the procedure below to read both the show and the system configuration components at once.

Action:

Keystrokes:

- Insert diskette in disk drive.
- 2. Press [Setup]. Selects Setup display
- Press [3], **Disk Functions**, Selects Diskette Functions menu [Enter].
 Press [5], **Read All from** Screen clears and Read All window
 - Press [5], Read All fromScreen clears and Read All windowDisk, [Enter].appears
- Press [Enter], or press [Clear] to cancel the operation.
 Message in record window appears and remains until read is complete: From disk in progress.

^{102.} If you are using the Designer's Worksheet option and your setup is different in the new show, a message will warn you.

Read show components only

Frequently you do not need to overwrite system configuration settings but only want a different showfile in console memory. For that purpose, read show contents only into memory with the following procedure:

Keystrokes: Action: 1. Insert diskette in disk drive. Selects Setup display 2. Press [Setup]. 3. Press [3], **Disk Functions**, Selects Diskette Functions menu [Enter]. 4. Press [2], Read Show Screen clears and Read Show window From Disk, [Enter]. appears 5. Press [Enter], or press Message in record window appears [Clear] to cancel the and remains until read is complete: operation. From disk in progress.

Read system configuration components only

Follow the procedure below if you want to restore your system configuration to one written previously to a diskette. $^{103}\,$

Keystrokes:		Action:
1.	Insert diskette in disk drive.	
2.	Press [Setup].	Selects Setup display
3.	Press [3], Disk Functions , [Enter].	Selects Diskette Functions menu
4.	Press [3], Read System Configuration From Disk , [Enter].	Screen clears and Read System Parameters window appears
5.	Press [Enter], or press [Clear] to cancel the operation.	Message in record window appears and remains until read is complete: Read system configuration in progress .

^{103.} System configuration information was not saved on diskette for shows recorded prior to version 3.03 software.

Chapter 21 Printing

The console supports parallel printers, including some laser printers. Printer installation is described in *Installing a printer, page 322*. This chapter includes instructions for using the console's print options. the following printouts are introduced and explained in this chapter.

- Stage display
- Cues
- Groups
- Submasters
- Cue list
- Group list
- Submaster list
- Macros
- Patch
- Profiles
- Channel attributes
- Real Time Programs
- Time Code events
- Focus Points
- Focus Points List
- Moving Lights

Printer options

Before you begin printing, verify that your printer is installed correctly and that it is turned on. For instructions on installing printers, see *Installing a printer, page 322*.

All print options are located on the Print Functions menu. To display the menu press [Setup], then select [5], **Print Functions**, and press [Enter]. The console displays the Print Functions menu illustrated below.



You may pause the current printing job or cancel it at any time while printing. To stop the printer temporarily while it is printing, press [S2], **Pause Printer**. The printer prints a few more lines, then stops and waits. Press [S2] again to resume printing. To cancel a print job, press [S1], **Stop Printer**. The printer prints a few more lines, then stops.

Printing procedure

Follow the procedure below for all printouts. This example shows the prompts for the Print Stage Display option on the Print Functions menu. Use this procedure for all printout options, varying as directed by the onscreen prompts.

Keystrokes:		Action:
1.	Press [Setup].	Displays Setup menu
2.	Press [5], Print Functions , [Enter].	Displays Print Functions menu
3.	Press [1], Print Stage Display , [Enter].	Prompt reads: To confirm, press ENTER To cancel, press CLEAR
4.	Press [Enter].	File sent to the printer

Printouts available

Following is a list of all 17 options on the Print Functions menu and an explanation of the printout each will produce.

- 1. Stage Display Reports the settings of all channels on stage.
- 2. **Cues** Lists cues in the show by number and attributes. Also gives the levels of all channels in each cue.
- 3. **Groups** Lists all groups in the show by number and label. Also gives the levels of all channels in each group.
- 4. **Submasters** Lists all 240 submaster memories, by submaster number; upfade, dwell and downfade times; rates and labels. Also gives the levels of all channels included in each submaster.
- 5. Cue List Lists cues in the show by number and attributes.
- 6. Group List Lists all groups in the show by number and label.
- 7. **Submaster List** Lists all 240 submaster memories, by submaster number; upfade, dwell and downfade times; rates and labels.
- 8. Macros Lists macro sequences in the show by macro number.
- 9. Patch Prints the current dimmer-to-channel patch.
- 10. **Profiles** Lists all 32 profiles and their fade point intensities in the show.
- 11. **Channel Attributes** Lists Channel Attributes, including link lists, recorded in the show.
- 12. **Real Time Programs** Lists Real Time Programs in the show, with complete information.
- 13. **Time Code Events** Lists all Time Code events in the show, with complete information.
- 14. **Focus Points** Lists all focus points in the show by number and label. Also gives the levels of all channels in each focus point.
- 15. Focus Point List Lists all focus points in the show by number and label.
- 16. **Moving Lights** This selection brings up the Print Moving Lights menu. See the explanation below of the four choices on this menu.

Moving lights

The Moving Lights option from the Print Functions menu brings up an additional menu called the Print Moving Lights menu. The four options on this menu and the printouts they produce are explained below.

- 1. **Personalities** Lists all personalities in the show and identifies the attributes of each by channel order, name, data type, independent status, LTP status and Flip status.
- 2. **Fixture Patch** Lists all fixtures in the show according to all parameters in fixture patch. Also identifies the channel assigned to the fixture's intensity attribute.
- 3. **Attribute Setup** Lists the setup in the show for all 64 attributes by number, name and category of assignment.
- 4. **Encoder Setup** Lists the page-by-page setup in the show for all five encoders, for the two wheels and for the two axes of the pointing device, if installed.

Chapter 22 Clear functions

This chapter includes instructions for using the console's clear options. Each of the following clear functions is explained and illustrated on the following pages.

- Show
- Cues
- Groups
- Submasters
- Show and patch
- Focus points
- Macros
- Reset patch
- Reset profiles
- Channel attributes
- Real Time Programs
- Time code events
- Moving lights

Clear functions

Each option on the Clear Functions menu erases information regarding a console function from the console's memory. If that information is saved in a show on a diskette, it can be restored to the console. Otherwise, the information is lost permanently.

Warning: Be certain to save your shows on disk before erasing information you may need in the future. See Chapter 20 Diskette functions, page 243, for information about saving shows.

All clear options are located on the Clear Functions menu. To display the menu, press [Setup], then select [4], **Clear Functions**, and press [Enter]. **The console** displays the Clear Functions menu illustrated below.



Clear and reset procedure

Follow the procedure below for all clears and resets. This example shows the prompts for the Clear Show option from the Clear Functions menu. Use this procedure for all clear and reset options, varying as directed by the onscreen prompts.

Keystrokes:		Action:
1.	Press [Setup].	Displays Setup menu
2.	Press [4], Clear Functions , [Enter].	Displays Clear Functions menu Prompt reads: Select function number, then press ENTER
3.	Press [1], Clear Show , [Enter]. ^a	Prompt reads: To clear show data, press ENTER To cancel, press CLEAR
4.	Press [Enter].	Show cleared. Returns to Stage display mode

^{a.} Press softkey [S1], **Reset System**, here to erase all show information from the console, reset to a 1-to-1 patch and reset the system, options and configuration to factory defaults.

Clear and reset options

Following is a list of all 14 options on the Clear Functions menu and an explanation of the function of each.

- 1. **Show** Erases all information pertaining to the show except patch information and the system configuration.
- 2. Cues Erases all recorded cues from the show.
- 3. Groups Erases all recorded groups from the show.
- 4. Submasters Erases all recorded submasters from the show.
- Show and Patch Erases all information pertaining to the show. Unaffected are system settings, options settings and the I/O configuration.See Reset System, next page, for clearing everything to defaults.
- 6. Focus Points Erases all recorded focus points from the show.
- 8. **Macros** Erases all macro information from the show.
- 9. **Reset Patch 1-to-1** Resets to a one-to-one patch. Thus, channel 1 is patched to dimmer 1, channel 2 is patched to dimmer 2, and so on. This function is independent of your show and does not clear label, level or profile settings. See *Chapter 4 Patching channels, page 35*, for more information about patch.
- 10. **Reset Profiles** Returns all dimmer profiles to their preset curves. Profiles 1-9 return to their preset curves identified under *Dimmer profiles, page 40.* Profiles 10-32 all return to a linear curve.
- 11. **Channel Attributes** Erases all channel attribute information, including link lists, from the show.
- 12. Real Time Programs Erases all Real Time Programs from the show.
- 13. Time Code Events Erases all Time Code information from the show.
- 15. **Moving Lights** Unpatches all fixtures and restores the defaults for personalities, encoders and attributes.

Chapter 23 Two scene preset

Express provides a two scene preset function with the A/B faders. When in the two scene mode, the C/D faders remain available to run recorded cues.

Two scene preset allows you to change the look on stage by using the two banks of channel sliders and the A/B faders to simultaneously fade one look out and bring a new one in. The A fader controls the output of the top row of channel sliders (scene A). The B fader controls the output of the bottom row of channel sliders (scene B).

Because the two rows of channel sliders are controlled independently, you can create a new scene while a scene is live on stage, then fade to the new scene. Control the rate of a crossfade manually by moving the faders.

This chapter includes the following sections:

- Enabling two scene mode
- The two scene faders
- Two scene status display
- Manual crossfades
- Timed crossfades

Setting the scene mode

The procedure for setting the scene mode differs for the Express 24/48 compared to that for the Express 48/96 and 72/144 models because the bottom row of sliders on the 24/48 functions as either channel sliders or submasters depending upon your choice.

Express 24/48

When changing the scene mode for this model, you are asked to choose how you will use the bottom row of sliders. You cannot use submasters in this model while in two scene mode.

Keystrokes:		Action:	
1.	Press [Setup] [1] [Enter].	Selects System Settings menu	
2.	Press [15] [Enter].	Prompt reads: Select scene mode, then press ENTER (1 = Two scene, 2 = One scene without subs, 3 = One scene with subs)	
3.	Press [1] [Enter].	Enables two scene mode	

Express 48/96 and 72/144

Follow these steps to put the console in two scene preset mode.

Keystrokes:		Action:
1.	Press [Setup] [1] [Enter].	Selects System Settings menu
2.	Press [15] [Enter].	Prompt reads:* Select scene mode, then press ENTER (0 = One scene, 1 = Two scene)
3.	Press [1] [Enter].	Enables two scene mode

The two scene faders



When two scene mode is enabled, the A/B faders control the scenes and function in reverse with respect to each other. When both faders are up, as shown above, fader A is at full and scene A (controlled by the top row of channel sliders) is up on stage. When the faders are both down, fader B is at full and scene B (controlled by the bottom row of channel sliders) is up on stage. Having the sliders function in reverse directions allows for smooth manual crossfades with the use of only one hand.

The [Rate], [Go] and [Hold] keys allow you to run timed crossfades between the scenes. The [Clear] and [Back] keys allow you to temporarily flash scenes A and B on stage. These two functions are described later in this chapter.

Two scene status display

When two scene mode is enabled, the A/B fader status display in Stage and Blind becomes the two scene status display. This display shows the current level of each scene on stage. If you use a timed crossfade, the display not only shows scene levels but also shows the current time settings and counts down the fades as they happen.

Here is an example of what the two scene status display shows during a manual fade from one scene to the other.



Suppose you initiate a timed crossfade from B to A with the upfade set for 20 seconds and the downfade set for ten seconds. The following illustrations show how the two scene display looks after 8 seconds have elapsed. Scene A has 12 seconds left to go in its fade and scene B has 2 seconds left. The fade settings are shown at the bottom of the display.

Scene	A		Sce	ene B
Up 12			2	Dn
42%				16%
Time:		20		10

In another example, upfade and downfade times are set alike at 5 seconds. You have initiated a timed crossfade from A to B that has finished. Note that scene B is at full and scene A has disappeared from stage. At this point you would set the levels for the next scene A.

Scene A	Scene B
Done	Done
0%	100%
Time:	5 / 5

Manual crossfades

In a crossfade, you normally set the channel settings for one scene blind (without affecting live settings) while the other is live. When you want to change from one scene to another, you use the crossfaders to simultaneously fade the live scene out and bring the next one up.

Follow these steps to create scenes and run a show using manual crossfades:

Ke	ystrokes:	Action:		
1.	Pull the A fader all the way toward you. Push the B fader fully away from you.	The stage is dark. The scene fader status display shows both scenes at 0%		
2.	Create scene A by setting the top bank of channel sliders at desired levels.			
3.	Slide fader A fully away from you.	Scene A comes up on stage. The scene fader status display shows Scene A at 100% and Scene B at 0%		
4.	Without moving the fad- ers, set the lower bank of channel sliders at the desired levels for scene B.			
5.	Pull both crossfaders down simultaneously to bring scene B up and fade scene A out.	Scene A fades out and scene B comes up on stage. The scene fader status display shows Scene A at 0% and Scene B at 100%		
6.	Now set the upper bank of channel sliders to the desired levels for the next look you want on stage.			
7.	Push both crossfaders up simultaneously to fade scene B out and bring scene A up.	Scene A comes up on stage. The scene fader status display shows Scene A at 100% and Scene B at 0%		
8.	Repeat steps 4 through 7 for each pair of scene			

Flash a scene

changes.

Press [A/B Clear] to flash scene A on stage. Press [A/B Back] to flash scene B on stage.

Timed crossfades

Use the A/B fader controls to run a timed crossfade from one scene to the other.

Ke	ystrokes:	Action:			
1.	Set up the new scene on the channel sliders.	Selects Channel Attributes display			
2.	Press [A/B Rate].	Prompt reads: Select scene upfade time, then press ENTER			
3.	Press [2][0] [Enter].	Prompt reads: Select scene downfade time, then press ENTER			
4.	Press [3][0] [Enter].	The Scene fade status display indicates time settings on the bottom line			
5.	Slide both faders to the opposite end. As soon as they reach their new positions, the fades start.	The new scene fades up in 20 seconds. The old scene fades out in 30 seconds			

Pause a timed crossfade

 $\ensuremath{\mathsf{Press}}$ [A/B Hold] to pause a running timed crossfade. Press [A/B Go] to resume the timed fades.

Chapter 24 Dimmer monitoring

ETC consoles may be connected to ETC Sensor dimming systems via the ETCLink communication protocol. In this configuration, the console operates a dimmer monitoring system that provides you with a wide range of dimmer status information, including overall dimming system status and specific information about individual dimmer modules and dimmer racks.

Your window on ETCLink is through the ETCLink Functions menu. Most of the dimmer, rack and dimming system information provided by console displays is also provided by the the Control Electronics Module (CEM) of your Sensor dimming system.

Consult this chapter for information on the following topics:

- Enabling ETCLink
- Enabling / disabling ETCLink error messages
- Recording, checking and clearing dimmer loads
- Examining overall dimming system status
- Examining rack status
- Examining dimmer status
- Setting / unsetting dimmers with ETCLink
- Using Sensor backup looks

ETCLink functions

Go to the ETCLink Functions menu by pressing [Setup] [9] [Enter]. Make selections from this menu to branch to the variety of options available in your dimmer monitoring system.



Enabling ETCLink

Before using ETCLink functions, you must enable your console to work with the ETCLink network. After enabling the connection, you should decide how to handle error advisory messages. See *Error messages, page 265*.

Following is one of two ways to enable ETCLink. You may also enable ETCLink using softkey [S1] in the ETCLink Functions menu, shown above.¹⁰⁴

Keystrokes:Action:1. Press [Setup].Selects Setup menu.2. Select 6, Options
Settings, and press
[Enter].Selects Options Settings menu3. Press [8], ETCLink,
[Enter].Prompt reads:
Enable/disable ETCLink
(1 = Enable, 0 = Disable)4. Press [1] [Enter].Dimmer Monitoring is enabled

^{104.} Note that option 9 in the Options Settings menu provides for an ETCLink address setting, which is related to operating more than one console on ETCLink. The default value is 1, and generally should be left as is. If you have questions about this setting, please call ETC Technical Services at the office nearest you.

Error messages

ETCLink provides messages for a wide variety of conditions, including information regarding your dimmers, racks, system, data, ports, and loads. These messages fall into two categories, fatal messages and secondary messages.¹⁰⁵

Fatal messages deal with anything that could potentially terminate or drastically change the look of your show. You may set fatal messages to be displayed even when secondary messages have been disabled.

Secondary messages deal with individual dimmer problems and warnings of potential rack temperature problems. These messages are generally less critical than the fatal messages. If you wish, secondary messages may be disabled without disabling fatal messages. The procedure for enabling or disabling ETCLink error messages is given in the next section.

The console shows error messages in pop-up advisory windows that appear regardless of which display mode you have chosen. They may also appear in abbreviated forms on the Status and About screens.¹⁰⁶ Advisories are cleared as soon as you enter any keystroke. An example of such an Advisory message is shown below.

			<mark>Sta</mark> 01:19	<mark>ge</mark> PM			С	op tur	Cl red	ian Cha	ппе	ls
001 02 03 45 45 45	04 05 0 45 45	06 07 08 09	10 011 12 Redvis	13 14 1 ory	5 016 1	7 18	19 20	021	22	23	24	25
026 27 28	29 30	Dimmer 1 ou	tput has f	ailed o	off.			046	47	48	49	50
051 52 53	54 55	Either the or the dimm	circuit br er needs t	eaker h o be re	as trip placed.	ped		071	72	73	74	75
076 77 78	79 80	Press [Clea	r] to cont	inue.				096	97	98	99	00
101 02 03	04 05							121	22	23	24	25
Select channel numbers												
Cue/Type 1 XF	Up/Down 5	Wait L	ink Follow	Rate L	.obe I			Cue	s le	eft:	60	0
S1	S2	SS Bockornd	S4 Previous	S5 Next	S	6	S	7 ore		88		
Sneak	Update	Overrides	Page	Page	e P	ark	Sof	tkey	s F	ixt	ure	

^{105.} See ETCLink errors, page 336, for a listing of errors.

^{106.} To identify errors on specific dimmers, see About Dimmer with ETCLink, page 47.

How to enable / disable ETCLink error messages

Keystrokes:

- 1. Press [Setup].
- 2. Press [9], ETCLink Functions, [Enter].
- 3. Press [6], **Display** Advisories, [Enter].

Action:

Selects Setup display

Selects ETCLink Functions menu

Prompt reads: Enable/disable display of ETCLink advisories (1 = Enable all, 2 = Enable fatal error advisories only, 0 = Disable)

4. Press [1] [Enter]. Enables all ETCLink error advisories

ETCLink displays

Dimming system status

The System Status display provides information about your Sensor dimming system. Press [Setup] [9] [Enter] [1] [Enter] to access the System Status display.

System Status 03:07 PM						
	Double Firing Mode	:	Disobled			
	Backup Looks		Inactive			
	ETCL ink		Has errors			
	Syste m- Wide Panic		0ff			
	Error on Rack		22			
	Racks On-Line		1			
	Racks in Configura	tion	32			
S1 S2	S3 S4	85	S6	S7	S8	
Double Backup	Backup	Status	Status		Return	

- **Double Firing Mode** shows whether that mode is enabled or disabled for your system. If Double Firing Mode is disabled, doubled dimmers function as normal dimmers.
- **Backup looks** indicates whether a backup look is active, and, if so, which one.
- **ETCLink** displays any ETCLink errors.
- **System-wide panic** displays status of system-wide panic.
- **Error on rack** displays the number of the rack with an ETCLink error. If errors exist on multiple racks, the first rack with an error is displayed.
- **Racks on-line** displays the number of racks presently on-line throughout the ETCLink network.
- **Racks in configuration** displays the total number of racks in the system.

Dimmer rack status

The Rack Status display provides information about specified dimmer racks, including rack type, starting address, port information, voltage, frequency, and ambient temperature.

Press [Setup] [9] [Enter] [2] [Enter] to access the Rack Status display. Press [S6], **Select Rack**, [#] [Enter] to select a specific rack, [+] to select the next rack, or [–] to view the previous rack.

Rack Status Rack 1 01:29 PM						
Rack: 1		Ok				
Rack Type Start Address Port A Type Status Port B Type Status Rack Voltage Line A Line B Line C Rack Frequency Ambient Temperature		Ser 1 0k 122 123 121 60 72	Sensor-SR6 with feedback 1 DHX512 Errors Ok 122 VRC 123 VRC 123 VRC 121 VRC 60 Hz 72 F / 22 C			
Dimming errors found						
	Select r	rack number	, then pre	ess ENTER		
S1 S2	\$3	84 System Status	S5 Dimmer Status	S6 Select Rack	\$7	S8 Return

- **Rack type** displays the type of Sensor rack this rack is. Possible rack types include SR6, SR12, SR24, SR36, SR48, SP6, SP12, SP24, SP48, and may be followed by AF if the rack is equipped with Sensor's Advanced Features option.
- Start address displays the lowest dimmer number in the rack.
- **Port A/B type** indicates whether the port is normal or Dimmer Doubled. "--" indicates a normal port.
- Status indicates the present status of the port.
- **Rack voltage** displays the input voltage for each of the three phases (A, B and C). Single phase racks only display values for A and C.
- Rack frequency displays the input frequency in hertz (Hz).
- **Ambient temperature** displays the temperature of the air drawn into the rack by the rack's fan. Ambient temperature is not displayed unless the fan is running.

Rack error messages, if any, are announced beneath the ambient temperature line.

Dimmer status

The Dimmer Status display provides information about dimmers, including size and type, recorded load, firing mode, output curve, rack, slot, panic mode, and boost. Press [Setup] [9] [Enter] [3] [Enter] to access the Dimmer Status display.

	Dimmer Status							
			03:09	PM				
D.'	Τ	D	F' -'	0	DI-	01-1	No	errors
Dimmer	Туре	Recorded	Firing	Curve	Rack	8101	Panic	Scale/
250	Nat Taatallar		noae				noae	BOOST
250	Not Installed	-						
251	Not Installer	4						
253	D15AF	12504		Mod Sauor	22			1160
254	D158F	950W		Mod Square	22	1		116V
255	D15AF	οw		Mod Sauara	22	2		116V
256	D15AF	ow		Mod Square	22	2		116V
257	D15AF	οW		Mod Square	e 22			116V
258	D15AF	οw		Mod Square	e 22			116V
259	D15AF	ow		Mod Square	e 22			116V
260	D15AF	ω		Mod Square	e 22			116V
261	D15AF	ow		Mod Square	e 22			116V
262	D15AF	οw		Mod Square	e 22	5		116V
263	D15AF	OW		Mod Square	e 22	6		116V
264	D15AF	OW		Mod Square	e 22	6		116V
-265	Not Installed							
	Press [+] or [-] to page through dimmers							
Q1	62	60	94	9E	94	0	7	60
	32	33	Sustem	Select	Bock	-		30
			Status	Dimmer	Status			Return
			oraros	C THERE	010103			HO TOF IT

Up to 16 dimmers are shown in the display at once. If a dimmer has an error condition, the entire dimmer row is highlighted in yellow (ordinarily the line is in gray). Dimmer errors are also identified in the About Dimmer display. See *About Dimmer with ETCLink, page 47*.

Press [S5], **Select Dimmer**, [#] [Enter] to select a specific dimmer or use [+] and [–] keys to move through the list of dimmers a page at a time. Following is an explanation of column contents.

- **Type** identifies the ETC type designation.
- **Recorded load** displays the load at which the selected dimmer was recorded.
- **Firing mode** identifies whether the dimmer is normal, doubled, or switched. "--" indicates a normal firing mode.
- **Curve** identifies the output curve assigned to the dimmer.
- Rack identifies the dimmer's rack number.
- **Slot** identifies the dimmer's slot number in the rack.
- **Panic mode** identifies whether the dimmer is assigned to a panic circuit. "--" indicates an unassigned dimmer.
- Scale/Boost indicates either the dimmer's Scale or Boost value. Either can be returned for each dimmer depending upon the rack's CEM software. Scale is expressed in voltage and indicated by a "V" following the number. Boost is expressed in percentage and indicated by a "%" following the number. A non-boosted level of 100 percent is indicated by the symbol "--".

Monitoring dimmers

When used in conjunction with Sensor Advanced Feature dimming equipment, the console allows you to monitor individual dimmer loads in your system. This can greatly simplify troubleshooting by identifying such things as burned out lamps, and incorrectly lamped or unplugged fixtures.

When dimmer monitoring is in use, Sensor electronics constantly monitor dimmer loads. Monitoring information is displayed by the dimming system and also sent to the console.

To use this monitoring information efficiently, you must first determine what constitutes a normal load. The console procedure for determining normal loads is called Record Loads, and it is explained in the next section. You may also perform a Record Loads procedure from the Sensor system.¹⁰⁷

Load Management display

The Load Management lists dimmers for which load errors have been detected, either by the Sensor system or by a Load Check you initiated. If you have a printer attached to your system, you may print the data shown in the Load Management display by pressing [S1], **Print Screen**. An example of a Load Management display is shown below.



If load errors are reported for many dimmers, Use [Page +] and [Page –] to page through the display.

- **Recorded Load** lists the loads determined for the listed dimmers during a Record Loads procedure.
- Actual Load lists the current loads for the listed dimmers.

^{107.} Loads may not be recorded on Sensor systems without the AF option. See the Sensor CEM Users Manual for more information on recording loads from your dimming system.

Record Loads procedure

Perform a Record Loads any time you relamp your fixtures, change the type of fixtures you are using, change the dimmer numbering scheme, or make any other significant changes to your system. In general, Record Loads should be the last step in setting up your system.

When you perform a Record Loads, the system records load information for dimmers set at a level above zero or for a list of dimmers. If setting dimmers above zero, you can record 24 dimmers per rack at a time until all non-zero dimmers have been recorded. If you have multiple racks, 24 dimmers in each rack are recorded simultaneously.¹⁰⁸

Caution: Record Loads changes levels on stage. Dimmer outputs rise and fall for several minutes during the procedure. To cancel a Record Loads operation that has already started, press [S7], *Cancel*, [Enter].

Keystrokes:

Action:

- Set desired dimmers to a level above zero.^a Only dimmers at levels above zero are recorded.
- 2. Press [Setup].
- 3. Select [9], **ETCLink Functions,** and press [Enter].
- 4. Select [4], **Load Management**, and press [Enter].
- 5. Press [S5], **Record Loads**. If you wish, you may enter a specific dimmer or dimmers to record.
- 6. Press [0] [Enter].

Selects Load Management display

Selects ETCLink Functions menu

Selects Setup display

Prompt reads:

To record loads, select dimmer(s) and press ENTER (Enter 0 to record loads for all dimmers)

Advisory reads:

New loads will be recorded for all dimmers with levels above zero. Levels on stage will change while the Record Load is in progress. The system will automatically vary the dimmer outputs during the Record Load. The process may take several minutes to complete.

Press [Enter] to proceed, or press [Clear] to cancel

7. Press [Enter]. New loads are recorded for all dimmers with levels above zero

a. If you wish, instead of setting the desired dimmers to a level in step 1, you may enter a list of dimmers to record in step 5.

^{108.} On single phase racks, the system checks 16 dimmers per rack at a time.

Load Check procedure

Load Check compares the current load on selected dimmers with their recorded loads. The system checks load information only for selected dimmers. To identify the dimmer(s) you wish to check, use either the console or the CEM to set the desired dimmers at a level above zero.

The system checks 24 dimmers per rack at a time until all dimmers at levels above zero have been checked. If you have multiple racks, 24 dimmers in each rack are checked simultaneously.¹⁰⁹

Caution: Load Check changes levels on stage. Dimmer outputs rise and fall for several minutes during the procedure. To cancel a check load operation in progress, press [S7], **Cancel**, [Enter].

Follow these steps to check loads for your system:

Ke	ystrokes:	Action:
1.	Set dimmers to be checked to a level above zero. Only dimmers above zero are checked. ^a	
2.	Press [Setup].	Selects Setup display
3.	Select [9], ETCLink Functions, and press [Enter].	Selects ETCLink Functions menu
4.	Select [4], Load Management , and press [Enter].	Selects Load Management display
5.	Press [S4], Load Check . (You may enter specific dimmers to check.)	Prompt reads: To check loads, select dimmer(s) and press ENTER (Enter 0 to check loads for all dimmers)
6.	Press [0] [Enter] [Enter].	Advisory reads: All dimmers with levels above zero will have their loads checked. Levels on stage will change while the Load Check is in progress. The system will automatically vary the dimmer outputs during the Load Check. The process may take several minutes to complete.
7.	Press [Enter] to proceed with the load check, or press [Clear] to cancel the operation.	Loads are checked for all dimmers with levels above zero Once complete, advisory reads: Load check processing has completed Press [Clear] to continue

a. If you wish, instead of setting the desired dimmers to a level in step 1, you may enter a list of dimmers to record in step 5.

^{109.} On single phase racks, the system checks 16 dimmers per rack at a time.

Clear Loads procedure

Clear Loads allows you to clear recorded loads information for selected dimmers, thus disabling dimmer monitoring for those dimmers. This can be useful if you know that the load on a dimmer or group of dimmers will change over the course of a show and don't want to receive load error messages every time it happens.

To clear recorded loads, follow these steps:

Keystrokes:

Action: Selects Setup display 1. Press [Setup]. Selects ETCLink Functions menu 2. Select [9], ETCLink Functions, and press [Enter]. Selects Load Management display 3. Select [4]. Load Management, and press [Enter]. Prompt reads: 4. Press [S6], Clear Loads. To clear loads, select dimmer(s) and (If you wish, you may press ENTER (Enter 0 to clear nonenter a specific dimmer or dimmers to clear.) zero loads for all dimmers) Advisory reads: 5. Press [0] [Enter]. Recorded loads will be erased for all dimmers with levels above zero, disabling load error messages for those dimmers. Press [Enter] to proceed, or press

6. Press [Enter] to proceed with the load clear, or press [Clear] to cancel the operation.

Loads are cleared for all dimmers with levels above zero

[Clear] to cancel

Setting and unsetting dimmers

If your console is connected to an ETC Sensor dimming system by an ETCLink network, you may use your console to set and unset dimmers at the dimmer rack.

Note: For more information on setting dimmers, see the Sensor CEM User Manual.

Setting a dimmer

To set a dimmer or group of dimmers to a level at the dimmer rack, ignoring any DMX512 outputs, follow these steps:

Keystrokes:		Action:
1.	Press [Setup].	Selects Setup display
2.	Press [9], ETCLink Functions, [Enter].	Selects ETCLink Functions menu
3.	Press [S7], Set Dimmer .	Prompt reads: Select dimmer number(s) to set, then press ENTER (To cancel, press CLEAR)
4.	Enter the dimmers you wish to set and press [Enter].	Prompt reads: Select dimmer level (Press FULL button for 100%)
5.	Enter the level at which to set the dimmers. Enter in two-digit form (e.g., one percent = 01)	Advisory reads: To confirm, press ENTER To cancel, press CLEAR

6. Press [Enter]. Dimmers are set to desired level

Unsetting a dimmer

To unset a dimmer (or group of dimmers) and return it to normal operation, follow the procedure below. (**NOTE**: Setting a dimmer to level 00 is not the same as unsetting it and returning it to normal operation.)

. ..

Keystrokes:		Action:
1.	Press [Setup].	Selects Setup display
2.	Press [9], ETCLink Functions, [Enter].	Selects ETCLink Functions menu
3.	Press [S6], Unset Dimmer.	Prompt reads: Select dimmer number(s) to unset, then press ENTER (Enter 0 to unset all dimmers)
4.	Enter the dimmers you wish to unset and press [Enter]. Press [0] [Enter] to unset all set dimmers.	Prompt reads: To confirm, press ENTER To cancel, press CLEAR
5.	Press [Enter].	Dimmers are unset
Working with Sensor backup looks

A backup look is a recording of a selected look on stage stored in the Sensor CEM. The Sensor system allows you to use either your console or any CEM to bring that look up on stage. You may save and use up to 32 backup looks.

Recording a backup look

[Enter].

To record a backup look, follow these steps:

Action: **Keystrokes**: 1. Use your console to create Creates look on stage the desired look on stage. 2. Press [Setup]. Selects Setup display Selects ETCLink Functions menu 3. Select [9], ETCLink Functions, and press [Enter]. Selects System Status display 4. Press [1], **Dimming** System Status, [Enter]. Prompt reads: 5. Press [S3], Record Select backup look to record, then Backup. press ENTER Advisory reads: 6. Enter the backup look **Record Backup processing has** number (1-32) and press completed. Press [Clear] to

continue.

Playing a backup look

Playing a backup look brings up the recorded look on stage. You may play back a backup look from the console or from a CEM.

Only one backup look may be on stage at a time. If there is a backup look on stage when you bring up a new one, the second look replaces the first.

Up and down fade times for backup looks are five seconds. They cannot be modified.

To use the console to play a recorded backup look, follow these steps:

Keystrokes:

Action:

- Press [Setup].
 Selects Setup display
 Select [9], ETCLink Functions, and press [Enter].
 Selects ETCLink Functions menu
 Selects Dimming System Statup
- Press [1], Dimming System Status, [Enter].
 Press [S2], Play Backup.
 Prompt reads:

Prompt reads: Select backup look to play, then press ENTER (Enter 0 to return to normal operation)

- Enter the backup look number (1-32) and press [Enter].^a
 Advisory reads: Play Backup processing has completed. Press [Clear] to continue.
 - a. To clear a playing backup look, enter [0] in step 5 as the backup look number. The currently playing backup look will be cleared from the stage.

Chapter 25 Control interfaces

The console can control and be controlled by a wide variety of external devices. These control interfaces may be as simple as a switch and as complicated as another piece of electronic equipment. They may be timed or asynchronous.

Chapter 25 explains the following interfaces with the console:

- ETC MIDI
- MIDI Show Control
- Real Time Programs
- MIDI time code
- Remote Macros
- Remote Trigger
- Serial Interface

MIDI (Musical Instrument Digital Interface) is a digital communication protocol that allows you to interconnect musical instruments and digital electronic equipment, such as lighting control consoles. The console supports MIDI Show Control 1.0 (MSC) and a subset of MIDI known as ETC MIDI. If you are not familiar with MIDI and would like more information on how it works, *Control Systems for Live Entertainment*, by John Huntington, includes several sections that deal with the subject.

ETC MIDI

The console both transmits and receives MIDI messages with any MIDI instrument. The MIDI protocol can control cues, macros, submaster bump switches and the level wheel.

ETC assumes that MIDI users have a working knowledge of MIDI. This section provides ETC MIDI interface information, message formats and message definitions. See *Installing MIDI, page 323* for installation information.

Configuring ETC MIDI

The console operates at all times in MIDI Mode 3 or Omni = off/Poly. This means it only receives or transmits MIDI commands on the user-selected channel.

Configure the console for ETC MIDI by specifying the MIDI channel number. Be sure your MIDI gear is set to the same channel. The console remembers the selected MIDI channel the next time it is turned on. The procedure for selecting the MIDI channel is given below:

1.	Press [Setup].	Go to the setup display
2.	Press [6] [Enter].	Selects the Options Settings menu
3.	Press [1] [Enter].	Prompt reads: Select MIDI channel (#1 through 16), or press DISABLE MIDI to disable MIDI
4.	Enter a number between 1 and 16. ^a	Specifies MIDI channel
5.	Press [Enter].	Completes the ETC MIDI setup

a. Press [S1], **Disable MIDI**, here to disable ETC MIDI.

ETC MIDI message formats

The following table lists MIDI message formats used to control the console. All numbers are in hexadecimal format.

Note off message format

<8n><kk><vv>

- 8 Note off status
- n MIDI channel number (0-F)
- kk Key number (0-7F)
- vv Note off velocity (0-7F)

Note on message format

<9n><kk><vv>

- 9 Note on status
- n MIDI channel number (0-F)
- kk Key number (0-7F)
- vv Note on velocity (0-7F)
 - [00=Note off]

Control change message format

<Bn><kk><vv>

- B Control change status
- n MIDI channel number (0-F)
- kk Control number (70-92)
- vv Control value (0-7F)

Program change message format

<Cn><kk>

- C Program (patch) change status
- n MIDI channel number (0-F)
- kk Program number (0-7F)

Pitch bend message format

<En><ll><mm>

- E Pitch bend status
- n MIDI channel number (0-F)
- II Least significant 7 bits of pitch bend value (0-7F)
- mm Most significant 7 bits of pitch bend value (0-7F)

MIDI Message definitions

Submaster bump switch execution

Submasters 1 - 12	C5 - B5	#60 - #71
Submasters 13 - 24	C6 - B6	#72 - #83

Note: C5 = MIDI note #60 or middle C.

Cue execution in AB fader pair

Next cue	Program change 0
Cues 1 - 127	Program change 1 - 127
Cues 128 - 255	Controller change 70, parameters 0 - 127
Cues 256 - 383	Controller change 71, parameters 0 - 127
Cues 384 - 511	Controller change 72, parameters 0 - 127
Cues 512 - 639	Controller change 73, parameters 0 - 127
Cues 640 - 767	Controller change 74, parameters 0 - 127
Cues 768 - 895	Controller change 75, parameters 0 - 127
Cues 896 - 999	Controller change 76, parameters 0 - 103

Cue execution in CD fader pair

Next cue	Controller change 77, parameter 0
Cues 1 - 127	Controller change 77, parameters 1-127
Cues 128 - 255	Controller change 78, parameters 0 - 127
Cues 256 - 383	Controller change 79, parameters 0 - 127
Cues 384 - 511	Controller change 80, parameters 0 - 127
Cues 512 - 639	Controller change 81, parameters 0 - 127
Cues 640 - 767	Controller change 82, parameters 0 - 127
Cues 768 - 895	Controller change 83, parameters 0 - 127
Cues 896 - 999	Controller change 84, parameters 0 - 103

Macro execution

Macros 1 - 127	Controller change 85, parameters 1 - 127
Macros 128 - 255	Controller change 86, parameters 0 - 127
Macros 256 - 383	Controller change 87, parameters 0 - 127
Macros 384 - 511	Controller change 88, parameters 0 - 127
Macros 512 - 639	Controller change 89, parameters 0 - 127
Macros 640 - 767	Controller change 90, parameters 0 - 127
Macros 768 - 895	Controller change 91, parameters 0 - 127
Macros 896 - 999	Controller change 92, parameters 0 - 103

Level change wheel

Pitch bend value (hexadecimal)	Message values (decimal)			
2000	ll=0	mm=64		
2001	ll=1	mm=64		
1FFF	ll=127	mm=63		
3FFF	ll=127	mm=127		
0	ll=0	mm=0		
228F	ll=15	mm=69		
1D71	ll=113	mm=58		
	Pitch bend value (hexadecimal) 2000 2001 1FFF 3FFF 0 228F 1D71	Pitch bend value (hexadecimal) Message (decir (decir) 2000 II=0 2001 II=1 1FFF II=127 3FFF II=127 0 II=0 228F II=15 1D71 II=113		

MIDI Show Control (MSC)

The consoles recognize the following MSC commands, which may be either transmitted or received (all other commands are ignored):

- Go
- Stop
- Resume
- Fire

Configuring MIDI Show Control

The console can receive MSC information, send MSC information, or both. Enable the sending and receiving of MSC information by specifying the device(s) that will act as the sender and receiver with respect to the console.

The sending and receiving device numbers are disabled by default. To enable these devices, proceed as follows:

1.	Press [Setup].	Go to the setup display
2.	Press [6] [Enter].	Selects the Options Settings menu
3.	Press [2] [Enter].	Prompt reads: Select MIDI receiver device (#0 - 126), or press DISABLE MIDI to disable MIDI Show Control
4.	Enter a number from 0 to 126. ^a	Specifies the number of the device that will send to the console (console is the receiver)
5.	Press [Enter].	Prompt reads: Select MIDI transmitter device (#0 - 126), or press DISABLE MIDI to disable MIDI Show Control
6.	Enter a number from 0 to 126. ^b	Specifies the number of the device that will transmit the MSC signal
7.	Press [Enter].	Completes the setup

- a. If the MIDI receiver device had been previously specified, press [S1], **Disable MIDI**, here to remove that specification.
- b. If the MIDI transmitter device had been previously specified, press [S1], **Disable MIDI**, here to remove that specification.

MSC commands received by the console

Consoles enabled for MSC accept the following MSC commands. When the console receives one of these commands, it executes the command immediately. In order to accept MSC commands, the console's receiver **Device ID** must match the target device ID for the MIDI device sending the signals.

Go	 If no cue number is sent, Go presses [A/B Go] on the console. The next cue on the cue list runs in the A/B fader. If a cue number is sent, the specified cue runs on
	the A/B fader.
	 If a cue number is sent, and 2 is sent as the list entry, that cue runs on the C/D fader.
	• If cue 0 is sent, and 2 is sent as the list entry, the command presses [C/D Go]. The pending cue runs in the
	C/D fader. You may also press [A/B Go] by sending Go-Cue 0-1 .
Stop	• The Stop command by itself holds all fades in both fader pairs.
	• If Stop is sent with a cue number and a list entry of 1, only the cue running in the A/B fader holds.
	• If Stop is sent with a cue number and a list entry of 2, only the cue running in the C/D fader holds.
	 The cue number field is ignored, but must be included if a list entry is sent.
Resume	 The Resume command by itself resumes all holding fades in both fader pairs.
	 If Resume is sent with a cue number and a list entry of 1, only a cue holding in the A/B fader resumes.
	 If Resume is sent with a cue number and a list entry of 2, only the cue holding in the C/D fader resumes.
	• The cue number field is ignored, but must be included if a list entry is sent.
Fire	• The Fire command executes a specified macro. Macro number must be in the range 1-127. If no macro is specified, or if the macro number is out of range, the command is ignored.

MSC commands transmitted by the console

MIDI Show Control (MSC) allows the console to send the following commands to MIDI devices. If MSC output is enabled on the console, the console automatically sends the MSC commands. The console's transmitter **Device ID** must match the device ID for the MIDI device receiving the signals.

[A/B Go]	 If a cue is pending, the console transmits [A/B Go] with cue number and a list entry of 1. If a cue is holding, the console transmits [A/B Resume] with cue number and a list entry of 1.
[C/D Go]	 If a cue is pending, the console transmits [C/D Go] with cue number and a list entry of 2. If a cue is holding, the console transmits [C/D Resume] with cue number and a list entry of 2.
[A/B Hold]	• If a cue is running, the console transmits [A/B Stop] with cue number and a list entry of 1.
[C/D Hold]	• If a cue is running, the console transmits [C/D Stop] with cue number and a list entry of 2.
Macros	• For macros 1-127, the console transmits Fire with the macro number.

MSC frame packet to run a cue:

An MSC frame packet consists of several bytes. Byte types, their hexidecimal values and explanations are given in the table below.

Byte type	Value (Hex)	Explanation
Start Byte	F0	Start of System Exclusive Message
	7F	Start of message
Send Channel		Send transmit channel number or 7F = "All Call" for system wide broadcasts
System Exclusive Message	2	Indicates System Exclusive Message is MIDI Show Control
"Lighting" command format	01	User can send 7F = "All Types"
"GO" general command		
Cue number		Cues numbered 0–9 are represented in an MSC frame as hexidecimal 30–39. For decimal cues, the point character is represented by hexidecimal 2E.
Delimiter	00	
Faders	31 or 32	Console faders are toggled by changing the Cue List number, with fader A/B represented by 31 and fader C/D represented by 32, both hexidecimal.
Delimiter	00	
Stop Byte	F7	End of System Exclusive Message

Examples

In the examples below, MSC frame packets are sent using transmit channel 66 (42 hexidecimal).

<u>G0</u>

Go A/B: Go C/D:	F0 F0	7F 7F	42 42	02 02	01 01	02 01	30 30	00 00	31 32	00 00	31 31	F7 F7	
GO CUE Cue1 A/B fader: Cue 5.6 A/B fader: Cue10 A/B fader: Cue350 A/B fader: Cue1 C/D fader: Cue2 C/D fader: Cue987 C/D fader:	F0 F0 F0 F0 F0 F0 F0	7F 7F 7F 7F 7F 7F 7F	42 42 42 42 42 42 42 42	02 02 02 02 02 02 02	01 01 01 01 01 01 01	01 01 01 01 01 01 01	31 35 31 33 31 32 39	00 2E 30 35 00 00 38	31 36 00 30 32 32 37	00 00 31 00 00 00	F7 31 00 31 F7 F7 32	00 F7 00	F7 F7 F7
STOP Stop A/B: Stop C/D:	F0 F0	7F 7F	42 42	02 02	01 01	02 02	30 30	00 00	31 32	00 00	31 31	F7 F7	
STOP CUE Cue 50 A/B Hold: Cue 50 C/D Hold:	F0 F0	7F 7F	42 42	02 02	01 01	02 02	35 35	30 30	00 00	31 32	00 00	F7 F7	
RESUME Resume A/B: Resume C/D:	F0 F0	7F 7F	42 42	02 02	01 01	03 03	30 30	00 00	31 32	00 00	31 31	F7 F7	

RESUME CUE

Cue 50 A/B Resume:F0 7F 42 02 01 03 35 30 00 31 00 F7 Cue 50 C/D Resume:F0 7F 42 02 01 03 35 30 00 32 00 F7

FIRE MACRO (Macros are limited to 1 - 127)

Macro 3:	F0	7F	42	02	01	07	03	F7
Macro124	F0	7F	42	02	01	07	7C	F7

Real time programs

The console allows you to create up to 500 real time programs that can run automatically when you're not there. For example, you may wish to turn on the work lights for a choir rehearsal between 7 PM and 9 PM on Monday and Wednesday. Or, warm the filaments of your studio instruments 15 minutes prior to your news program.

These programs run in real time, which means that they execute periodically when pre-set conditions arrive. These conditions include the time of day and either the day of the week or a date. The time settings can be absolute, such as 7:00 a.m., or they can be related to your local sunrise or sunset using the console's astronomical clock feature.

You must do two things before you can properly execute a real time program. First, you must set the real time clock. The procedure for setting the clock is given under *Scene mode, page 30*. Second, you must enable real time programs, which is explained in this chapter.

Go to the Real Time Programs display

Press [Setup] [1][2], **Real Time Programs**, [Enter] to go to the Real Time Programs display.

			Real Time	e Programs		Pr	rogrm 4
Friday	11 August	nn	03:19	9 PM			
Program	Time	Days	s/Date		Macro	Label	
1 2 3 4	08:00 AM 04:00 PM 04:00 PM 12:00 PM	Mon Mon 17 S	Wed Wed January	Fri Fri	1 2 3 4	Startup Mid End Birthday	ļ
			Select prog	gram number			
Sunrise O	6:00 AM					Sunset ()6:00 PM
S1	S2	S3	S4	S5	S6	S7	S8
Select Program	Time	Astro Clock	Days / Date	Macro	Label	More Softkeys	Return

Navigation and Feedback -	Real Tim	e Progra	ıms displ	ay	
	7 8 9 4 6 6 1 2 3	[S]	^↓	₩	±
Select a program	Х	Х	Х		Х
Select a field to edit		Х		Х	
Select new field data					Х
White row	Inc	dicates	progran	n select	ed
Yellow coloration	I	ndicate	s field s	selected	k

Enabling / disabling real time programs

Real time programs are enabled by default. Follow the procedure below to enable or disable real time programs:

Action:

Keystrokes:

- 1. Press [Setup]. Selects Setup display mode
- 2. Press [6] [Enter]. Selects Options Settings menu
- 3. Press [1][1] [Enter]. Prompt reads: Enable/Disable real time programs

(1 = enable, 0 = disable)

4. Press [1] [Enter]. Enables Real Time Programs.

Creating real time programs

You can create a real time program that references either the absolute local time or the astronomical times of sunrise or sunset. Also, you can specify either the days the program will run or a particular date.

Days and absolute times

Use this procedure when you want to specify days of the week and absolute times. Note in the footnotes to this procedure the substitutions that allow you to specify a date rather then days of the week and sunrise or sunset rather than the absolute time.

Action:

Keystrokes:

- 1. Press [Setup]. Selects Setup display mode
- 2. Press [1][2] [Enter]. Selects Real Time Programs display
- 3. Press [S1], Select Prompt reads: Program, [1] [Enter]. Enter time (12 hour clock) Press [+] to enter AM or PM
- 4. Press [8][0][0] [Enter].^a Enters time to run macro. Prompt reads:

Enter days of week (1=Mon, 2=Tue, 3=Wed, 4=Thu, 5=Fri, 6=Sat, 7=Sun) or press [Days/Date] softkey again for date

- 5. Press [1] [And] [3] [Thru] [5] Enters days to run macro [Enter].^b Prompt reads: Enter macro number
- 6. Press [5] [Enter].^c

Creates real time program 1 Prompt reads:

Type program label (F6 = clear to end, F7 = previous program label, F8 = next program label)

- a. To reference sunrise or sunset rather than absolute time, substitute steps A–C given under Referencing sunrise or sunset, page 289, for step 4 here. Then continue in this procedure.
- b. To reference a date rather than days, substitute steps A–D given under Referencing a date, page 289, for step 5 here. Then continue in this procedure.
- c. Labels are allowed in Express showfiles but cannot be assigned there. To assign labels for Express showfiles, see Expression Off-Line, page 312.

Referencing sunrise or sunset

To reference sunrise or sunset rather than absolute time, substitute the partial procedure below as explained under *Days and absolute times, page 288*. This example sets the time to 10 seconds before sunrise.

Key	ystrokes:	Action:			
A.	Press [S3], Astro Clock.	Prompt reads: Select astronomical time of day (0 = none, 1 = before sunrise, 2 = after sunrise, 3 = before sunset, 4 = after sunset).			
В.	Press [1] [Enter].	Selects before sunrise. Prompt reads: Enter time offset (hours/minutes)			
C.	Press [1][0] [Enter].	Enters time offset before sunrise when the macro runs Prompt reads: Enter days of week (1=Mon, 2=Tue, 3=Wed, 4=Thu, 5=Fri, 6=Sat, 7=Sun) or press [Days/ Date] softkey again for date			

Referencing a date

To specify a date rather than days of the week, substitute the partial procedure below as explained under *Days and absolute times, page 288*. This example sets the date to 21 March 2000.

Key	ystrokes:	Action:			
Α.	Press [S4], Days/Date .	Switches to date entry procedure Prompt reads: Enter date (0=all days of month) or press [Days/Date] softkey again for days of week			
Β.	Press [2][1] [Enter].	Selects date=21. Prompt reads: Enter month (#1–12)			
C.	Press [3] [Enter].	Selects month=3. Prompt reads: Enter last two digits of year or press [Thru] for all years			
D.	Press [0] [Enter].	Selects year=2000 Prompt reads: Enter macro number			

Editing real time programs

Once you have created a real time program, you can easily make changes to it and others in the Real Time Programs display.¹¹⁰ Press [\uparrow] or [\downarrow] to move from one program to the next. Press [\leftarrow], [\rightarrow] to move through program options. Although you cannot enter the label field in an Express console, you can label Express real time programs using Expression Off-Line. See *Expression Off-Line, page 312*, for more information.

Deleting real time programs

You can delete all real time programs as one of the Clear Functions reached from the Setup menu (option 12). Alternatively, you can delete one program at a time in the Real Time Programs display.

Delete a real time program with the following procedure:

Keystrokes:

- 1. Press [Setup].
- 2. Press [1][2] [Enter]. Selects Real Time Programs display

Action:

- 3. Press [S7], More
 Prompt reads:

 Softkeys, [S6], Delete
 Select program number(s) to

 Program.
 delete, then press ENTER

 To cancel, press CLEAR
- 4. Press [5] [And] [6] [Enter]. Selects programs 5 and 6 to delete Prompt reads: **To confirm, press ENTER To cancel, press CLEAR**
- 5. Press [Enter].

Deletes programs 5 and 6

Selects Setup display mode

Inserting real time programs

Keystrokes:

- 1. Press [Setup].
- 2. Press [1][2] [Enter].
- 3. Press [S7], More Softkeys, [S1], Insert Program, [4] [Enter].

4. Press [2] [Enter].

Action:

Selects Setup display mode

Selects Real Time Programs display

Specify insertion at program 4 Prompt reads:

Select program number to insert, then press ENTER To cancel, press CLEAR

Inserts two new programs starting with number. All following programs are renumbered

^{110.} While editing a real time program, you can run it simultaneously because the editing procedure is buffered in memory. The changes are recorded once you leave the Real Time Programs display and or sort the programs. See Sorting/recording real time programs, page 291.

Copying real time programs

Keystrokes:

- 1. Press [Setup].
- 2. Press [1][2] [Enter].
- 3. Press [S7], More Softkeys, [S2], Copy Program.
- 4. Press [1] [Thru] [5] [Enter].

Action:

Selects Setup display mode

Selects Real Time Programs display

Prompt reads:

Select program number(s) to copy, then press ENTER To cancel, press CLEAR

Selects programs 1 through 5 to copy Prompt reads:

To copy selected programs(s), select time and press ENTER Press [+] to enter AM or PM

5. Press [7][0][0] [+] [Enter].

Copies program 1 to a new program starting at 7:00 AM; the rest of the programs maintain their original relationship in time

Moving real time programs

You may move one or more real time programs from one time slot to another. (To move a single program, you may also use the arrow keys to highlight the time for the program you want to move, use the keypad to enter the new time, then press [Enter].)

Ке	ystrokes:	Action:				
1.	Press [Setup].	Selects Setup display mode				
2.	Press [1][2] [Enter].	Selects Real Time Programs display				
3.	Press [S7], More Softkeys , [S3], Move Program .	Prompt reads: Select program number(s) to move, then press ENTER To cancel, press CLEAR				
4.	Press [1] [Thru] [5] [Enter].	Selects programs 1 through 5 to move Prompt reads: To move selected programs(s) , select time and press ENTER Press [+] to enter AM or PM				
5.	Press [5][0][0] [Enter].	Copies program 1 to a new program starting at 5:00 PM; the rest of the programs maintain their original relationship in time.				

Sorting/recording real time programs

The console simultaneously sorts and records real time programs according to time of day when you exit the display or when you move, copy or delete programs. You can force a sort at any time you are in the display by pressing [S7], **More Softkeys**, [S8], **Sort**.

Time Code

You can create and run shows that respond to programming based on a standardized time code protocol. The console responds to the Musical Instrument Digital Interface (MIDI) time code.

The console generates an internal time code in the MIDI protocol. The console also can run under external MIDI. You can have both clocks simultaneously enabled so that if ever the external time code signal stopped during a show, the internal clock would immediately take over preserving the continuity of your show.

Shows designed for time code control consist of a series of events that play back at specified times. A time code program also has a modifiable loop time that ranges from 5 seconds to 24 hours. There can be as many as 3,000 time code events, with each event having any combination of cues loaded in faders (one cue for each of two faders), a submaster bump button or a macro.

Up to 32 events may be executed in a single frame.¹¹¹ Event times are expressed in hours, minutes and seconds, with each second broken down into frames. For example, 01:25:30:17 is one hour, twenty-five minutes, thirty seconds and seventeen frames. Two frame rates are available in addition to the default rate, which is thirty frames per second.

Setting time code frame rate

If you are running the time code program from an external clock with internal clock backup, make sure the internal clock has the same frame rate as the external clock. The default frame rate is 30 frames per second, but you can reset it to 24 or 25 frames per second. Reset it as follows:

Keystrokes: Actions:

1.	Press [Setup].	Selects Setup display
2.	Press [6], Options Settings , and press [Enter].	Selects Options Settings menu
3.	Press [6], Time Code Frames Per Second , [Enter].	Prompt reads: Select Time Code frames per second, then press ENTER (1 = 30 fps, 2 = 25 fps, 3 = 24 fps)
4.	Press [2] [Enter].	Time code frame rate is set to 25 fps

^{111.} If more than 32 events are assigned to the same frame, only the first 32 are executed in that frame, with the rest executing in the following frame or frames until all those assigned are used up. In manual mode, however, only one event is executed when step is pressed, regardless of how many are assigned.

Creating a time code program

You can create a time code program in either of two ways: by definition in the Time Code Events display or live after activating Learn Mode in the Time Code Events display. The cues, submasters or macros that you include in time code programs must be pre-recorded.

				Time C	ode Ev	ents		Ti	ime	
TimeCd	: 11:34:59:23			11:4	2 AM			Firs Las	st: 00 st: 23	:00:00:00 ::59:59:29
Even † 1 2 3 4 5	Time (30fps) 00:00:01:00 00:100:00 00:10:00:00 00:20:00:00	A/B 1 2	Rate	C/D 10 3	Rate	Bump 16 On 16 Off	Rate 150 150	Macro E E 1 E	Label Event Event Event Event	#1 #2 #3 #4
		(Pre	ss TIM	Select E to ed	Code T it spe	ime cific f	ields)			
S1	S2	S3		S4	S5		S6	ST	7	S8
Inter Cloc	nal Clock k Disable	Manu Mod	al -	Pause Mode	St	ер	Learn Mode	Mo Soft	one tkeys	Return

For all procedures in this chapter involving programming in the Time Code Events display, press [Setup] [1][3], **Time Code Events**, [Enter] [Enter] to go to that display. In the display:

- Press [Enter] to advance the cursor across the event line.
- Press horizontal arrows to move to other fields in the event line.
- Press vertical arrows to move up or down to other events.
- Press the right arrow at the end of an event line to move the pointer to the first field of the next event.
- Press the down arrow in the last event to create a new event.

Creating a program by definition

Use the following procedure to define a time code program in the Time Code Events display. A time code program created in this manner is not recorded until you leave the Time Code Events display, which sorts the program's events as well.¹¹²

Key	vstrokes:	Actions:
1.	Enter [1][0][0] [Enter].	Selects one second as the time of the first event you want to create Prompt reads: Select A/B Cue
2.	Press [1] [Enter].	Enters cue 1 for event 1 to play on the A/B fader. Prompt reads: Select A/B Rate (0 to 2000, 100 = Normal)
3.	Press [1][2][5] [Enter]. ^a	Enters a rate of 125 percent of the recorded fade rate Corner reads: Rate 125
4.	Press [Enter].	Highlight moves to the C/D field Prompt reads: Select C/D Cue
5.	Repeat steps 1 through 4 for fader C/D.	Moves the highlight to the Bump field. Prompt reads: Select submaster number for bump event, then press [+] for ON, or [–] for OFF
6. F	Press [1][2] [+] [Enter]. ^b	Selects submaster 12 and turns the submaster ON. Prompt reads: Select Bump Rate (0 to 2000, 100 = normal)
7.	Press [Enter].	Leaves fade rate at normal and moves the highlight to the Macro field Prompt reads: Select Macro
8.	Press [5] [Enter].	Selects macro 5 to run when event plays. Prompt reads: Enter Label
9.	Press [Enter].	You cannot enter a label from the console but can do so with Expression Off-Line. See <i>Expression Off-Line,</i> <i>page 312,</i> for specific details. Prompt reads: Select event number
10.	Press [2] [Enter]. Enter the number of an event followed by [Enter].	Selects event 2. Repeat steps above for this and subsequent events
	a. Zero stops the fade; 50 ro If no rate is entered, the	uns the fade at half its recorded rate. cue runs at its recorded rate.

b. Entering [+] sets the submaster ON; entering [–] sets the submaster OFF.

Creating a program using Learn Mode

Learn Mode allows you to record macro keys, submaster bump buttons and fader [Go] keys into time code events as you go along. Because you are making real-time decisions about the timing of events, you can record a program live in Learn mode without specifying code times. When you leave Learn Mode (press the Learn Mode softkey a second time), the program is recorded with sorted event times.

Follow these steps to record a time code program in Learn mode.

Keystrokes:

Actions:

TimeCd Learn flashes in red in the upper left corner of the screen

The internal clock, in the upper right

corner of the display, starts to run

- 1. Press [S7], until [S6] reads Learn Mode.
- 2. Press [S6], Learn Mode.
- If using the internal clock to time the show, press [S2], Clock Enable, to start the clock.^a
- 4. Go to the Stage display
- 5. If using an external clock, start it now. You must have time code input enabled as explained under *External time code clock, page 304*.
- 6. Select the cues, submasters and macros you want to record as time code events.
- 7. At the exact moment in the program that you want an event to begin, press
 [Go] for the fader in which you want the time code event to run the cue, press the submaster's bump button, or start the macro.
 Each button press is recorded as an event in your time code program
- 8. Press [Setup] [1][3] [Enter] [S6], Learn Mode. Returns to Time Code Events display and deactivates Learn mode; edit the events as necessary
 - a. After starting the clock, you may press [Record] to enter a blank event.

^{112.} You can force an immediate sorting the events in the Time Code Events Display. Press [S8], Sort, to sort the events. The sort key is in the third tier of softkeys in this display, so if you don't see it, press [S7], More Softkeys, until it appears at [S8].

Sorting/recording events

Events are recorded when sorting is done. Sorting is done when you leave the Time Code Events display or you end the time code Learn Mode. You can also force sorting without leaving the Time Code Events display.

A reason for sorting before leaving the Time Code Events display arises when you are playing the program you are currently editing. If the program has not yet come to the place where you made the edits, those edits will be effective on that pass. If, however, the program has already passed the place where you made the edits, those edits will not be effective until the next pass of the program. In some cases, you may want to reset the event list pointer, which is explained below.

To sort, note if your softkeys show Sort at softkey [S8]. If not, press [S7], **More Softkeys**, one or two times until that softkey appears. Then press [S8], **Sort**.

Editing time code programs

Edit time code programs in the Time Code Events display. While editing a time code program, you can run it simultaneously because the editing procedure is buffered in memory. Your edits, however, may not be effective immediately upon leaving the Time Code Events display because the program is controlled by the events list pointer. If that pointer has already passed an event you edited, the edits don't take effect until the event list pointer is reset to the beginning of the program.

Re-setting the event list pointer

The event list pointer jumps through time code events regardless of what the time code signal is doing. For example, if the program's next event is 100 frames away, the event list pointer resets immediately to that frame while a steady time code signal moves to it uniformly, frame by frame.

You can interrupt the program by interrupting the time code signal that drives it. If you are using the console's internal clock, you only need to disable that. Likewise, if you are driving the program with an external time code clock, you need only disable the external clock. If using both clocks, you need to interrupt both the internal and the external time code signals to interrupt the program.

Please note that when you disable an external clock while relying on the internal clock for backup, the resynchronization of the clocks cannot occur in less than five seconds after the external signal is restored. Any events scheduled during that resynchronization period will be missed on that pass but will be picked up on the next pass of the program.

If you have been editing the program, the events list pointer may need to be reset. Without leaving the Time Code Event Display and without disabling the clock, you can force the event pointer to reset with the Learn Mode softkey. This works because when you leave Learn Mode by pressing softkey [S6] a second time, you force a resorting of time code events in the program and a reset of the event pointer. There is no need to actually use Learn Mode—just press the Learn Mode softkey twice in succession to do the job.

Resetting loop time

A time code program loop plays from the first event time to the last event time, then resets and plays again. Any events with code times before the first time or after the last time are ignored. The resettable loop time can run from five seconds to 24 hours.¹¹³

If you are running a time code program from an external clock, the external clock will control the loop time with its own first event time and last event time settings. To provide synchronized internal clock backup, you must set the first event time and last event time in the Time Code Events display to correspond exactly with those times set for the external clock. Otherwise events might be missed until the two clocks synchronize. It takes at least 5 seconds for external and internal clocks to synchronize.

Use this procedure to set loop times either when running on the internal clock alone or when running from an external clock with internal clock backup.

Keystrokes:

Actions:

- 1. Press [S7] until [S8] reads **Reset Loop**.
- Press [S8], Reset Loop.
 Prompt reads: Enter first valid frame of internal time, then press ENTER. (Press TIME to edit specific fields)
 Press [1][0][0][0].
 Sets ten seconds as the starting time for the time code program
 Press [Enter].
 Prompt reads: Enter last valid frame of internal time, then press ENTER. (Press TIME to edit specific fields)
- 5. Press [5][0][0][0][0] then Sets the time code program to reset at the five minute mark

^{113.} If the loop is set to less than five seconds, the internal clock resets it to five seconds from the loop's starting time.

Deleting time code events

Follow these steps to delete time code events:¹¹⁴

Keystrokes:Actions:1.Press [S7] until [S6] reads
Delete Event.Prompt reads:
Select event number(s) to delete,
then press ENTER
To cancel, press CLEAR2.Press [S6], Delete Event.Prompt reads:
Select event number(s) to delete,
then press ENTER
To cancel, press CLEAR3.Press [5] [And] [6] [Enter].Enters events 5 and 6 to delete
Prompt reads:
To confirm, press ENTER
To cancel, press CLEAR4.Press [Enter] to delete the

4. Press [Enter] to delete the event or [Clear] to leave it unchanged.

Inserting time code events

Insert a time code event into an existing time code program with this procedure:

Actions: **Keystrokes**: 1. Press [S7] until [S1] reads Insert Event 2. Press [S1], Insert Event. Prompt reads: Select event number to insert, then press ENTER To cancel, press CLEAR Prompt reads: 3. Press [4] [Enter].^a Select number of events to insert, then press ENTER To cancel, press CLEAR 4. Press [2]. Indicates that you wish to insert two new events Corner reads: Insert 2 New events 4 and 5 are inserted; all 5. Press [Enter]. following events are renumbered

a. The new event(s) will be inserted before event 4.

^{114.} The **Clear Time Code Events** menu option on the Clear Functions menu allows you to delete all recorded time code events. To do so, press [Setup] [4] [Enter] [1][3] [Enter] [Enter].

Copying time code events

If you are creating a series of similar time code events, you may find it easier to create one event and then copy that as the basis for additional events. Follow the procedure below to copy a selected event or range of events to different code times:

Key	ystrokes:	Actions:
1.	Press [S7] until [S2] reads Copy Event.	
2.	Press [S2], Copy Event .	Prompt reads: Select event number(s) to copy, then press ENTER. To cancel, press CLEAR
3.	Press [1] [Thru] [5] [Enter].	Selects events 1 through 5 to copy Prompt reads: To copy selected event(s), select time and press ENTER. To cancel, press CLEAR
4.	Press [Time] [Time] [2][5].	Selects 25 seconds for the first event to copy
5.	Press [Enter].	Copies event 1 to a new event starting at 25 seconds; the rest of the events maintain their original relationship in time

Moving time code events

Follow this procedure to move a selected event or range of events from one code time to another. The event will move to the new time when you sort the event list or leave the Time Code Events display.

Keystrokes:		Actions:			
1.	Press [S7] until [S3] reads Move Event .				
2.	Press [S3], Move Event .	Prompt reads: Select event number(s) to move, then press ENTER To cancel, press CLEAR			
3.	Press [1] [Thru] [5] [Enter]. ^a	Selects events 1 through 5 to move Prompt reads: To move selected event(s), select time and press ENTER. To cancel, press CLEAR			
4.	Press [Time] [Time] [Time] [5].	Selects five minutes for the first event to move			
5.	Press [Enter].	Copies event 1 to a new event starting at the five minute point; the rest of the events maintain their original relationship in time			
	- To many a single event	where the second s			

a. To move a single event, you may also use the arrow keys to highlight the code time for the event you want to move, then press [+] or [–] until the new code time is displayed in the keypad prompt window, and press [Enter]. Or, use the keypad to enter the new time, then press [Enter].

Editing events

You may add, change or delete events in the Time Code Events display.¹¹⁵ The changes are effective when you quit the Time Code Event display or press the Learn Mode softkey twice.¹¹⁶

Follow the procedure below to edit a time code program:

Keystrokes:

Actions:

- 1. Use the arrow keys to Selects field to edit highlight the field of the item you want to edit.
- 2. Enter the new contents of the field. If you wish to delete the item, press [Clear].
- 3. Press [Enter], or use the arrow keys to select another field.

Range editing

If you wish to apply a change to a range of events, you may select multiple events and edit them all in a single step. For example, if you wanted to set the rates for your first ten events to 50 percent, proceed as follows:

Actions: **Keystrokes:** 1. Press [S7] until [S1] reads Select Event. Prompt reads: 2. Press [S1], Select Event. Select event number 3. Press [1] [Thru] [1][0]. The first rate field is highlighted 4. Press [S4]. Rate.^a Prompt reads: Select A/B Rate 5. Press [5][0]. Sets the rate to 50 percent 6. Repeat steps 6 and 7 for the remaining rate fields.

a. Alternatively, you can press other softkeys at this point to edit code time, cue, submaster or macro settings.

^{115.} The console does not permit labeling directly. Insert labels or edit in the label field with Expression Off-Line. See Expression Off-Line, page 312, for more information.

^{116.} Pressing the Learn Mode key twice is a shortcut way to reset the event list pointer. See Re-setting the event list pointer, page 296, for information.

Or, if you wanted to move ten events five seconds later in a program:

Or,	If you wanted to move ten e	vents five seconds later in a program:
Ke	ystrokes:	Actions:
1.	Press [S7] until [S1] reads Select Event.	
2.	Press [S1], Select Event.	Prompt reads: Select event number
3.	Press [1][1] [Thru] [2][0].	
4.	Press [S2], Code Time .	The time field is highlighted Prompt reads: Select Code Time (Press TIME to edit specific fields
5.	Press [Time] [Time].	Selects the seconds field for all ten events Prompt reads: Select seconds
6.	Press [+] five times.	Each time you press [+], the seconds field for each event increases by one second
7.	Press [Enter].	Sets the new times

Running a time code program

You can run a time code program in three ways: using the console's internal time code clock, using an external time code clock or manually.¹¹⁷ When using the external time code source, the internal clock serves as a back up to continue the program if the external clock fails.

Internal time code clock

Follow this procedure to run a time code program using the console's time code clock:

Keystrokes:

Actions:

1. Press [S1], Internal Clock. Prompt reads: Set internal clock, then press ENTER (Press TIME to edit specific

fields)

- 2. Use the keypad or the [+] and [-] keys to enter the code time of the first event you want to view, or enter zero to start at the beginning of the time code program.
- 3. Press [Enter].
- 4. Press [S2], **Clock Enable**, to start the internal clock running at the desired code time. ^a

Each time code event will run at its recorded time

a. This softkey toggles between Clock Enable and Clock Disable. A disabled clock is indicated by the message Clock Disabled in the upper left corner of the display and an unchanging **TimeCd** value. When the clock is enabled and runs, the **TimeCd** value runs up.

^{117.} As you play a time code program, you may find it useful to include the Time Code List in the Stage and Blind displays. Display the Time Code List by pressing [Setup] [6] [Enter] [7] [Enter] [1] [Enter].

External time code clock

When running a real time program with an external clock, the event list pointer jumps to agree with the frame of the external clock. Sometimes the timing signal is not yet present even though the external clock is enabled, causing a delay in the execution of the program. When that happens, you will see a **Waiting for input** message at the upper left corner of the Time Code Events display. When the external signal begins, the message disappears and the **TimeCd** value begins to run.¹¹⁸

You can lose events on the first pass through the program if the external signal starts before the program is ready.¹¹⁹ That happens because the event list pointer moves with the external signal and has already passed the code time of one or more events. These missed events, however, will be played in subsequent passes through the program.

Enable an external clock with the procedure below. Note that the procedure also enables the console's internal clock, which can then provide backup if the external clock signal fails. The order in which these two clocks is enabled is important. Also note that it takes at least five seconds for the external and internal clocks to come into synchronization, so any events during that initial synchronization period could be missed.

Ке	ystrokes:	Actions:
1.	Press [Setup].	Selects Setup display
2.	Press [6], Options Settings , and press [Enter].	Selects Options Settings menu
3.	Press [5], Time Code Input, [Enter].	Prompt reads: Enable/disable external time code input 0=Disable, 1 = Enable MIDI Time Code (MTC)
4.	Press [1] [Enter].	Enables the external MIDI time code clock
5.	Press [S8], Return.	Returns to the Setup display
6.	Press [1][3] [Enter].	Selects the Time Code Events option

7. Press [S2], Enable Clock. Enables the internal time code clock

^{118.} You can verify which clock is running the program by the color of the **Timecd** number in the upper left corner. A red number means the internal clock is running the program; a green number means that the external clock is running the program.

^{119.} Losing events on the first pass can also happen if you edit a program that is running at the same time. To avoid that, see *Re-setting the event list pointer, page 296*.

Manual playback

The [Manual Mode], [Pause Mode], and [Step] softkeys allow you to manually control playback of time code events without a time code source enabled. Press [Time] to select an event out-of-sequence by specifying its code time. Use either the Manual Mode or Pause Mode softkeys to ensure that neither an internal nor an external time code clock can run events while you are creating or editing a time code program.

Keystrokes:

Actions:

1.	Press [S3], Manual Mode or	Stops the time code input and resets the console to the first recorded time code event, or Interrupts time code input at the current time code event
F	Press [S4], Pause Mode .	
2.	Press [S5], Step . ^a	Advances to the next recorded time code event,
3.	Repeat step 4 to advance sequentially through time code events.	
4.	If you are in Manual mode, press [S3], Manual Mode . If you are in Pause mode, press [S4], Pause Mode .	Returns to normal operation and the time code resumes

a. In Manual mode, pressing [Step] starts with the first recorded time code event and proceeds in recorded order. Only one event is executed each time you press [Step].

Remote macros

The remote macro feature provides the ability to control up to 4 console macros from locations up to 1,000 feet away. Typically the Remote Macro control device is a four button control station.

The remote macro terminals on the console rear panel control macros 1,901 through 1,904. To operate one of these console macros from a remote location, press the appropriate control.

ETC does not provide remote macro control units. However, the console does provide a 15-pin connector labeled **Remote Macro** to which you may attach a user-supplied, remote macro control device. See *Installing remote macros, page 324* for more information about connecting a remote macro controller to your console.

Serial interface

Please disregard option 13, Serial Protocol Baud Rate, on the Options Settings menu as well as the associated softkey in that menu, [S2], **ESP Baud Rate**. Those choices are intended for the Express Lighting Playback Controller which has a RS232 serial interface port that is reserved for future implementation.

Remote trigger

The remote trigger function allows you to program a macro to send an On or Off signal to any external device that responds to a remote contact closure. This signal can control any external event (for example, a sound machine or a bubble machine).

To create a simple remote trigger macro, follow these steps:

Keystrokes:

Action:

1. Press [Setup]. Selects Setup display screen 2. Select 8, Macro Editing, Selects Macro display screen Prompt reads: and press [Enter]. Select macro number, then press ENTER Macro 10 created 3. Press [1][0] [Enter]. Prompt reads: Select operation(s) for this macro press ENTER MACRO when done Wheels and sliders are not valid entries in macros) 4. Press [S7] More Softkeys, Enters an On Trigger command Macro contents line reads: OnTrigger [S3], On Trigger. Enters a macro wait of 5 seconds 5. Press [S8], Macro Wait, [5] Macro contents line reads: [Enter]. **OnTrigger Mwait-5** Enters an Off Trigger command 6. Press [S4], Off Trigger. Macro contents line reads: **OnTrigger Mwait-5 OffTrigger** Saves macro. Macro 10 sends an On 7. Press [Enter Macro]. Trigger command, waits five seconds, then sends an Off Trigger command

Chapter 26 Accessories

Chapter 26 provides information about the following lighting system accessories:

- Remote Focus Unit (RFU)
- Alphanumeric keyboard
- Console lights
- Expression Off-Line

For accessory installation instructions, see *Appendix A Installation, page 313.* For purchase information, please contact your local dealer or ETC.

Remote Focus Unit (RFU)

The Remote Focus Unit (RFU) is a small, portable control panel you can use from a remote location, such as in the house, on your studio set or from backstage, with or without a remote monitor. You can control most console functions (not submasters) with an RFU. The console keypad and RFU are able to operate simultaneously. Changes made from both console and RFU are displayed immediately on both the console monitor and the RFU.



• Keypad

The keys on the RFU's keypad function exactly like their counterparts on the console.

Fader window

The top line displays the next cue on the cue list. The bottom line displays the cue in the A/B fader on the left and the cue in the C/D fader on the right.

Cue/channel number window

Displays the currently selected cue, group or submaster

G Keypad prompt window

Displays the same prompt that appears in the upper right corner of the Stage or Blind display.

6 Power switch

Power is **ON** in the up position and **OFF** in the down position. To operate your installed RFU, move power switch to **ON**. *WARNING:* Do not connect or disconnect the RFU when it is turned on.

For RFU installation instructions see *Installing Remote Focus Unit, page 322.* For instruction on installing a remote monitor, see *Installing remote video monitors, page 333.*
Alphanumeric keyboard

The Express console does not support an alphanumeric keyboard. However, if you have either a Remote Interface Unit or a Remote Video Interface unit attached to your console, you can attach an alphanumeric keyboard to that peripheral device and achieve the same results.¹²⁰

The keyboard's function is to allow you to assign labels (also called names) to your show and to elements of it, including cues, submasters, groups, channels, dimmers, time code events and fixtures. Names may have up to 16 characters, composed of letters, numbers or the symbols **#**, **%**, **&**, *****, (,), +, ', -, [,], / as well as the comma and period.

Labeling procedure

- Go to the display in which you want to create a label. For example, go to [Stage] or [Blind] to label cues, submasters, groups or focus points. Go to the Time Code Events display to label an event.
- 2. At the console, select the item to label. For example, if you want to label cue 5, press [Cue] [5] [Enter] to make the selection.
- 3. Press [F5] on the keyboard to enter label mode. When in label mode, a blue band appears at the upper right corner of the monitor containing a prefix, such as **Label**, and a blinking cursor.
- 4. Type the desired label on the alphanumeric keyboard. You may use the [Home], [End] and [Insert] keys on the keyboard when entering a label. Home and End allow you to move directly to the beginning or end of the name, respectively. Insert is a toggle that allows you to choose between overwriting or inserting text. You may also use [F6] to clear the label from the point of the cursor to the end of the line.
- 5. Press [Enter] on the alphanumeric keyboard to record the label, or press [Esc] to quit and return to the original console display screen.
- 6. Press [F8] on the alphanumeric keyboard to advance to the next selection, such as the next cue, submaster or group. Press [F7] to go to the previous selection.

Shows

To name a show, press [Setup], and use steps 3-5 of the *Labeling Procedure* above to enter the show's name.

^{120.} See Installing an alphanumeric keyboard, page 321, for installation information.

Console lights

Express provides two 3-pin female XLR type connectors at the top rear of the console for the attachment of optional Littlite gooseneck console lights. Littlites come in 6-inch (6X-HI), 12-inch (12X-HI), and 18-inch (18X-HI) lengths. They are available from ETC or from your dealer.

CAUTION: Use of any other brand but Littlites is not recommended by ETC. The results may be unexpected.

After installing control lights, adjust light intensity with the knob located above the power switch on the console's rear panel.

The lamps provide a 5 watt, high intensity light source, operating at 12 volts AC or DC and 380 mA. Lamp life is rated at 12 volts and will decrease with higher voltage operation.

Expression Off-Line

When you want to create or modify a program but are not near your console, consider working off-line with Expression Off-Line. This handy program runs on a pc computer and emulates the function of Express consoles running version 3.03 system software.

With Expression Off-Line, you can do everything in the computer you could do at your console keyboard except run a show. When the show you produce in Expression Off-Line is ready, merely store it on a diskette, transfer the diskette to your console, read it and run it. Or, if you want to modify a show stored in the console, you can do it in Expression Off-line as well and free the console for other purposes.

One advantage of using Expression Off-Line is that you can print lists from your show without attaching a printer to the console. Another special benefit for Express users is that you can label show elements, such as dimmers, cues and the show itself, and the labels appear with the show when you run it in the console. Type the keyboard equivalent "B" in Expression Off-Line whenever you are in a display that allows labeling, such as in cue and spreadsheet lists or the Real Time Programs display.

Expression Off-Line is available without charge from ETC. It can be ordered through your dealer or directly from ETC at 800-775-4382. You can also download Expression Off-Line from the ETC website at www.etcconnect.com.

Appendix A Installation

This appendix includes instructions for installing your console and optional accessories. *Chapter 3 System settings* and *Chapter 4 Patching channels* include instructions for entering the software settings you will probably update before you begin a new show.

Appendix A includes the following installation procedures:

- Installing your console
- Installing your monitor
- Connecting your dimmers
- System configuration
- Installing the alphanumeric keyboard
- Installing a printer
- Installing Remote Focus Unit
- MIDI
- ETCNet
- Installing remote video monitors
- Installing Remote Macros
- Installing console lights

An illustration of the console's back panel is shown on the next page. Operating instructions for optional accessories are included in *Chapter 26 Accessories, page 309*.

Console's back panel



External device fuse

If you have an external device such as console lights, an RFU or a remote macro controller connected to the console and it doesn't operate, check the External 12V fuse. This fuse is located in a pop-out receptacle located next to the RFU port.

- 1. Turn off the console.
- 2. Remove the power cord.
- 3. Remove the cover of the fuse receptacle with a flat blade screwdriver.
- 4. Remove and examine the fuse. Telltale signs of a blown fuse include discoloration or deposits on the glass envelope and/or a visibly broken fuse strip.
- 5. If you find a blown fuse, replace it with the fuse of the same size and type.
- 6. With a good fuse installed, reinsert the fuse into the rear panel holder and secure with the screwdriver.
- 7. Verify that the external device works properly. If still having problems, see *Help from ETC Technical Services, page 11*, to get help from ETC.

Installing the console and monitor

Follow these steps to install the console and its monitor:

- 1. Place console on a hard, stable, flat surface. Leave at least six inches of space behind console for ventilation and cable clearance. Console should be at least six feet from dimmers and high-current AC lines. *CAUTION*: Do not leave the console in a road case tray or on a soft surface. This will inhibit proper ventilation.
- 2. Move console power switch (by fan on back panel) to the Off position.
- 3. Connect the video cable from the monitor to the console connector labeled **CRT Display** on the back panel.
- Insert the female end of the console power cord into the connector on the power supply. Insert the round 6-pin connector on the power supply cord into the connector labeled **Power Input** on the console's back panel.
- 5. Insert the female end of the monitor power cord into the connector on the back of the monitor.
- 6. Insert the male end of the monitor power cord into a grounded power outlet.
- 7. Insert the male end of the console power cord into a grounded power outlet.

VGA monitor connections

Connector

HD-DB15 female

VGA monitor pinout

- 1 Red video
- 2 Green video
- 3 Blue video
- 4 Ground
- 5 Ground
- 6 Red ground
- 7 Green ground
- 8 Blue ground
- 9 not connected
- 10 Ground
- 11 Ground
- 12 not connected
- 13 Horizontal (H/V) sync
- 14 Vertical sync
- 15 not connected

Note: In some installations you may need additional grounding. An additional grounding location is provided on the rear of the console for this purpose. This console is not certified for use in wet locations.

Understanding ETCNet

The console is capable of operating with other devices in local area networks. ETC has two such networks, ETCNet and ETCNet2, and both operate using Ethernet protocols. None of the Expression-family consoles are capable of operating directly on ETCNet2. One exception is through the use of a ETCNet2 DMX Node as a DMX-to-ETCNet2 converter, but this network configuration will not be discussed in this User Manual.

When operating on ETCNet, any network interface device connected to the network mimics the output of the console. Your network devices can be the older-style Remote Interface Unit (RIU) devices or Remote Video Interface (RVI) devices. Or, they may be ETC's newest remote interface devices, including the ETCNet2 DMX Node and the ETCNet2 Video Node. You can mix and match old and new interface devices in your network. Only the newer nodes are capable of operating on ETCNet2.

Installing interface devices

To install RIU or RVI devices, follow the instructions given in the Reference appendix of this manual. To install an ETCNet2 node, see the separate Installation Guide for that device.

Network wiring

Express consoles are now designed to operate only with twisted pair network wiring.¹²¹ Connect a twisted pair cable to the RJ45 connector on the back of the console and run it to a network hub or interface device.

It makes a difference to your console whether you are connected to a hub or directly to an interface device. When connecting directly, the signals between the console and the interface device must be swapped on the twisted pairs. When connecting to a hub, that swapping is taken care of by the hub. To verify or change this setting, press [Setup] [6] [Enter] [1][2] [Enter]. Press 1or 0, if necessary, as directed by the screen prompt. Press [Enter] to complete the operation.

Preparing interface devices

Every device operating on your ETC network must be running the same system software. If you have a new system, most likely the software installed in each device is compatible with all the others. But different versions of software can exist in different devices because of software upgrades that occurred while the device was being manufactured. You should make sure.

To verify the software running on your interface devices and upgrade it if necessary, go to the Remote Unit Upgrade Program display. You reach this display using the Remote Interface diskette supplied with your system or in a system software upgrade kit. Follow the procedure given under *Upgrading remote interface devices, page 326*.

^{121.} If using an older console and thinnet, see Using thinnet with older consoles, page 334, for information and instructions.

Connecting dimmers to console

These instructions explain how to connect DMX512 outputs and provide DMX512 connector pinout specifications. The console provides two DMX512 output ports for a total capacity of 1,024 outputs.

Follow these steps to connect dimmers to your console:

1. Verify that your dimmer connector pinout matches the pinout listed below. If your pinout does not match, contact your dealer or ETC.

Caution: Your dimmer control common must be compatible with console control common; they must either be the same level, or the dimmer control common must float. Verify compatibility with your dealer if you are not sure.

2. Connect up to two DMX512 cables to DMX512 output connectors on the console's back panel (shown under *Console's back panel, page 314*).

DMX512 connector

XLR 5-pin female 512 digital multiplex dimmers

DMX512 pinout

- 1 Common
- 2 Data (--)
- 3 Data (+)
- 4 not connected
- 5 not connected

Configuring the DMX512 ports

Once your console is installed, you may need to reset some hardware configuration settings. The Output Configuration screen allows you to reset the starting dimmer numbers for your DMX512 ports, set your ports for dimmer doubling and adjust the DMX512 signal speed if your dimming system requires a slower signal.

Output Configuration Por 09:22 AM				Port 1	
10	1X512 Ports	Operating Mode	Starting Dimme	r Number	
	1 2	Normal Normal	1 513		
	Curren	t DMX512 Transmissio	n Speed: Max		
Select DMX512 port					
1 DMX512 0	2 DMX512 - Startin	o 4 DMX512 5	6 7	8	
Port	Mode Dimmer	Speed	o r	Return	

Port starting dimmer numbers

Each port has a starting dimmer number which can re reset in the Output Configuration display. Shown above are the default starting dimmer numbers for Express consoles.

Unless using dimmer doubling,¹²² you might want to set different starting numbers, such as when default port settings would result in some racks being connected to two ports. For example, if your system included 10 racks, each with 96 dimmers, you could set port 2 to start at **481**.

Set port starting numbers in the Output Configuration screen as follows:

- 1. Press [Setup] to display the Setup Menu.
- 2. Press [2], Output Configuration, and press [Enter].
- 3. Press $[\downarrow]$ to select the port to configure (port 1 or 2).
- 4. Press [S3], Starting Dimmer.
- 5. Enter the desired starting number for the port.
- 6. Press [Enter] twice to confirm your choice.

^{122.} You cannot change starting dimmer numbers when using Dimmer Doubling. See Setting the port to Dimmer Doubling, page 320.

Setting the port to Dimmer Doubling

If your console is controlling an ETC Sensor dimming system that can operate in Dimmer Doubling mode, each dimmer and the port to which the dimmer is connected must be individually set to support that feature. Moving light fixtures cannot be patched to a doubled port.

WARNING: Set the port mode using the procedure below BEFORE you create your patch. Changing a port to or from Dimmer Doubler mode unpatches all conventional lights and moving light fixtures controlled by that port.

Use the following procedure to set a port's mode to double. Use the procedure given under *Setting dimmers to Dimmer Doubling, page 48*, to set the mode of individual dimmers to double.

- 1. Press [Setup] to display the Setup Menu.
- 2. Press [2], Output Configuration, and press [Enter].
- 3. Press [S1], **DMX512 Port**, enter the port to configure (port 1 or 2). You may also use [↓] to select a port.
- 4. Press [Enter].
- 5. Press [1] to set the port for Dimmer Double mode or [0] to set the port for Normal mode.
- 6. Press [Enter] twice to confirm your choice.
- 7. Display identifies mode as either Normal or Double.

Setting DMX512 speed

If your console is controlling a dimming system that requires a slower DMX512 signal, specify this in the Output Configuration screen

The console is designed to run at the highest rate provided for in DMX512 specifications. Some dimming systems (including some Colortran ENR[™] dimmers) may require a signal slower than the full DMX512 specification. If this proves necessary, you may reset the console's signal speed.

Speed choices are **Slow**, **Medium**, **Fast**, and **Max**. When installed, the console defaults to **Max**. If you have problems with outputs flashing, fades not running smoothly, or unselected dimmers rising spontaneously, experiment with slower speeds until the symptoms disappear. If the symptoms persist, please call ETC Technical Services at the office nearest you.

To reset the DMX512 signal speed, follow these steps:

- 1. Press [Setup] to display the Setup Menu.
- 2. Select 2, Output Configuration, and press [Enter].
- 3. Press [S4], DMX512 Speed.
- 4. Press [0] for **Max**, [1] for **Fast**, [2] for **Medium**, or [3] for **Slow**. The speed you choose appears in the upper right corner of the display.
- 5. Press [Enter] to confirm your choice. The display shows the speed setting.

Installing an alphanumeric keyboard

Although your console does not support an alphanumeric keyboard, you can connect a keyboard to a Remote Interface Unit or Remote Video Interface. Use the optional keyboard to assign labels to many features of your shows, such as to name the show and the cues, submasters, groups, timed events and programs within it.

You can supply your own keyboard or order one from ETC. If you supply your own, it must be an AT compatible type or switchable to an ATcompatible mode. ETC recommends the Cherry G80-1800 and Keytronic 101 keyboards. Although you may use keyboards from other manufacturers, ETC does not guarantee compatibility.

CAUTION: Do not connect or disconnect an alphanumeric keyboard while your system is turned on. Doing so may cause the keyboard to initialize improperly.

Follow these steps to install an alphanumeric keyboard:

- 1. Be sure the selector switch is set to the AT position, if applicable.
- 2. Insert the keyboard cable into the connector labeled **Keyboard** on the remote interface unit.

Console connector

DIN 5-pin female

Keyboard pinout

- 1 Clock
- 2 Data
- 3 Reset
- 4 Ground
- 5 +5 Vdc

Installing a printer

The console supports parallel printers, including most laser printers. Printer functions are described in *Chapter 21 Printing, page 249.* Follow these steps to install the printer:

- 1. Insert the parallel printer cable into the connector labeled **Parallel Printer** on the back panel of the console.
- 2. Insert the opposite end of printer cable into printer.
- 3. Turn printer power switch on, and verify that printer is on line.

Console connec DB25F	tor Centronics D36	Printer connector
Pinout 1 2 3 4 5 6 7 8 9 10 11 12, 13 14 to 17 18 to 25	Signal STRB D0 D1 D2 D3 D4 D5 D6 D7 ACK Busy Not used not connected Ground	Pinout 1 2 3 4 5 6 7 8 9 10 11 12, 18 13 to 15, 17, 19 to 36 16
10 10 20	Ground	10

Installing Remote Focus Unit

The Remote Focus Unit (RFU) allows you to set channel levels, check dimmers or run cues from remote locations.

To install the RFU, follow these steps:

- 1. Verify that RFU power switch is turned **Off**. (Unit is off when switch is in the position toward the bottom edge of the RFU.)
- 2. Insert the RFU cable into the connector on the back of the console or Remote Interface labeled, **RFU**.
- 3. Turn RFU power switch to **On**.

RFU console connector

XLR 6-pin female

RFU pinout

- 1 Data (+) (to RFU)
- 2 Data (–)
- 3 Data (+) (from RFU)
- 4 Data (–)
- 5 Common (AC ground)
- 6 +12 Vdc (fused, 2 amp)

Installing MIDI

Connect the console to any MIDI equipment using a standard MIDI cable.

There are three round, 5-pin, DIN-type connectors labeled **MIDI In**, **MIDI Out**, and **MIDI Thru** on the back of the console. Turn console power off, then connect the cable from the **MIDI Out** of the electronic instrument or sequencer to the **MIDI In** on the console. Connect the cable from the **MIDI In** on the instrument or sequencer to the connector labeled **MIDI Out**.

Follow these steps to connect MIDI equipment to the console:

- 1. Turn console power off.
- 2. Insert standard MIDI cable into the connector on the back of the console labeled **MIDI In**. 3.If you are sending MIDI commands from the console, insert another standard MIDI cable into the connector on the back of the console labeled **MIDI Out**.

MIDI console connectors

DIN 5 pin female

MIDI pinout

- 1 not connected
- 2 Ground
- 3 not connected
- 4 MIDI +
- 5 MIDI –

Installing console lights

Plug the two Littlites into the connectors at the top rear of the console. Bend the gooseneck of each to suit your needs.

CAUTION: Use of any other brand but Littlites is not recommended by ETC. The results may be unexpected.

Connectors

XLR 3 pin female

Pinout for Littlites

- 1 Chassis ground
- 2 Dimming leg
- 3. + 12 Vdc

Connect the light between pins 2 and 3.

Installing remote macros

The console provides four remote macro inputs through the 15-pin connector on the back panel labeled **Remote Macro**. A user-supplied remote device connects to the console via a 24 AWG, aluminum-shielded, multi-conductor cable with one twisted pair designated for each switch (Belden 9507 S-R PCV Insulated or Alpha 5477 80 Deg. C 300 V PVC). The cable connector at the remote device will vary depending on the device itself.

Console connector DB-15 female

Remote connector Connector type depends on unit

- Pin Function
 - 1 +Macro 1,901
 - 2 –Macro 1,901
 - 3 +Macro 1,902
 - 4 –Macro 1,902
 - 5 +Macro 1,903
 - 6 –Macro 1,903
 - 7 +Macro 1,903
 - / +IVIacio 1,904
 - 8 –Macro 1,904
 - 9 Remote Trigger normally closed (30V 1 amp max)
 - 10 Remote Trigger normally open (30V 1 amp max)
- 11 Remote Trigger common (30V 1 amp max)
- 12 Ground
- 13 Ground
- 14 + 12 Vdc fused
- 15 + 12 Vdc fused

Wiring remote macros

There are three typical ways to wire the **Remote Go** function:

1. Connect all -Macro pins (pins 2, 4, 6, and 8) to ground (pins 12 and 13) and switch the leads connecting the +Macro pins (pins 1, 3, 5, and 7) to +12 Vdc (pins 14 and 15) as shown in the following diagram.



- Connect all +Macro pins (pins 1, 3, 5, and 7) to the +12 Vdc pin (pins 14 and 15) and switch the leads connecting the -Macro pins (pins 2, 4, 6, and 8) to the ground (pins 12 and 13).
- 3. Provide your own power supply that generates a 12 Vdc potential between the +Macro and -Macro pins and switch either of these leads.

Upgrading software

Upgrading a console

NOTE: If upgrading system software in a lighting playback controller (LPC), some of the steps below are slightly different because LPC controls are different. See your LPC QuickGuide for information about these differences.

Express software upgrades are distributed in kits that contain one or more upgrade diskettes and usually an installation document. Follow these kit instructions when provided. When upgrading, make sure the diskette you use is marked for your console.

- 1. Installing new console software clears all system memory. Please save your current show!
- 2. Turn the console off.
- 3. Insert the console software diskette into your console's diskette drive.
- 4. Turn the console back on. The console displays the boot screen and automatically installs the software. This process takes approximately one minute. The console displays the following messages as the installation progresses: **Loading**, **Erasing Flash**, **Writing Flash**. Wait until the Stage display appears.
- 5. Press [Setup] to confirm that the new software has been successfully installed. The current software version is displayed in the lower right corner of the display. This version number should match the number on the diskette. If it does not, repeat the procedure.
- 6. Press [4] [Enter] [S1], **Reset System**, [Enter] to complete the upgrade.
- 7. Remove the diskette from the disk drive and store.

Upgrading remote interface devices

If your console is connected through ETCNet to one or more remote units, you need to upgrade the system software in those units whenever you upgrade the console software. The reason is that every device operating on an ETC network must be using the same version of software.

If your network contains any of ETCNet2 nodes, you might need to set the network status before downloading the code. The reason is that these nodes can operate using either of two ETC local area protocols, ETCNet or ETCNet2, but Expression-family systems must use ETCNet. Setting the network configuration is covered in one of the following sections.

Remote Unit Upgrade Program display

Verify and upgrade the software operating in remote interface devices in the Remote Unit Upgrade Program display. Enter that display as follows:

- 1. Save your current show. Installing a new version of software will **not** clear system memory, but it is always best to be cautious.
- 2. Turn off the console.
- 3. Turn on all remote interface devices.
- 4. Insert the Remote Unit Upgrade diskette into your console's diskette drive.
- 5. Turn the console back on. The console will display a boot screen with a loading counter. When the count reaches 100%, the Remote Unit Update Program display appears.

Characteristics of the display

The display contains the following three elements: (1) the title line, (2) an inventory of network devices, and (3) the Remote Units list. The title line names the display and identifies the version of code on the diskette you used to bring up the display (the upgrade diskette). The device inventory, located below the title line, identifies all possible ETC network interface devices by type, version number and CRC number. For a device in your network to be compatible with the code on the upgrade diskette, both the version number and the CRC number must match.

Your console will detect remote interface devices operating on your network by listing them in the Remote Units list. From this list, you can make the following determinations.

- Are any interface devices in your network not showing up in the list?
- Does every device in your network display a software version that matches the version for that type in the device inventory?
- Does every device in your list display a CRC number that matches the CRC number for that type in the device inventory?

Devices missing from the Remote Units list

There can be several problems preventing an interface device from showing up on the Remote Units list, most of which are easily correctable. First of all, verify power to a missing device as well as to the hub to which it is connected, if any. Second, verify all network connections along the network route along between the console and the missing device. If your network uses twisted pair wiring, press [S6], **Swap Twst Pair**, and wait ten seconds. If a missing device is an ETCNet2 node, set the protocol to ETCNet by pressing [S5], **Discover Nodes**, and wait ten seconds. If all efforts fail, see *Help from ETC Technical Services, page 11*, for information about getting technical assistance.

Incorrect version or CRC number

If one or more devices on your Remote Units list does not show the correct version or CRC number, perform a software upgrade for that device. You have three options.

• Upgrade one unit

Use the console's arrow keys to move the cursor to the unit. Press [S3], **Update This Unit**.

• Upgrade some units

Use the console's arrow keys to move the cursor to a unit you want upgraded. Press [S8], **Mark This Unit**, to select that unit. If you want to upgrade others at the same time, repeat this marking procedure for each unit. An M will appear in the lines of marked units. When finished marking, press [S2], **Update Marked**, to upgrade the marked units.

• Upgrade all units

Press [S1], Update All Units, to download to all remote units at once.

While code is loading to a remote unit, the percent completion for that unit is shown in the display's Status column. When the word **Pass** appears, the upgrade for that unit is complete.

NOTE: It is normal for software to load faster to an ETCNet2 device than to a Remote Interface Unit or to a Remote Video Interface device.

Finish

- 1. Remove the Remote Unit Upgrade disk from the console disk drive.
- 2. Turn the console off.

Appendix B References

Remote Interface devices

Until the appearance of ETC's ETCNet2 devices, the only way you could perform remote network operations was with ETC's Remote Interface Unit (RIU) and the Remote Video Interface (RVI). ETC continues to support the RIU and RVI devices but no longer sells them.

This section covers the installation of the RIU and RVI devices with your system. For information about installing ETCNet2 devices, including the ETCNet2 DMX Node and ETCNet2 Video Node, consult the separate Installation Guides for those products.

Install a Remote Interface Unit or Remote Video Interface as follows:

- 1. Connect the network cable to the RJ45 twisted pair connector.¹²³
- 2. Plug the power cable into a grounded power outlet.
- 3. Set DIP switches and/or installing jumpers, as appropriate.
- 4. Install Remote Unit software (see *Upgrading remote interface devices, page 326*) for a discussion and procedure.

Installing jumpers

A jumper is a small plastic connector used to join a pair of pins sticking out of a printed circuit board. The jumper is installed when it covers both pins. It is not installed when it covers one or none of the pins (see illustration below).





Jumper not installed

Jumper installed

Remote Interface Unit (RIU)

The illustration below shows the RIU's back panel and indicates the connector used by each accessory. The front panel includes a connector for a digitizer (not used with Express consoles) and an alphanumeric keyboard.

The RIU back panel contains connectors for up to two monitors (only CRT 1 is active), three DMX512 outputs and an RFU.

^{123.} If using an older console and thinnet wiring, please see Using thinnet with older consoles, page 334, for information and instructions.



RIU DIP switch and jumper settings

The RIU's main circuit board contains one 8-switch DIP at location S1 and a set of 14 jumpers at location J22, as shown in the illustration below.



- 1. Remove the screws that secure the top panel.
- 2. Raise the top panel to expose the internal circuitry.
- Locate the DIP switches at location S1 on the corner of the circuit board nearest the power switch. Switches are either On (Closed) or Off (Open). DIP switch 1 must be Off and 2 must be On or the Remote Interface will not start. Adjust the settings as necessary to match the following table.

<u>Position</u>	<u>Function</u>
Off (Open)	Normal operation, Factory Use Only
On (Closed)	Normal operation, Factory Use Only
Off (Open)	Normal operation, Factory Use Only
Off (Open)	Normal operation, Factory Use Only
Off (Open)	Normal operation, Factory Use Only
Off (Open)	Normal operation, Factory Use Only
Off (Open)	Normal operation, Factory Use Only
Off (Open)	Normal operation, Factory Use Only
	Position Off (Open) On (Closed) Off (Open) Off (Open) Off (Open) Off (Open) Off (Open) Off (Open)

- 4. Locate jumpers 1 through 14. (location J22)
- 5. Jumper 13 must always be off. Jumper 14 should always be installed.
- 6. Install jumpers 7 through 12. Be certain jumpers 1 through 6 are not installed.¹²⁴
- 7. Close the face panel and replace the screws.
- 8. The Remote Interface checks DIP switch settings when it is turned on. Restart the unit for new DIP switch settings to take effect.

^{124.} If using an older console and thinnet wiring, please see Using thinnet with older consoles, page 334, for different jumper arrangements.

Replacing RIU fuses

The Remote Interface unit contains two pop-out 6.25 Amp fuses at the left side of the rear panel. Inspect and replace as explained below.

- 1. Turn off the device.
- 2. Remove the power cord.
- 3. Pull the fuse tray out of its holder by placing something sharp behind the tab on the bottom of the cover. The tray remains connected to the tray holder but rotates downward for convenience.

CAUTION: Operate the tray carefully to avoid damage.

- Examine both fuses. Telltale signs of a blown fuse include discoloration or deposits on the glass envelope and/or a visibly broken fuse strip.
- 5. If you find a blown fuse, replace it with the fuse of the same type and size.
- 6. With good fuses installed, rotate the tray up and inward until it is again flush with the panel.
- 7. Replace the power cord and check the console for proper operation. If still having problems, see *Help from ETC Technical Services, page 11*, to get assistance from ETC.

Remote Video Interface (RVI)

The Remote Video Interface provides ports for remote accessories. It supports one monitor (the connector labeled **CRT 1** is active), an alphanumeric keyboard and an RFU, and provides a serial port for a digitizer (digitizer not used with Express). The illustrations below show the RVI's front and back panels and indicate the connector used by each accessory.

ETCNet Remote Video Interface back panel



ETCNet Remote Video Interface front panel



Fuses

The RVI contains a 6.25 Amp power fuse in a recessed tray at the right side of the rear panel. Inspect and replace this fuse as explained in the section above entitled *Replacing RIU fuses*.

The RVI unit also contains a 1.5 Amp fuse to protect the RFU circuit. This fuse is contained in a pop-out receptacle located near the middle of the rear panel. Inspect and replace this fuse as explained under *External device fuse, page 314*.

Remote Video Interface settings

The RVI Processor Board is the lower circuit board in the Remote Video Interface (RVI). It contains one 8-switch DIP. Under normal conditions, these switches will never need to be changed.



If the settings get changed and you need to restore them, find the switches at location **S4** and adjust the settings as listed below. The RVI checks DIP switch settings when the unit is turned on. You must restart the unit for the new settings to take effect.

<u>DIP Switch</u>	<u>Position</u>	<u>Function</u>
1	On (Closed)	Normal operation, Factory Use Only
2	Off (Open)	Normal operation, Factory Use Only
3	Off (Open)	Normal operation, Factory Use Only
4	Off (Open)	Normal operation, Factory Use Only
5	Off (Open)	Normal operation, Factory Use Only
6	On (Closed)	Normal operation, Factory Use Only
7	On (Closed)	Normal operation, Factory Use Only
8	Off (Open)	Normal operation, Factory Use Only

Switches are either On (Closed) or Off (Open).

RVI ETCNet DIP switch settings

In order to enable the RVI for use on the ETCNet network, you must verify or adjust the settings of two sets of DIP switches. You will need to use a pin or a similar fine-pointed object to set the switches.

To set the switches, follow these steps.

- 1. Locate the two sets of DIP switches, visible through the right side panel of the RVI. See the drawing below.
- Set all six switches of the DIP closest to the front of the RVI to the Off position (up). Set all six switches of the DIP closest to the back of the RVI to the On position (down).¹²⁵



Installing remote video monitors

You can have additional monitors at remote locations. Connect them to RIUs or RVIs operating on ETCNet. These remote monitors duplicate the console's displays.

Connect monitors to interface devices by following these steps.

- 1. Insert the female end of the monitor power cord in the monitor connector, and the male end of the monitor power cord in the interface device connector labeled **Switched outlets**.
- 2. Connect the cable to the connector labeled CRT 1.
- 3. Turn monitor power switch to its **On** position.

VGA monitor console connector

HD-DB15 female

VGA monitor pinout

- 1 Red video
- 2 Green video
- 3 Blue video
- 4 Ground
- 5 Ground
- 6 Red ground
- 7 Green ground
- 8 Blue ground
- 9 not connected
- 10 Ground
- 11 Ground
- 12 not connected
- 13 Horizontal (H/V) sync
- 14 Vertical sync
- 15 not connected

^{125.} If using an older console and thinnet wiring, please see Using thinnet with older consoles, page 334, for different DIP switch settings.

Using thinnet with older consoles

Older model Express consoles supported thinnet as well as twisted pair wiring for networking. The thinnet option is no longer available for Express consoles or Express Lighting Playback Controllers. If you are using one of those older models and wiring with thinnet, however, follow the instructions below.

Network wiring

Your console may be connected to the network using either thinnet (BNC) or twisted pair (RJ45) wiring. If operating with an ETCNet2 device, you must connect to it using twisted pair wiring. That means that if you are running a network cable from the console directly to the ETCNet2 device, it must be a twisted pair cable connected to the console's RJ45 port. If you are connecting the console to a hub however, and the hub supports thinnet, you may run thinnet cable between the console and the hub. Cabling to any other device from the hub may be by whatever means the hub and other devices support.

RIU jumpers

Install jumpers 1 through 6. Be certain jumpers 7 through 12 are not installed.

RVI DIP switch settings

Set all six switches of the DIP closest to the front of the RVI to the **On** position (down). Set all six switches of the DIP closest to the back of the RVI to the **Off** position (up).

Appendix C Error messages

Diskette error messages

Bad Disk

Disk is unformatted or defective. Try formatting it. If that doesn't work, try a different disk.

Corrupted Disk

This disk is defective. Try formatting it. If that doesn't work, try a different disk.

Data not recorded on disk

You cannot read the System Configuration settings from showfiles created with software Version 3.02 or earlier. You must save the show with 3.03 or later software to include System Configuration settings.

Disk controller failure

Call ETC Technical Service at the office nearest you.

Disk full

Disk contains other files. Remove enough files to make room for show file.

File not found

This disk does not appear to have a show stored on it. Please confirm that you have inserted the correct disk.

No disk in drive

Show diskette must be inserted in the diskette drive before you can save or read a show.

Unknown disk error - try again

Try the diskette again. If it fails again, call ETC Technical Service at the office nearest you.

Write-protected disk

The write-protect tab on this diskette is open. Close the tab to unprotect the diskette.

Other error messages

Out of memory

You have used up all system memory allotted to the function with which you are working. Delete unnecessary parts of the show to free up memory. If this doesn't work, you may want to break the show into two shows, one for each act. This message may also appear if you attempt to run too many effects.

ETCLink errors

ETCLink is the communications software that serves the Dimmer Monitoring System, explained in *Chapter 24 Dimmer monitoring, page 263*. ETCLink provides advisory messages for a wide variety of conditions, including information regarding your dimmers, racks, system, data, ports, and loads. These messages fall into two categories, fatal messages and secondary messages.

Fatal messages deal with anything that could potentially terminate or drastically change the look of your show. You may set fatal messages to be displayed even when secondary messages have been disabled.

Secondary messages deal with individual dimmer problems and warnings of potential rack temperature problems. These messages are generally less critical than the fatal messages. If you wish, secondary messages may be disabled without disabling fatal messages. See *Error messages*, *page 265*, for more information.

Fatal messages

Dimmer # has shut down due to an overtemperature condition. The dimmer will remain shut down until the condition is cleared at the dimmer rack. Use Dimmer Status to determine the rack number for the dimmer.

Rack # DMX port A/B failure. Either there is a problem with the DMX cabling/connections between the console and the rack, or the rack has been configured incorrectly.

Rack # A/B/C phase input (main) voltage is in error at #V.

Rack # input (main) frequency is out of spec at #Hz.

Rack # has shut down due to fan failure or other interruption of air flow. Please check the rack, looking for dirty air filters, blocked air passages, or fan failure.

ETCLink has failed. Please check cabling and connections. If the problem persists, please call a qualified service technician.

Rack # processor error.

Secondary Messages

Dimmer # has a load, but the recorded load is zero. Because the recorded load is zero, the Dimmer Monitoring system is unable to determine whether the dimmer has a load error.

The load on dimmer # has changed. Because the dimmer output is not at a high enough level, the Dimmer Monitoring system is unable to determine the size of the load. To correct the problem use [Check Loads] to determine the size of the load change.

The load on dimmer # has changed from #W to #W. A decreased load indicates lamp failure. An increased load indicates that a lamp has been added since the last [Record Load]. Correct the problem or, to prevent further error messages, use [Clear Load] or [Record Load].

DC output has been detected on dimmer #. If this condition persists, it may harm the connected load. Please check the connected load.

An SCR has failed On/Off in dimmer #. The dimmer should be replaced.

Dimmer # output has failed on. The dimmer should be replaced.

Dimmer # output has failed off. Either the circuit breaker has tripped or the dimmer needs to be replaced.

Dimmer #'s load has failed. The most likely cause is a lamp failure. Either replace the lamp or, to prevent further error messages, use [Clear Load] or [Record Load].

Data error on Rack # DMX port A/B. Please check DMX cabling and connections between the console and the rack.

Rack # ambient temperature is high at # degrees F. The temperature does not yet exceed acceptable operational limits, but the rack should be checked. Please check the cooling/ventilation in the dimmer room.

Rack # ambient temperature is low at # degrees F. Please check the heating/ventilation in the dimmer room.

Rack # ambient temperature is outside the acceptable operating range at # degrees F. Please check the cooling/ventilation in the dimmer room immediately.

A ground fault (GFI/RCD) error has occurred in dimmer #. Use Dimmer status to determine the rack number for the dimmer.

The phasing in Rack # is not allowed. The rack has been shut down. Please check the input power service.

Appendix D Showfile

Each showfile saved with version 3.03 (or later) system software contains recordings or settings in two general programming classifications. Some programming pertains directly to the show, such as recordings of cues, groups and focus points. Other programming pertains to your system configuration, such as clock or MIDI settings that seldom if ever change.

At your option, you can read show and configuration contents separately or at the same time using the console's diskette read operations. If you read show contents only from the diskette, your console's system configuration at that time will not change. Conversely, if you read only the system configuration contents from the diskette, the show information in console memory does not change.

The portion of a showfile that represents show contents is identified below. There are some configuration settings, however, that are also considered part of the show contents. These are identified on the next page. Also identified on the next page is the portion of the showfile that represents configuration contents, and which can be read separately.

Show contents

- Bump button status
- Channel attribute settings
- Cues and their settings
- Dimmer profile and proportional settings
- Dimmer profile revisions
- Doubled dimmers
- Encoder setup
- Fixture attribute setup
- Focus points
- Groups
- Link lists
- Macros
- Parked channels and dimmers
- Patching for conventional lights
- Patching for ML fixtures
- Show name
- Personalities loaded
- Submasters and their settings
- Time code events

Configuration settings

Read show results

Certain configuration information is included with show contents information when you do a *Read Show From Disk* operation. These items are identified below by the display in which each may be edited.

Setup display Show name System Settings display Number of channels Number of dimmers Default fade time Default level Default fader clear time Default Sneak Time Scene mode **Output Configuration display** DMX512 mode Starting Dimmer DMX512 speed **Options Settings display** Time code input Time code frames per second Display Cue / Time Code list Powerup macro

Time Code Events display Clock enable / disable

Read system configuration results

Certain configuration information is retrieved when you perform a *Read System Configuration From Disk* operation. These configuration items are identified by the display in which each may be edited.

System Settings display

Blackout key Flexichannel Master type Record lockout Bump keys

Options Settings display

ETC MIDI channel ETC MIDI show control device IDs ETCLink (enable) ETCLink address Real Time Programs (enable) External port Twisted pair polarity Baud rate ETCLink Functions display Display advisories Clock Functions display

12 / 24 hour clock Latitude

Longitude Time zone

Appendix E Softkeys

Stage			
	[Stage]	Stage 2	
S1	Sneak	Enable/Disable Quickstep	
S2	Update	Sub List	
S3	Background Overrides	Solo	
S4	Only	Previous Page	
S5	Follow	Next Page	
S6	Park	Delete	
S7	More Softkeys>Stage 2	More Softkeys>Stage 3	
S8	Fixture	Flash	

Stage			
	Stage 3	[Stage] [Fixture] [Only]	
S1	Part	Position	
S2	Load Sub	Image	
S3		Color	
S4	Fader	Beam	
S5	Rate	None	
S6		Attribute	
S7	More Softkeys>Stage	Return	
S8	Step	Fixture	

	Blind/Cue			
	[Blind] [Cue]	Cue 2		
S1	Select Cue	Part		
S2	Cue List>Cue List	Follow		
S3	Spreadsheet>Cue SS	Solo		
S4	Only	Previous Page		
S5	Rate	Next Page		
S6	Delete Cue			
S7	More Softkeys>Cue 2	More Softkeys>Cue		
S8	Fixture			

Blind/Cue			
	Cue List	Cue SS	
S1	Part	Select Cue	
S2	Follow	Create Cue	
S3	Rate	Replace Level	
S4	Previous Page	Previous Page	
S5	Next Page	Next Page	
S6	Delete Cue	Delete Cue	
S7		Enable/Disable Tracking	
S8	Return>Cue	Return>Cue	

Blind/Group			
	[Blind] [Group]	Group List	Group SS
1	Select Group		Select Group
2	Group List>Group List		Create Group
3	Spreadsheet>Group SS		Replace Level
4	Previous Page	Previous Page	Previous Page
5	Next Page	Next Page	Next Page
6	Delete Group	Delete Group	Delete Group
7	Only		
8	Fixture	Return>Group	Return>Group

	Blind/Focus			
	[Blind] [Focus Point]	Focus List	Focus SS	
1	Select Focus		Select Focus	
2	Focus List>Focus List		Create Focus	
3	Spreadsheet>Focus SS		Replace Level	
4	Previous Page	Previous Page	Previous Page	
5	Next Page	Next Page	Next Page	
6	Delete Focus	Delete Focus	Delete Focus	
7	Only			
8	Fixture	Return>Focus	Return>Focus	

Blind/Submaster			
	[Blind] [Sub]	Sub 2	
1	Select Sub	Bump Status	
2	Sub List>Sub List		
3	Spreadsheet>Sub SS	Solo	
4	Only	Previous Page	
5	Rate	Next Page	
6	Delete Sub		
7	More Softkeys>Sub 2	More Softkeys>Sub	
8	Fixture		

Blind/Submaster			
	Sub List	Sub SS	
1	Bump Status	Select Sub	
2	Hold		
3	Rate	Replace Level	
4	Previous Page	Previous Page	
5	Next Page	Next Page	
6	Delete Sub	Delete Sub	
7			
8	Return>Sub	Return>Sub	

Blind/Cue/Effect			
	[Blind] [Cue /Effect] (CE)	CE 2	CE 3
1	Step	Step	
2	Cue List>Cue List	Step Time	Follow
3	Spread Sheet>Cue SS	In/Dwell/Out	
4	Previous Page	Low/High	
5	Next Page	Insert Step	Rate
6	Delete Cue	Delete Step	
7	More Softkeys>CE 2	More Softkeys>CE 3	More Softkeys>CE
8	Add Channels	Attribute>Attributes	

В	Blind/(Cue or Sub)/Effect		
	Attributes		
1	Positive/Negative		
2	Alternate		
3	Reverse		
4	4 Bounce		
5	5 Build		
6	Random		
7	Random Rate		
8	B Return>CE		

Blind/Submaster/Effect			
	[Blind] [Sub/Effect] (SE)	SE 2	SE 3
1	Step	Step	Bump Status
2	Sub List>Sub List	Step Time	
3	Spread Sheet>Sub SS	In/Dwell/Out	
4	Previous Page	Low/High	
5	Next Page	Insert Step	Rate
6	6 Delete Sub Delete Step		
7	More Softkeys>SE 2	More Softkeys>SE 3	More Softkeys>SE
8	Add Channels	Attribute>Attributes	

Blind/Subroutine			
	[Blind] [Cue/Subr]	Subr 2	
1	Step	Step	
2	Cue List>Cue List	Select Cue	
3	Spread Sheet>Cue SS	Rate	
4	Previous Page	Type/Level	
5	Next Page	Insert Step	
6	Delete Cue	Delete Step	
7	More Softkeys>Subr 2	More Softkeys>Subr	
8	Style	Up/Down/Follow	

Stage/Fader			
	[Fader]	Fader 2	Fader 3
1	Select Fader	Enable/Disable Quickstep	
2	Update	Load Sub	Part
3	Background Overrides	Solo	
4	Only	Previous Page	
5	Follow	Next Page	Rate
6	Park	Delete	
7	More Softkeys>Fader 2	More Softkeys>Fader 3	More Softkeys>Fader
8	Return	Fixture	Step

	Stage/Park		
	[Park]		
1			
2	A		
3	В		
4	Previous Page		
5	Next Page		
6			
7			
8	Return		

	Patch			
	[Patch]	Patch 2		
1	Dimmer Double			
2	А			
3	В			
4	Previous Page			
5	Next Page			
6	Unpatch	Profile		
7	More Softkeys>Patch 2	More Softkeys>Patch		
8	Fixture Patch>Fixture Patch	Show/Hide Labels		

	Setup - System Settings (1), Output Config (2) and Clear (4)			
	System Settings (1)	Output Configuration	Clear Functions	
1	Purge Flexi	DMX512 Port	Reset System	
2		DMX512 Mode		
3		Starting Dimmer		
4		DMX512 Speed		
5				
6				
7				
8	Return>Setup	Return>Setup	Return>Setup	

	Setup - Print (5) and Options (6)			
	Print Functions	Options	ESP	
1	Stop Printer	Disable MIDI	9,600 Baud	
2	Pause Printer	ESP Baud Rate > ESP	14,400 Baud	
3			19,200 Baud	
4			28,800 Baud	
5			38,400 Baud	
6	6 57,600 Baud			
7			115,200 Baud	
8	Return>Setup	Return>Setup	Return>Options	

Setup - Macro Editing (8)			
	Macro Editing	Macro 2	
1	Select Macro	On Sub-Bump	
2	Insert/Replace	Off Sub-Bump	
3	Delete Entry	On Trigger	
4		Off Trigger	
5		Copy Macro	
6	Delete Macro	Macro Enter	
7	More Softkeys>Macro 2	More Softkeys>Macro	
8	Return>Setup	Macro Wait	

Setup – ETC Link Functions (9)			
	ETC Link Functions	System Status (1)	Rack Status (2)
1	Enable/Disable ETCLink	Dimmer Double / Normal Fire Mode	
2	A	Play Backup	
3	В	Record Backup	
4			System Status
5		Dimmer Status	Dimmer Status
6	Unset Dimmer	Rack Status	Select Rack
7	Set Dimmer		
8	Return>Setup	Return>ETC Link	Return>ETC Link

Setup - ETC Link Functions (9)			
	Dimmer Status (3) Load Management (4)		
1		Print Screen	
2			
3			
4	System Status	Load Check	
5	Select Dimmer	Record Loads	
6	Rack Status Clear Loads		
7		Cancel	
8	Return>ETC Link	Return>ETC Link	

Setup – Profiles (10), Channel Attributes (11)					
	Profiles	Channel Attributes	LL		
1	Profile	Independent	Link		
2	Percent	Flip	X Channel		
3	Clear All	16 Bit	Y Channel		
4	Clear to End	Previous Page	Position		
5	Fill Between	Next Page	Insert Link		
6	Copy to Profile	LTP	Delete Link		
7	Reset Profile	Link List>LL	Move Link		
8	Return>Setup	Return>Setup	Return>Chan Att		

Setup - Real Time Programs (12)						
	Real Time Programs	RTP 2				
1	Select Program	Insert Program				
2	Time	Copy Program				
3	Astro Clock	Move Program				
4	Days / Date	Previous Page				
5	Macro	Next Page				
6		Delete Program				
7	More Softkeys>RTP 2	More Softkeys>RTP				
8	Return>Setup	Sort				

Setup – Time Code (13)						
	Time Code (TC)	TC 2	TC 3			
1	Internal Clock	Select Event	Insert Event			
2	Clock Enable/Disable	Code Time	Copy Event			
3	Manual Mode	Cue	Move Event			
4	Pause Mode	Rate	Previous Page			
5	Step	Bump	Next Page			
6	Learn Mode	Macro	Delete Event			
7	More Softkeys>TC 2	More Softkeys>TC 3	More Softkeys>TC			
8	Return>Setup	Reset Loop	Sort			
Setup – Moving Light Functions (15)						
-------------------------------------	--------------------------	--------------------------	-------------------	--		
	Personality Setup	Fixture Patch	FP 2			
1	From Disk	Select Fixture	Select Fixture			
2			Start Channel			
3	View Personality	Personality	DMX512 Port/Start			
4		Previous Page	Remote Dimmer			
5		Next Page	Swap Focus			
6	Delete Personality	Delete Fixture	Flip			
7	Reset Defaults	More Softkeys>FP2	More Softkeys >FP			
8	Return>Moving Light Ftns	Return>Moving Light Ftns	Autoload Encoders			

Setup – Moving Light Functions (15)		
	Attribute Setup	Encoder Setup
1	Select Attribute	Select Encoder
2	Category	Page
3		Attribute
4	Previous Page	
5	Next Page	
6		Autoload Encoders
7	Reset Defaults	Reset Defaults
8	Return>Moving Light Ftns	Return>Moving Light Ftns

Appendix F Time and location

United States cities

<u>City. State</u>	<u> Time Zone (Standard)</u>	<u>Latitude</u>	Longitude
Albuquerque, NM	+ 7 West	35° 03′	N 106° 37′ W
Anchorage, AK	+ 10 West	61° 10′	N149° 11′ W
Atlanta, GA	+ 5 West		N84° 26′ W
Baltimore, MD	+ 5 West		N
Augusta, ME	+ 5 West	44° 19′	N69° 48′ W
Billings, MT	+ 7 West	45° 47′	N 108° 32′ W
Boise, ID	+ 7 West	43° 36′	N 116° 13′ W
Boston, MA	+ 5 West	42° 20′	N71° 01′ W
Buffalo, NY	+ 5 West	42° 53′	N78° 51′ W
Burlington, VT	+ 5 West	44° 29′	N73° 13′ W
Charleston, SC	+ 5 West	32° 47′	N79° 59′ W
Cheyenne WY	+ 6 West	41° 08′	N 104° 47′ W
Chicago, IL	+ 6 West	41° 50′	N87° 41′ W
Columbus, OH	+ 5 West	40° 00′	N82° 53′ W
Dallas, TX	+ 6 West	32° 47′	N96° 45′ W
Denver, CO	+ 7 West	39° 46′	N 104° 52′ W
Des Moines, IA	+ 6 West	41° 34′	N93° 37′ W
Detroit, MI	+ 5 West	42° 22′	N83° 06′ W
Fargo, ND	+ 6 West	46° 52′	N96° 49′ W
Hartford, CT	+ 5 West	41° 45′	N72° 41′ W
Honolulu, HI	+ 10 West	21° 79′	N157° 48′ W
Kansas City, MO	+ 6 West		N94° 33′ W
Las Vegas, NV	+ 7 West		N 115° 13′ W
Lincoln, NE	+ 6 West	40° 48′	N96° 41' W
Little Rock, AR	+ 6 West	34° 43′	N92° 21′ W
Los Angeles, CA	+ 8 West		N 118° 24′ W
Indianapolis, IN	+ 5 West	39° 44′	N
Madison, WI	+ 6 West	43° 04′	N
Nashville, TN	+ 6 West		N86° 41′ W
Miami, FL	+ 5 West	25° 49′	N80° 13′ W
Minneapolis, MN	+ 6 West	44° 57′	N93° 16′ W
Montgomery, AL	+ 6 West		N86° 17′ W
New Orleans, LA	+ 6 West		N89° 55′ W
New York, NY	+ 5 West	40° 46′	N73° 58′ W
Oklahoma City, OK	+ 6 West	35° 28′	N97° 30′ W
Philadelphia, PA	+ 5 West	40° 00′	N75° 08′ W
Phoenix, AZ	+ 7 West	33° 32′	N 112° 04′ W
Portland, OR	+ 8 West	45° 32′	N122° 39′ W
Raleigh, NC	+ 5 West	35° 52′	N78° 47′ W
Salt Lake City, UT	+ 7 West	40° 46′	N111° 55′ W
San Francisco, CA	+ 8 West	37° 47′	N122° 33′ W
Seattle, WA	+ 8 West	47° 37′	N122° 21′ W
Sioux Falls, SD	+ 6 West	43° 32′	N96° 43′ W
Washington D.C	+ 5 West		N77° 00′ W

Cities outside the United States

<u>City. State</u>	<u> Time Zone (Standard)</u>	<u>Latitude</u>	La	ngitua	<u>le</u>
Abuja, Nigeria	1 East		N7°	Ī1′	Е
Algiers, Algeria	1 East		N3°	3´	Е
Amsterdam, Netherlands	1 East	52° 17′	N4°	57´	Е
Ankara, Turkey	2 East		N32°	52´	Е
Athens, Greece	2 East		N23°	43´	Е
Bangkok, Thailand	7 East	13° 44′	N 100°	31′	Е
Berlin, Germany	1 East	52° 27′	N13°	22´	Е
Berna, Switzerland	1 East		N7°	26´	Е
Bombay, India	6 East	18° 54′	N72°	49´	Е
Brussels, Belgium	1 East	50° 50′	N4°	20´	Е
Buenos Aires, Argentina	+ 3 West		S58°	27´	W
Cairo, Eqypt	2 East		N31°	15´	Е
Cape Town, South Africa	2 East		S18°	22′	Е
Casablanca, Morocco	0		N7°	35´	W
Copenhagen, Denmark	1 East		N12°	35´	Е
Dublin, Ireland	0		N6°	15´	W
Edinburgh, Scotland	0		N3°	13′	W
Edmonton, Alberta, Canad	a 7 West	53° 33′	N	28′	W
Fukuoka Japan	- 9 Fast	33° 35′	N	24′	F
Helsinki, Finland	- 2 Fast	60° 10′	N	58′	F
Hong Kong	- 8 Fast	22° 18′	N 114°	09′	F
Jakarta Indonesia	- 7 Fast	6° 10′	S 106°	48′	F
Lima Peru	+ 5 West	12° 03′	S 77°	03	Ŵ
Lisbon Portugal	0	38° 43′	N 9°	8′	Ŵ
London England	0	51° 30′	N 0°	0′	Ŵ
Madrid Spain	- 1 Fast	40° 24′	N 3°	41′	W/
Marseilles France	- 1 Fast	43° 18′	N 5°	23	F
Mexico City Mexico	+ 6 West	19° 24′	N	09′	Ŵ
Montreal, Quebec, Canada	n + 5 West	45° 30′	N	36′	W
Moscow, Russia	- 3 Fast		N	20′	F
Munich. Germany	1 East		N 11°	34′	Е
Oslo, Norway	- 1 Fast	59° 56′	N	44′	F
Paris. France	1 East		N2°	29′	E
Praque. Czechoslovakia	1 East		N14°	25′	E
Revkiavik, Iceland	0		N21°	56´	Е
Riga, Latvia	3 East		N 106°	10′	Е
Rio De Janeiro, Brazil	+ 3 West		S43°	12´	W
Rome, Italy	1 East	41° 48′	N12°	36′	Е
San Juan, Puerto Rico	+ 4 West		N66°	07´	W
Santiago, Chile	+ 4 West		S70°	42´	W
Sapporo, Japan	9 East		N141°	21′	Е
Seoul, Korea	9 East		N126°	58´	Е
Singapore, Malaysia	8 East		N 103°	55	Е
Stockholm, Sweden	1 East		N	04´	Е
Svdnev. Australia	10 East		S151°	12´	Е
Taipei, Taiwan	8 East		N121°	31′	Е
Tokvo, Japan	9 East		N139°	46´	Е
Toronto, Ontario, Canada	+ 5 West		N79°	23´	W
Vancouver, B.C., Canada	+ 8 West		N123°	07´	W
Vienna, Austria	1 East		N16°	22´	Е
Warsaw, Poland	1 East		N21°	02´	Е
Wellington, New Zealand	12 East	41° 71′	S 174°	46´	Е

Appendix G Specifications

Differences between the three models at a glance.

	Express 24/48	Express 48/96	Express 72/144
Dimmers	1,024	1,024	1,024
Maximum Channels	96	192	240
Channel Faders	48	96	144
Two-scene operation	24 Channels	48 Channels	72 Channels
Submasters	24*	24	24

Electrical

- Voltage input 100-240 VAC, 50-60 Hz
- Maximum current 0.8 amps

Built-in interfaces

- 1,024 DMX512 outputs
- Parallel printer
- Remote Focus Unit
- Remote Macro control
- Remote Trigger option
- MIDI Time code control
- ETCLink
- Console lights

System capacity

- 600 cues per show
- 48, 72 or 144 control channels
- Proportional patching of up to 1,024 DMX512 dimmers
- Eight-part multipart cues
- Thirty-three dimmer profiles, all but one of which are editable
- 500 groups
- 99 focus points
- 2,000 macros
- 24 overlapping submasters
- Ten pages of submaster memory
- Two timed/manual fader pairs

Fader functions

- Fade times programmable from 0.1 seconds to 99:59 minutes
- Manual override of upfade and/or downfade
- Rate override
- Split time fades
- Manual fades

- Background fades with LTP channels
- User selectable default fade times
- Hold/Back functions
- Two-scene preset

Playback controls

- Two timed/manual fader pairs
- Two [Go] buttons
- Two [Hold] buttons
- Two [Back] buttons
- Two [Rate] buttons
- Two [Clear] buttons
- 24 submasters¹²⁶
- Programmable Master on 100mm potentiometer
- Blackout function
- Trackpad
- Eight softkeys to streamline operations

Timed control

- Internal or external clock
- 12-hour or 24-hour timing
- References sunrise and sunset with astronomical clock
- Up to 500 user-created, Real Time Programs

Display functions

- VGA video output
- Extensive online Help displays available for all functions
- Stage
- Blind
- Fader
- Effects
- Spreadsheets: Cues, Submasters, Groups and Focus Points
- Patch
- Park
- Setup
- Flexichannel (displays only recorded channels)
- Channel attributes

Submaster functions

- Ten pages of recorded submasters each
- Fully overlapping channel assignments
- Proportional channel levels
- The bump buttons for all submasters may be enabled, disabled or placed in solo mode as a group or individually
- Integral LEDs on all submasters
- Programmable fade and wait times

^{126.} On the Express 24/48, the 24 submasters are also the bottom 24 channel faders on the console.

- Live and programmed rate control
- Submasters either overlapping pile-on or inhibitive
- All submasters programmable with effects
- Update function
- Control keypad features
- Spreadsheet editing
- Submaster list

Channel functions

- 8-bit and 16-bit data types
- Both highest level (Highest Takes Precedence) and last action (Latest Takes Precedence) channel types
- Group function to proportionally manipulate channels
- [And], [Except], [Only], and [Thru] functions for selection of control lists
- [Full] function
- [Level] sets a channel to an editable default value
- Independent channels
- Flip channel
- Link List allows channels to be linked together for control by the trackpad

Moving light functions

- Fixture personalities may be loaded from diskette
- Patch fixtures by assigning personalities, starting channels, starting DMX512 address, remote dimmer, swap focus, pan or tilt flip
- Five attribute categories
- Fixture box level adjustment
- Fixture focus with Solo

Cue functions

- Up to 600 cues in the range 0.1 to 999.9
- Discrete upfade and downfade times (00:00-99:59) for each cue
- Linked cue sequences
- Effect cues
- Split wait times
- Follow time
- Link to cue or macro
- Eight-part multipart cues
- Selective cue recording
- Update cue command
- Attribute range editing
- Subroutines, with cue or style steps
- Spreadsheet editing
- Cue list

Group functions

- Up to 500 groups
- Any cue or submaster may be accessed as a group
- Spreadsheet editing
- Group list

Focus point functions

- up to 99 preset focus points
- Hard key for quick access
- Update cues and submasters when focus point changes
- Record level of focus point without link
- Available in effects
- Printout available
- Spreadsheet editing
- Focus point list

Diskette functions

- 3.5-inch high-density diskette drive for show storage
- One show per disk
- Software updates installed through diskette drive
- Retrieve show and configuration contents separately or together

Macro functions

- Up to 2,000 macro selections for programming
- Macros may activate any key except [Enter Macro]
- Live Learn mode
- Macro editing
- Macros programmable for Macro wait
- Can include in real time programs
- Can include in time code events
- Four macros operated by remote switches
- Powerup macro
- Remote Trigger function

Effects functions

- Effects may be recorded as cues or submasters
- Up to 100 steps each
- Live effects recording
- Spreadsheet editing
- 8-bit and 16-bit data types
- Variability of rate during playback
- Step times
- In/Dwell/Out Step fade times
- High/Low Levels
- In/Dwell/Out Effect fade times
- Range editing of effect attributes and step values

Profile functions

- Profiles may be assigned to dimmers
- Ten preset profiles, nine of which are editable
- Twenty-three additional profiles that may be programmed

Options

- Parallel printer
- Remote Focus Unit
- Lighting Playback Controller
- Remote Interface Unit
- Remote Video Interface
- Remote Macro controls
- Console lights

Size and weight

Express 24/48

- 43 x 15 x 6 inches
- 30 pounds

Express 48/96

- 43 x 24 x 6 inches
- 35 pounds

Express 72/144

- 54 x 24 x 6 inches
- 40 pounds

Appendix H Declaration of Conformity

CE

DECLARATION OF CONFORMITY

We, Electronic Theatre Controls, Europe Limited

Unit 5, Victoria Industrial Estate, London W3 6UU United Kingdom

declare under sole responsibility that the product

Product name:		Express Lighting Control Console
Product type/model:		Express 24/48, Express 48/96, Express 72/144, Express 125 and Express 250
Lot:		n/a
Batch / Serial nur	nber:	n/a
Item numbers:		one of each model
to which this declaration		relates is in conformity with the following standards:
EN60950 Safety		of Information Technology Equipment
following the pro-	visions	of EU LV Directive(s) 73/23/EEC
EN55022	Emissi	ons standard for IT equipment (class B environment)
EN50081-1	Generi light in	c emissions standard for residential, commercial and dustrial applications
EN50082-2	Generi	c immunity standard for industrial applications

following the provisions of EU EMC Directive(s) 89/336/EEC and 92/31/EEC

London, United Kingdom (Place of issue)

(Date of Issue)

Mr Adam Bennette (Name of authorised person)

(signature of authorised person)

Appendix I Limited Warranty

Electronic Theatre Controls, Inc. (ETC[™]) warrants to the original owner or retail customer (Customer) that during the warranty period ETC will repair or replace its products that are defective in materials or workmanship under normal use and service, subject to the terms of this limited warranty. The warranty period shall begin on the date of delivery of a portable system or on the date of energization of a permanently installed system, and shall continue for the following periods: (a) one year, for all Irideon products, and (b) two years, for all other ETC products. Warranty is limited to (60) days from shipment for purchase of demo or loaner products.

Warranty does not cover any product or part of a product subject to accident, negligence, alteration, abuse or misuse, or any accessories or parts not supplied by ETC. Warranty does not cover "consumable" parts such as fuses, lamps, color media or components warranted directly to the owner by the original manufacturer. ETC's warranty does not extend to items not manufactured by us. Freight terms on warranty repairs are FOB ETC factory or designated repair facility. Collect shipments or freight allowances will not be accepted.

ETC's sole responsibility under this warranty shall be to repair or replace at ETC's option such parts as shall be determined to be defective on ETC's inspection. ETC will not assume any responsibility for any labor expended or materials used to repair any equipment without ETC's prior written authorization. ETC SHALL NOT BE RESPONSIBLE FOR ANY INCIDENTAL, GENERAL OR CONSEQUENTIAL DAMAGES, DAMAGES TO PROPERTY, DAMAGES FOR LOSS OF USE, TIME, PROFITS OR INCOME, OR ANY OTHER DAMAGES.

The customer's obligations during the warranty period under this warranty are to notify ETC at ETC's address within one week of any suspected defect, and to return the goods prepaid to ETC at their factory or authorized service center.

THIS WARRANTY IS CONTINGENT ON THE CUSTOMER'S FULL AND TIMELY COMPLIANCE WITH THE TERMS OF PAYMENT SET FORTH IN THE "TERMS AND CONDITIONS." THIS WARRANTY IS EXPRESSLY IN LIEU OF ANY AND ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND OF OTHER OBLIGATIONS AND LIABILITIES ON OUR PART. THE CUSTOMER ACKNOWLEDGES THAT NO OTHER REPRESENTATIONS WERE MADE TO HIM OR RELIED UPON BY HIM WITH RESPECT TO THE QUALITY AND FUNCTION OF THE GOODS SOLD.

This written warranty is intended as a complete and exclusive statement of the terms thereof. Prior dealings or trade usage shall not be relevant to modify, explain or vary this warranty. Acceptance of, or acquiescing in, a course of performance under this warranty shall not modify the meaning of this agreement even though either party has knowledge of the performance and a chance to object.

Terms and Conditions

The following terms and conditions, and those on the face hereof, shall control as to any order accepted by Electronic Theatre Controls, Inc. (ETC), notwithstanding any terms and conditions that may be contained in any purchase order or other document of Customer, and ETC's acceptance of any order is expressly made conditional on Customer's assent to such terms and conditions. Such terms and conditions will constitute the entire agreement between the parties as to any order and will supersede any prior understandings, agreements, representations, or warranties. Such terms and conditions will not be modified, added to, superseded or otherwise altered except by written document signed by an authorized representative of ETC, notwithstanding any terms and conditions contained in the purchase order or other document of Customer. ETC's

commencement of performance and/or delivery shall not constitute a waiver of these terms and conditions or any acceptance of any terms and conditions contained in the Customer's order or other documents. Acceptance of any product or service by the Customer will be construed as acceptance of ETC's terms and conditions. Any dispute or questions of construction with respect to any order placed with ETC shall be governed by the laws of the State of Wisconsin.

All prices are in US Dollars, FOB ETC's factory or warehouse. Prices, models and specifications are subject to change without notice. Orders must be in writing. Phone orders will be accepted from established accounts when followed by written confirmation. The acceptance of any order does not imply conformance with plans and specifications unless the plans and specifications accompany the order and are accepted as binding by ETC. Equipment ordered which differs in any way from our standard catalog items will require drawings approved in writing by the Customer. When drawings are approved, they shall take precedence over all other written or verbal instructions. Orders are effective only when accepted and acknowledged by the factory. Minimum order is \$25.00 net, exclusive of freight.

Price protection will be given on orders entered for immediate shipment and for project orders entered before the effective date of a price increase. All other orders will be billed at the current price at time of shipment. Quotations for custom products are valid for thirty (30) days.

ETC will attempt to ship goods for delivery on or about the times stated on the reverse side hereof, although time shall not be the essence in this contract. ETC will attempt to follow customer's written instructions as to mode and routing of shipments. In absence of such instructions, ETC shall have absolute discretion as to mode and routing of shipments, including express or parcel post for small shipments. Where the customer has requested expedited freight, the customer will be responsible for the incurred additional charges.

ETC shall not be liable for late delivery and/ or inability to perform due to unforeseen circumstances or conditions, including our ability to obtain supplies and raw materials, government regulations, labor stoppages, casualties, fire, and other causes beyond our control. When such circumstances or conditions have been remedied. ETC will make and Customer will accept delivery/ performance. Equipment is shipped at the Customer's risk and our obligation to deliver equipment is discharged upon their delivery in good condition to the carrier. Shipments are FOB ETC factory or warehouse. ETC will prepay and bill freight on UPS shipments. Freight and air are sent collect unless specifically quoted otherwise. Unless specifically prohibited. partial shipments will be made. Federal, state and/or local taxes, duties and other charges are the responsibility of the purchaser.

Any changes in engineering drawings, specifications, or in other terms of manufacture, assembly or shipment, requested by customer, must be in writing and approved by ETC. If any such change by Customer causes an increase in the cost of, or in the time required for performance of, any part of the contract, then ETC shall make a reasonable adjustment to the price of the goods.

If purchaser cancels any portion of a Purchase Order prior to shipment, Purchaser shall be liable to ETC for a cancellation charge equal to ETC's actual costs incurred in connection with that portion of the Purchase Order that is cancelled, including, without limitation, labor and materials. Customer represents that it is solvent. ETC retains a security interest in the goods to secure payment of the purchase price and all other indebtedness now or hereafter owed by the customer to ETC. At ETC's request, customer will execute a financing statement or statements evidencing such security interest and will take any other action necessary to perfect the same.

Payment terms are net 30 days after date of invoice. If ETC in good faith doubts customers ability or willingness to pay, ETC may in its discretion complete its performance of this contract upon a cash in advance basis or make deliveries only upon a C.O.D. basis or file a UCC filing or suspend all or part of its performance here under. All payments are applied to the oldest outstanding invoice. Accounts over thirty (30) days are subject to a 1 1/2% (one and one-half percent) per month late payment penalty. ETC will have the option of withholding performance under any and all orders from the Customer if an invoice remains unpaid after 30 days. All disputes otherwise unresolved between ETC and Customer shall be resolved in a court of competent jurisdiction in the location of ETC's offices, Dane County, Wisconsin. If suit or action is instituted by ETC to enforce payment or performance by the Customer, the Customer agrees to pay all costs and attorney's fees incurred.

Claims for shortage or damaged goods must be made within ten (10) days. Equipment is carefully packed and delivered in good condition to the carrier. All claims for loss or damage in transit must be made by the consignee directly to the carrier. ETC will render every aid and assistance in the presentation and enforcement of such claims without waiver of our rights to have compliance with the terms of payment of our invoices.

Equipment returned without ETC's written permission will not be accepted. Equipment returned for credit must be in accordance with established RMA procedures. Equipment must be unused, in original cartons and in saleable condition, subject to ETC's quality control and test inspection. Restocking charges of \$25.00 or 25% of invoice (whichever is greater) plus any repacking or reconditioning costs will be deducted from the credit. Returns for warranty work will be via warranty procedures. In no case will permission be granted to return specially-modified or custom equipment, or merchandise invoiced more than six (6) months prior to date of Customer's return request.

No failure of ETC to insist upon or compel compliance by the customer with any of these terms and conditions shall be constructed as a waiver by ETC of its right to insist upon compliance. No waiver by ETC of any breach by customer shall be effective unless in writing signed by ETC, and no waiver by ETC of any breach by customer shall be deemed a waiver of any other breach.

If ETC shall fail to repair or replace defective goods within a reasonable time after they are returned to ETC, or if ETC shall wrongfully fail to make delivery or shall wrongfully repudiate this contract, then customer shall be entitled to recover from ETC such part of the purchase price as has been paid by customer to ETC. The remedy stated in the preceding sentence shall be customer's exclusive remedy for any breach, non delivery, or repudiation by ETC or for any other liability of ETC to customer. This exclusive remedy shall not be deemed to have failed its essential purpose so long as ETC is willing and able to repair or replace defective parts in the prescribed manner.

Index

Numerics

16-bit
About Channel 60
Enable 53
1-to-1 Patch 36
•
A
A/B display
In two scene mode
Status 16
About Channel
Background overrides
Explained 60
About Dimmer
Error reporting
Explained 46–47
About Show 34
Romoto Focus Unit 310
Allidue cue
Subroutine step 220
Alphanumeric keyboard
Function
Installation 321
Astronomical Clock 33
Р
Back key
Back panel diagram 314
Background
Channel 17
Fader 4
Override
Backup looks
Playing 276
Recording
System Status display
Backup, power fail
Baud Rate 306
Blackout cue
Blackout key
Enable/Disable 27
M/ith Dark 190
VVIUI Faik 189 Plind
Cup List 170
Uisplay

Multipart cues 115

Bump buttons
Enable/Disable
Status
0
C/D display
Status
Captured channels
Defined
In Patch
Category
Default assignments
Definition
Reset defaults
CD80
Channel
About
Captured
Captured in Patch
Channel check
Channel levels
Color
Flash
Full
Match to submasters
Modes
Moving
Park
Recorded
Release captured
Selected
Selecting channels
Set number
Sneak
Specifications
System settings
Tracked
Channel Attributes
Clear
Print
Settings 53-55
Channel zero
Setting dimmer count
Unpatching dimmers 39
Check
Channel 59
Сце 127
Dimmer 15
Dimmer loads 272
Clear
Channel attributes 255
Clear Functions menu

Blocking cue

Fader Functions Groups Groups Macros Macros Moving lights Patch Real time programs Reset system Show SMPTE events Submasters Time code events	121 254 149 273 255 255 255 255 254 255 254 255 298 170 255
Real time	-33 304 303
Color Channel/Fixture LEDs Submasters Tracked channels defined Color scrollers Configuration	14 156 172 52 239
Read from disk Saved to showfile Write to diskette	247 339 245
Alphanumeric keyboard Dimmer	321 318 333 322 322
Copy Cue or group to sub Cues Macro SMPTE events Submasters	170 99 234 299 170
Cue type. Subroutine step Cue Allfade Back key Blackout Blackout cue. Blind Blocking Clear Command display list Copy Copy to sub	80 220 79 80 121 108 108 84 6 255 172 113 99 170

Cue check	127
Cue/Command	172
Default Fade Time	24
Delete	98
Follow	89
Go	121
Go to	124
Hold	121
Insert	100
lahel	311
	88
	91 91
Load to sub	169
Maximum number	79
Modify	102
Modify attributes	05
Multipart defined	
	104
	194
	124
	127
	8/
Record from stage	83
Record in Blind	84
Record with fade time	85
Record with split fades	86
Recording with solo	.92, 131
Select cue	124
Specifications	353
Spreadsheet	179
Stage	83
Subroutine	80
Subroutine steps	220
Туре	80
Update	96–97
View	81
Custom patch	37
D	
	31
Default	
Channel/Submaster link	
Dimmer protiles	43
Encoder	74
Fade Time	24
Fader Clear Time	25

 Cues
 .98

 Fixture
 .70

 Focus point
 .149

 Group
 .137

 Link
 .242

Delete

Part of multipart cue	115 298
Submaster	170
Dimmer	
About Dimmer	46
About with FTCL ink	. 10
Check	. 47
Clear leads	. 4J 272
	275
	. 40
	209
	319
	320
Error messages	265
	318
Load check	272
Park dimmer	190
Patch	5, 37
Pinout	318
Port setup	319
Rack status	268
Record loads	271
Sensor	263
Set	274
Strand CD80 rack	49
Unpatch	
	274
	2/4
Sot dimmors	10
Set DMVE12 port	. 40
Set DIVIASTZ port	267
	207
	4.1
	. 41
Programming	2-43
	. 43
DIP switch	
EICNet	333
Remote Interface	330
Remote Video Interface332	-333
Disable	
Blackout key	. 27
Bump buttons	. 29
Flexichannel	. 27
MIDI Show Control	281
Record Lockout	. 29
Discover nodes	327
Diskette	
Drive specifications	354
Erase diskette	244
Error messages	335
Format	244
Management	244
Read all.	246
Read configuration only	247
Read show only	247
Write configuration	245
	0

Write showfile
Display
Blind16, 84
Channel Attributes
Clear Functions
Cue List
Dimmer System Status
Diskette Functions
ETCLink Functions
Fixture patch
Flexichannel
General features
Macro
Output Configuration
Patch
Print Functions
Rack status
SMPTE Edit
Specifications
Stage
Time Code Events
DMX512
About Dimmer
Connecting
Set port start
Set signal speed
Double mode
Dwell time
Changing for submaster
Effects
Submaster Hold/Manual
E
 Edit

Edit
Clear submasters170Copy cues.99Copy submaster169, 170Cue List172Delete cue.98Delete part from multipart115Events.294Load submaster.169Macro.233Range of submasters.174
Effect
Create in Blind200Create in Stage204Cue type80Fade times214Insert steps210LTP channels in6Specifications354Submaster217Submaster type152Update207
Effect submaster defined

Enable
Blackout key
Bump buttons 29
ETCLink 264
Flexichannel
Record Lockout
Two scene mode
Encoder
Autoload
Print setup
Reset defaults
Setup
Error messages
About Dimmer
Diskette 335
Other
ETC locations 11
ETC MIDI
(See, also, MIDI Show Control)
Message format 279
FTCl ink
About Dimmer 47
Backup looks 275
Clear Loads 273
Dimmer status 267
Enable 264
Error messages general 265
Fatal messages 336
l oad check 272
Becord loads 271
Secondary messages 337
Set dimmer 27/
ETCLink address 264
Install remote monitor 333
Using ETCNet2 devices 316
Wiring 316
FTCNet2 devices
Discover nodes 327
Using on ETCNet 316
Wiring 316
ETCNet2 DMX Node 316
ETCNet2 Video Node
Events Edit 29/
Events, Luit
F
Fade
Multipart 117
Rate
Туре 80
Fade time

Changing for submaster.158Effect214Recording cue85, 86

	Set cue default	24 21
Fade	er	
	Back key12	21
	Background	4
	Clear	21
	Default Clear Time2	25
	Go	21
	Hold	21
	In two scene mode	59
	Manual	25
	Specifications	51
	Timed	20
Fixt	ure	
	Definition	7
		, 0
		sa
		Q Q
	Poloaco conturad channels	:2
		02 10
		0
ΓΙΧΙ		· ^
		00 74
		/
	Print setup	
	Reset defaults	2
	Setup	2
Fixt	ure box	'5
Fixt	ure patch	
	(See, also, Patch)	
	DMX512 start6	69
	Fixture box7	'5
	Flip6	69
	Personality6	9
	Print	51
	Remote dimmer6	69
	Start channel	69
	Swap focus	69
Flas	h٤	57
Flas	h scene	51
Flex	kichannel	
	Enable/Disable	27
	Purge Flexi	6
	Sample macro	35
	Selecting channels.	6
	Update 1	8
Flin	opadio	Ŭ
	About Channel	0
	Explained F	53
	Fixture natch	,0 ;0
	Sat F	, J 5/1
Foo	us noint	· -+
	Clear 25	5
	Defined 14	, J 1
	Doloto 14	
		.0

Maximum number 141
Print
Recording with solo
Setting linked levels 150
Show/hide link 144
Spreadsheet
Update
Use to park
Use to set levels 150
View on stage 144
Follow time, subroutine 221
Follow, cue playback
Format diskette 244
Frame rate 292
Full key 57

G

Н

Help 2
Highest Takes Precedence (HTP)
Explained
Set
Hold
Fader key
Pause timed crossfade
Submaster dwell 159
Hold-for-Go (subroutine)
Home position 152
1
Independent channel
Explained

Release	2
Set 54	1
Inhibitive submaster	
defined 152	2

Programming
Insert
Cue, using record
Cue, using track
Empty channel link
Installation
Alphanumeric keyboard
Console lights
Dimmers
ETCNet
MIDI Show Control
Printer
Remote Interface
Remote macro
Remote monitors
RFU

J Jumpers

oumpers	
Remote Interface	30
Jump-to-cue	21

K Ke

L Label

Label
Acceptable characters
Channel Attribute display53
Cue
Fixture
Focus point
Group
Submasters
Latest Takes Precedence (LTP)
About Channel
Background override
Blocking cue6
Enable
Overview
Set
Learn
Macro
Time code events

LEDs	
Submaster	156
Submaster type change	153
Level	001
In subroutines	221
	150
Evolained	57
Set	25
Setting unlinked levels	150
Link	
Creating	239
Cue to cue	. 88
Cues in playback	. 88
Delete	242
	240
	. 91
	230
Move	241
	241
List	212
Cue/Command	172
Focus point.	177
Group	176
Submaster/Command	173
Littlites	312
Console lights.	312
	323
Load	160
	272
Personality	66
Lockout Record	. 29
Loop	-
In subroutines	221
Of cues	. 90

M Ma

ас	ro	
	Cancel	232
	Clear	255
	Сору	234
	Creating	-228
	Display mode	228
	Edit	233
	Learn	226
	Link to cue	. 91
	Link to macro	230
	Macro Wait	229
	Modify	233
	Play	232
	Print	251
	Remote	325
	Remote Trigger	307
	Samples	234

Specifications
Manual
Override cue 125
Override submaster fade 167
Master slider 28
Master type setting 28
Memory 34
Memory utilization 34
Clear Eurotiona 254
Diakatta Eurotiana
Diskette Functions
(See, also, Time code program)
MIDI Show Control
(See, also, ETC MIDI)
Commands
Configuring
Disable
Installation
Interfacing with
Message definitions
Modify
Cue attributes
Macro 233
Multipart fade and wait 117
Submaster 16/
Move Link 241
Moving obangola defined
Moving Chamels, defined
(Cap. dag. <i>Fixtura</i>)
(See, also, rixture)
Patching
Print
Multipart cue
Converting regular cue to
Create
Defined111
Editing
Modify fade/wait
Update part
Wait time
Multipart cues
Definition
Delete part
Recording 112

Ν

Name
(See Label)
Navigation
Attribute setup
Effect
Encoder setup

Explained
Fixture patch 68, 70
Personality setup 65
Real time programs
Submaster list 174
Network
Compatibility 316
Thinnet

0

One-to-one patch 36
Only
Explained 8
Recall channels 8
Updating cue
Updating effect 207
Updating group
Optional equipment
Alphanumeric keyboard 321
Remote Focus Unit
Output level conventions 4

Ρ

Page	
Channel 14	4
Submasters 154, 16	1
Paging through displays 14	4
Park	
At focus point	2
Channel 192	2
Cue	4
Dimmer	C
Fixture	ō
Group	4
Submaster	4
Unpark channel	3
Unpark dimmer 19	1
Part	
Create	2
Delete from multipart cue 11	ō
Modify fade/wait	7
Update	6
Parts	2
Patch	
(See, also, Fixture patch)	
1-to-1	6
Captured channels	4
Custom	7
Dimmer 3	7
Display 19	3
Editing 7	5
Proportional patch 3	R
Reset 1-to-1 25	5
Pause fade 12	1
Pending cues	4

About Channel
Defaults
Definition
Fixture patch
Load
Print 251
Reset defaults 67
Setun 65–67
Viow 66
Pile on submaster defined
Pine-off Submaster, defined
Alphanumaria kaybaard 221
Printer
Remote Macro
Remote macros
RFU
Playback
Cues119, 124
Groups133, 144
Macro
Manual override
Specifications
Plavback display
Time Code list
Port
Set Dimmer Doubling 320
Set DMX512 start 310
Print
Options 250
Printor 222
Profile
Profile 41
Assign
Pre-defined40
Reset

Clear. 255 Create. 288 Enable/Disable 287 Print 251
Cue. 87 Dimmer loads. 271 Disable with Lockout 29 Explanation. 81 Follow. 89 Link cues 88 Multipart cues 112–115 Record Lockout 29 Recorded channels. 52 Recording cue with Solo 92, 131 Recording focus point with Solo 143 Sub minus sub 161 Submasters 155, 157 Recorded channels defined 52 Recorded channels defined 52
Remote dimmer, patching 69 Remote Focus Unit (RFU) About 310
Installation
DIP switches/jumpers
Installation 324 Remote Macro connectors 324 Remote Trigger 307 Remote Unit Upgrade display 327 Remote Video Interface
DIP switch settings
Categories72Dimmer profiles43Encoders74Fixture attributes72Profiles255Reset system254
Scenemaster
Backup looks275Dimmer Doubling48Monitoring263, 270System status267Serial interface306

Set
Channel levels
Channels to submasters
Clock
Default fade time
Default fader clear time
Default level
Default sneak time
Dimmer
Dimmer levels
Grandmaster type 28
Latitude 33
l evel kev 25
Longitude 33
I TP/HTP channel 55
Master type 28
Time zone 33
Show
Clear 255
Showfilo
Configuration contents 220
Evolution contents
Slider 20
Slider, Master
SIVIPTE
(See Time code program)
(See Time code program) Sneak
(See Time code program) Sneak Set default time
(See Time code program) Sneak Set default time 26 Use 58 Softkeys About 15 Flash 57 Quickstep 127 Unload sub 170 Software Upgrading a console 326 Upgrading remote interfaces 326 Solo Fixture focus 78 Recording a cue 92, 131 Recording a focus point Specifications 351–355 351–355 Split fade times 86 Spreadsheet Cue 179 Focus point 186 Group 184 Submaster 182 Step Delete 212 Insert 210 Subroutine 220

Strand CD80	49 221 28
Submaster	
Changing shows	154
Changing type	153
Clear	170, 255
Command display list	173
Сору	169
Copy cue or group	170
Default match to channels	28
Dwell hold	159
Effect	152 217
Event	102, 217
Fade and dwell times	15/
Fade times	158, 167
Home position	152
In macros	231
Inhibitive	152, 162
Label	168, 311
LEDs	156, 162
l ist	167
	169
	217
	167
	107
	164
Override fade time	167
Pages	154, 161
Park	194
Pile-on	152
Print	251
Range edit in Submaster List	174
Rate	160 167
Becord	100, 107
Recording	161
	107
	167
Spreadsheet	182
Types	152
Subroutine	
About	80
Allfade cue steps	220
Bounce style steps	221
Creating	222
Crossfade cue steps	220
Cue steps	220
	224
	224
	224
Hold for go style steps	
Inserting step	224
	221
Loop	221
Style steps	221
Times, fade and follow	221
Swap focus, fixture	69

Swap twisted pair	7
System settings	
Default Fade Time	4
Default fade time2	4
Default Fader Clear Time2	5
Default level	5
Flexichannel2	7
Number of channels	3
Number of dimmers	2
Record Lockout 2	9
Set Channels/Subs 1-to-1 2	8
Set time and date	2
System software ungrade 32	6
System Software upgrade	7
	/
Т	
Technical Services	1
Thinnet	
Older consoles	4
Time	
Default fade	4
Effect fade time	4
Effect Up/Dwell/Down 214–21	5
Follow time	g
Macro Wait 22	q
Set clock 3	1
Set system	2
Submactor 157 16	1
Subrouting fade and follow	1
VVdll	1
	4
	-
	5
Delete	8
Learn Mode	5
Print	1
lime Code list	3
Time code program	
Copy event	9
Edit event	1
External clock	4
Insert an event	8
Internal clock	3
Manual Mode	5
Manual playback	5
Move event	0
Pause Mode	5
Playback	3
Range edit	1
Reset loop	7
Setting frame rate 29	2
Step softkey 30	-
Timed fader	0
Track	2
About	1
Allfade	8
	-

Channel color
Twisted pair wiring
Two scene mode
A/B faders 259 C/D faders 257 Enable 258 Flash scene 261
Manual crossfade
Timed crossfade
Two scene status display 260
Type Cue

U

Unload submaster 1 Unpark	70
Channel 1	93
Dimmer 1	91
Fixture 1	96
Unpatch dimmer	39
Unset Dimmer 2	274
Update	
Channel 0	. 8
Cue	-97
Effect	207
Flexichannel	56
Focus point	46
Group	35
Only	. 8
Rate	98
Upgrading software 3	326
Using remote keyboard 3	311

V

Х								
XY mode			 			•	 	9